

# Owner's Manual

## Installation and Operation

**INSTALLER:** Leave this manual with party responsible for use and operation.

**OWNER:** Retain this manual for future reference.

**NOTICE:** DO NOT discard this manual!

### HEAT & GLO™

No one builds a better fire

IAPMO-R&T



GasMark


Ref No GMK10616  
AS/NZS 5263.1.3



### Models:

ST-HVBI-AUB

ST-HVBILP-AUB



**NOTE:** NOT INTENDED FOR  
FIREPLACE INSERT.

### ⚠ WARNING:

#### FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury, death, or property damage.

- **DO NOT** store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **What to do if you smell gas**
  - **DO NOT** try to light any appliance.
  - **DO NOT** touch any electrical switch. **DO NOT** use any phone in your building.
  - Leave the building immediately.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

# ⚠ DANGER



**HOT GLASS WILL  
CAUSE BURNS.**

**DO NOT TOUCH GLASS  
UNTIL COOLED.**

**NEVER ALLOW CHILDREN  
TO TOUCH GLASS.**

A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and shall be installed for the protection of children and other at-risk individuals.

**DO NOT PLACE ARTICLES ON OR AGAINST THIS APPLIANCE.**

**DO NOT USE OR STORE FLAMMABLE MATERIALS NEAR THIS APPLIANCE.**

**DO NOT SPRAY AEROSOLS IN THE VICINITY OF THIS APPLIANCE WHILE IT IS IN OPERATION.**

**DO NOT MODIFY THIS APPLIANCE.**

# HEAT & GLO™

No one builds a better fire

PLEASE READ THIS MANUAL BEFORE INSTALLING  
AND USING THIS APPLIANCE.

## **MODELS: ST-HVBI-AUB, ST-HVBILP-AUB**

### **ARE IAPMO OCEANA APPROVED FOR NATURAL GAS OR PROPANE AS A BALANCED FLUE HEATER.**

Refer to the appliance data plates for gas consumptions and pressures.

Installation of this appliance should only be carried out by an authorized person in accordance with the manufacturer's instructions. Appliance is to be installed in full compliance with the National Gas Installation Standard AS/NZS 5601, the manufacturer's instructions, and any local authorities' requirements for gas, electrical and building regulations.

This appliance and its components are tested and safe when installed in accordance with this Installation Manual. Report to your dealer any parts damaged in shipment, specifically check glass condition. The gas logs and flue system components are in separate packages. Read all instructions before starting installation and

follow these instructions carefully during installation to ensure maximum benefit and safety. Failure to follow them will void your warranty and may present a fire hazard.

The Heat & Glo, a brand of Hearth & Home Technologies warranty will be voided by, and Heat & Glo, a brand of Hearth & Home Technologies disclaims any responsibility for the following actions:

- Installation of any damaged heater or flue system component
- Modification of the heater or balanced flue system installation other than as instructed by Heat & Glo, a brand of Hearth & Home Technologies.
- Improper positioning of the gas logs or the glass door
- Installation and/or use of any component part not manufactured or approved by Heat & Glo, brand of Hearth & Home Technologies, notwithstanding any independent testing laboratory or other party approval of such component part or accessory.

**It is the responsibility of the professionals involved with the service and installation of the appliance to test the operation of the appliance before leaving the installation site.**

**IMPORTANT:** Read all instructions carefully before starting installation. Failure to follow these installation instructions may result in a possible fire hazard and will void the warranty. Save this manual for future reference.

Heat & Glo, a brand of Hearth & Home Technologies  
7571 215<sup>th</sup> Street West, Lakeville, MN 55044  
Copyright 2019 • Printed in U.S.A.

# TABLE OF CONTENTS

<b>1.0 INSTALLATION INSTRUCTIONS</b> .....	4
1.1 Locating the Heater .....	5
1.2 Framing the Heater.....	6
1.3 Exhaust Restrictor Installation.....	9
1.4 Flue System Approvals and Installations.....	10
1.5 Connecting the Gas Supply.....	22
1.6 Ignition System Wiring.....	23
1.7 Fan Wiring .....	24
1.8 Mantel Clearances.....	25
1.9 Log Placement.....	26
1.10 Installation / Removal of Optional Vanity Panel.....	28
1.11 Control Module Heat Shield Instruction .....	29
1.12 Installer Testing .....	30
<b>2.0 OPERATING INSTRUCTIONS</b> .....	31
2.1 Operation Cautions.....	31
2.2 Safety and Lighting Information.....	31
2.3 Control Module Operation .....	33
2.4 Remote Control Operation.....	34
<b>3.0 SERVICING AND MAINTENANCE</b> .....	39
3.1 Removal of Covers for Servicing .....	41
3.2 Removal of Components for Service.....	41
3.3 Parts Replacement .....	41
3.4 Adjustments and Replacement Parts .....	41
3.5 Maintenance Tasks.....	42
3.6 Troubleshooting .....	43
<b>4.0 SERVICE PARTS</b> .....	44
Limited Lifetime Warranty.....	47

## 1.0 INSTALLATION INSTRUCTIONS

When planning a heater installation, it's necessary to determine:

- Where the unit is to be installed.
- The flue system configuration to be used.
- Gas supply piping.
- Electrical wiring.
- Framing and finishing details.

- Whether optional accessories—devices such as wall switch, or remote control—are desired.

If the heater is to be installed on carpeting or tile, or on any combustible material other than wood flooring, the heater should be installed on a metal or wood panel that extends the full width and depth of the heater.




Figure 1. Diagram of the ST-HVBI-AU

## 1.1 Locating the Heater

The diagram below shows space and clearance requirements for locating a heater within a room.




Figure 2. Heater Dimensions and Locations

### Clearance Requirements

The top, back, and sides of the heater are defined by stand-offs. The minimum clearance to a perpendicular wall extending past the face of the heater is 1 in. (25 mm). The metal ends of the heater may **NOT** be recessed into combustible construction.

The distance from the unit to combustible construction is to be measured from the unit outer wrap surface to the combustible construction, **NOT** from the screw heads that secure the unit together.

Minimum Clearances from the Flue Pipe to Combustible Materials		
	<u>mm</u>	<u>Inches</u>
<b>Vertical Sections</b> .....	25	1
<b>Horizontal Sections</b>		
Top.....	76	3
Bottom.....	25	1
Sides.....	25	1
<b>At Wall Firestops</b>		
Top.....	64	2-1/2
Bottom.....	13	1/2
Sides.....	25	1

For minimum clearances, see the direct flue termination clearance diagrams on pages 6 and 7 in this manual.

Minimum Clearances from the Heater to Combustible Materials		
	<u>mm</u>	<u>inches</u>
Glass Sides or Ends.....	914	36
Floor.....	0	0
Rear Flue.....	13	1/2
Metal Sides or Ends.....	13	1/2
Top.....	64	2-1/2
Ceiling*.....	787	31

\* The clearance to the ceiling is measured from the top of the unit, excluding the standoffs (see Figures 1 and 2).

## 1.2. Framing the Heater


Framing can be built before or after the heater is set in place. Framing should be positioned to accommodate wall coverings and heater facing material. The diagram below shows framing reference dimensions.

**CAUTION:** MEASURE HEATER DIMENSIONS AND VERIFY FRAMING METHODS AND WALL COVERING DETAILS, BEFORE FRAMING CONSTRUCTION BEGINS.




**WARNING: FRAMING DIMENSIONS ASSUME USE OF 10 MM (THICK WALL COVERING MATERIALS ON EXTERIOR OF FRAMING ONLY AND NO SHEETROCK ON INTERIOR OF FRAMING.**

\* **Note:** These dimensions show the center of the horizontal flue pipe. The center of the framing hole is 1 in. (25 mm) above the center of the flue pipe. Framing should be constructed of 2 in. x 4 in. (51 mm x 102 mm) lumber or heavier.



**Figure 3. Framing Dimensions**




**LEGEND:**  
 I = Mechanical air inlet  
 M = Gas meter  
 P = Electricity meter or fuse box  
 S = Structure  
 T = Flue terminal  
 Z = Fan-assisted appliance only  
 Shading indicates prohibited area for flue terminals

Ref.	Item	Minimum Clearance (mm)	
		Natural Draft	Fan Assisted
a	Below eaves, balconies or other projections		
	Appliances up to 50 MJ/h input	300	200
	Appliances over to 50 MJ/h input	500	300
b	From the ground or above a balcony		
	Appliances 32 MJ/h and below	300	355
	Appliances from 32 MJ/h to 53 MJ/h	300	410
	Appliances 53 MJ/h and above	300	460
c	From a return wall or external corner	500	300
d	From a gas meter (M)	1000	1000
e	From an electricity meter or fuse box (P)	500	500
f	From a drain or soil pipe	150	75
g	Horizontally from any building structure (unless appliance approved for closer installation) or obstruction facing a terminal	500	500
h	From any other flue terminal, cowl, or combustion air intake	500	300
j	Horizontally from an openable window, door, non-mechanical air inlet, or any other opening into a building, with the exception of sub-floor ventilation		
	Appliances up to 150 MJ/h input	500	300
	All fan assisted appliances in the direction of discharge	-	1500
k	From a mechanical air inlet, including a spa fan	1500	1000
n	Vertically below an openable window, non-mechanical air inlet or any other opening into a building, with the exception of See table sub-floor ventilation		
	For space heaters up to 50 MJ/h input	150	150
	For other appliances up to 50 MJ/h input	500	500
	For appliances over 50 MJ/h input and up to 150 MJ/h	1000	1000
	For appliances over 150 MJ/h input	1500	1500

- NOTES:**
- All distances are measured vertically or horizontally along the wall to a point in line with the nearest part of the terminal.
  - Prohibited area below electricity meter or fuse box extends to ground level.
  - Flue terminal under covered area:
    - The covered area or recess shall be open on at least two sides.
    - Fan assisted flue appliance shall have at least one side open and the terminal shall be within 500 mm of the opening and discharging in the direction of the opening.
  - Clearance from a flue terminal to a LP cylinder shall be a minimum of 1 meter.

**MINIMUM CLEARANCES REQUIRED FOR BALANCED FLUE TERMINALS OR THE FLUE TERMINALS OF OUTDOOR APPLIANCES**

**Figure 4**



**NOTE: PIPES OVERLAP 32 mm (1-1/4 in.) AT EACH JOINT.**

**Figure 5. DVP-Series Direct Flue Component Specifications (127 mm (5 in.) inner pipe / 203 mm (8 in.) outer pipe)**



### 1.3. Exhaust Restrictor Installation

Exhaust restrictors are recommended for these vertically terminated products which have excessive draft. Exhaust restrictors will compensate for high draft and restore visual flame height. If the vent configuration has a total vertical of 15 ft. - 40 ft. (4.6 m - 122 m) an exhaust restrictor may be needed. The exhaust restrictor can be located in the manual bag.

#### Exhaust Restrictor Instructions:

1. Locate the center vent hole of the air passage on the inside firebox chamber as shown in Figure 6.
2. Center the exhaust restrictor such that the center hole of the restrictor aligns with the center vent hole of the air passage inside the firebox chamber.
3. Use (2) 1/2 in. (13 mm) self-tapping screws to secure exhaust restrictor to the firebox air passage. See Figure 7.
4. In some applications, such as those that where the fireplace is elevated off the floor, the exhaust restrictor may be painted but painting is not required.

**NOTICE:** Before painting, contact your dealer for information on the appropriate high temperature paint.




Figure 6. Air Passage Inside Firebox




Figure 7. Exhaust Restrictor - Air Passage

## 1.4 Flue System Approvals and Installation

### A. Flue System Approvals

These models are approved to use DVP series direct flue pipe components and terminations (see Figures 5 and 8). Approved flue system components are labeled for identification. This pipe is tested and listed as an approved component of the heater. The pipe is tested to be run inside an enclosed wall. There is no requirement for inspection openings at each joint within the wall. There is no required pitch for horizontal flue runs. **NO OTHER FLUEING SYSTEMS OR COMPONENTS MAY BE USED.**

Detailed installation instructions are included with each flue termination kit and should be used in conjunction with this *Installers Guide*.

The flame and ember appearance may vary based on the type of fuel burned and the flueing configuration used.

### Identifying Flue Components

The flue systems installed on this gas heater may include one, two, or three 90° elbow assemblies. The relationships of vertical rise to horizontal run in flue configurations using 90° elbows **MUST BE** strictly adhered to. The rise to run relationships are shown in the flueing drawings and tables. Refer to the diagrams on the next several pages.

This model has a 45° elbow built into it. It may be positioned to flue either horizontal or vertical. Depending on the installation, decide which direction the elbow should be facing. Remove the 8 screws from the corner cover plate. Position the 45° elbow as desired and replace the corner cover plate with the 8 screws.




Figure 8. Flue System Components and Termination Kits

**STRAIGHT UP  
VERTICAL FLUEING  
V (FT.)  
12.2 M MAX. (40 ft.)**

TERMINATION CAP




Figure 9

**STRAIGHT OUT  
HORIZONTAL FLUEING  
H  
Max. Run  
610 mm (24 in.)**





Figure 10

**NATURAL GAS - FLUEING WITH ONE 90° ELBOW**


V (FT.)	H (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
6' MIN. (1.83 m)	18' MAX. (5.5 m)
V + H = 40' MAX. (12.2 m)	

**PROPANE - FLUEING WITH ONE 90° ELBOW**

V (FT.)	H (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
6' MIN. (1.83 m)	12' MAX. (3.6 m)
V + H = 40' MAX. (12.2 m)	



**Figure 11. Flueing with One 90° Elbow**




**NATURAL GAS  
FLUEING WITH ONE 90° ELBOW**

V (FT.)	H (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
V + H = 40' MAX. (12.2 m)	

**PROPANE  
FLUEING WITH ONE 90° ELBOW**

V (FT.)	H (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
V + H = 40' MAX. (12.2 m)	

**Figure 12. Flueing with One 90° Elbow**



NATURAL GAS	
FLUEING WITH TWO 90° ELBOWS	
V (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
V + H + H <sub>1</sub> = 40' MAX. (12.2 m)	
H + H <sub>1</sub> = 15' MAX. (4.5 m)	

PROPANE	
FLUEING WITH TWO 90° ELBOWS	
V (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
V + H + H <sub>1</sub> = 40' MAX. (12.2 m)	
H + H <sub>1</sub> = 10' MAX. (3.0 m)	

NATURAL GAS	
FLUEING WITH TWO 90° ELBOWS	
V + V <sub>1</sub> (FT.)	H (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
V + V <sub>1</sub> + H = 40' MAX. (12.2 m)	

PROPANE	
FLUEING WITH TWO 90° ELBOWS	
V + V <sub>1</sub> (FT.)	H (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
V + V <sub>1</sub> + H = 40' MAX. (12.2 m)	




Figure 13. Flueing with Two 90° Elbows

NATURAL GAS FLUEING WITH TWO 90° ELBOWS	
V (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
V + H + H <sub>1</sub> = 40' MAX. (12.2 m)	
H + H <sub>1</sub> = 15' MAX. (4.5 m)	

PROPANE FLUEING WITH TWO 90° ELBOWS	
V (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
V + H + H <sub>1</sub> = 40' MAX. (12.2 m)	
H + H <sub>1</sub> = 10' MAX. (3.0 m)	




Figure 14. Flueing with Two 90° Elbows

NATURAL GAS FLUEING WITH TWO 90° ELBOWS	
V (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
V + H + H <sub>1</sub> = 40' MAX. (12.2 m)	
H + H <sub>1</sub> = 15' MAX. (4.5 m)	

PROPANE FLUEING WITH TWO 90° ELBOWS	
V (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
V + H + H <sub>1</sub> = 40' MAX. (12.2 m)	
H + H <sub>1</sub> = 10' MAX. (3.0 m)	





Figure 15. Flueing with Two 90° Elbows



**NATURAL GAS**  
**FLUEING WITH THREE 90° ELBOWS**

V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
V + V <sub>1</sub> + H + H <sub>1</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> = 15' MAX. (4.5 m)	

**PROPANE**  
**FLUEING WITH THREE 90° ELBOWS**

V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
V + V <sub>1</sub> + H + H <sub>1</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> = 10' MAX. (3.0 m)	

**NATURAL GAS**  
**FLUEING WITH THREE 90° ELBOWS**

V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> + H <sub>2</sub> (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
V + V <sub>1</sub> + H + H <sub>1</sub> + H <sub>2</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> + H <sub>2</sub> = 12' MAX. (3.6 m)	


**PROPANE**  
**FLUEING WITH THREE 90° ELBOWS**

V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> + H <sub>2</sub> (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
V + V <sub>1</sub> + H + H <sub>1</sub> + H <sub>2</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> + H <sub>2</sub> = 8' MAX. (2.4 m)	

Figure 16. Flueing with three 90° elbows

NATURAL GAS FLUEING WITH THREE 90° ELBOWS	
V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
V + V <sub>1</sub> + H + H <sub>1</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> = 12' MAX. (3.6 m)	

PROPANE FLUEING WITH THREE 90° ELBOWS	
V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
V + V <sub>1</sub> + H + H <sub>1</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> = 8' MAX. (2.4 m)	



NATURAL GAS FLUEING WITH THREE 90° ELBOWS	
V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	3' MAX. (914 mm)
2' MIN. (610 mm)	6' MAX. (1.83 m)
3' MIN. (914 mm)	9' MAX. (2.7 m)
4' MIN. (1.22 m)	12' MAX. (3.6 m)
5' MIN. (1.5 m)	15' MAX. (4.5 m)
V + V <sub>1</sub> + H + H <sub>1</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> = 15' MAX. (4.5 m)	

PROPANE FLUEING WITH THREE 90° ELBOWS	
V + V <sub>1</sub> (FT.)	H + H <sub>1</sub> (FT.)
1' MIN. (305 mm)	2' MAX. (610 mm)
2' MIN. (610 mm)	4' MAX. (1.22 m)
3' MIN. (914 mm)	6' MAX. (1.83 m)
4' MIN. (1.22 m)	8' MAX. (2.4 m)
5' MIN. (1.5 m)	10' MAX. (3.0 m)
V + V <sub>1</sub> + H + H <sub>1</sub> = 36' MAX. (10.9 m)	
H + H <sub>1</sub> = 10' MAX. (3.0 m)	

Figure 17. Flueing with three 90° elbows



## → B. Power Vent Configurations

The PVLP-SLP-AU power vent is approved for use with this appliance.

Table 4.1 below shows the allowable vent length and elbow combinations when using PVLP-SLP-AU. Refer to the PVLP-SLP-AU instruction manual for limitations and appliance specific requirements.

Horizontal Termination													
Total Venting Length (Feet) Includes both horizontal and vertical section of pipe													
# of Elbows	10 ft. (3.05 m)	20 ft. (6.10 m)	30 ft. (9.14 m)	40 ft. (12.19 m)	50 ft. (15.24 m)	60 ft. (18.29 m)	70 ft. (21.34 m)	80 ft. (24.38 m)	90 ft. (27.43 m)				
1													
2													
3	<b>ALLOWABLE VENT RUNS</b>												
4													
5													
6													
7													
8													
9													
10													
11													
12													

NOT
ALLOWED

Table 4.1 Allowable Vent Runs - Horizontal Termination

## B. Installing Flue Components

After determining which direction the 45° elbow will be used follow flueing instructions accordingly.

- This heater requires the attachment of supplied 45° elbow to unit before connection of flue components.
- To attach the elbow flue, the elbow cover plate must first be removed from the unit (see Figure 18).
- The elbow can be removed from the unit by aligning the seams of the elbow to the arrows on the surrounding heat shield (see Figure 19).
- Position the elbow in the horizontal or the vertical position. Snap in place with the starting collar.
- Replace the elbow cover plate aligning it with the elbow and secure in place with the 8 screws.
- Place the rope ring around the first section of pipe and slide it up against the cover plate.

**NOTE:** The rope ring is needed for the heat management and to prevent cold air infiltration.








Figure 20

<b>⚠ WARNING</b>	
  	<p>Fire Risk Exhaust Fumes Risk Impaired Performance of Appliance</p> <ul style="list-style-type: none"> <li>• Overlap pipe slip sections at least 1-1/2 inches (38 mm).</li> <li>• Use pilot holes for screws.</li> <li>• Screws must not exceed one inch long.</li> <li>• Pipe could separate if not properly joined.</li> </ul>

### C. Assembling Flue Components

Insert the inner flue of section A into the flared inner flue of section B.

Start the outer flue of section A over the outer flue of section B (see Figure 21). **Note:** The end of the pipe sections with the lances/tabs on it will face towards the appliance.




Figure 21



Figure 22

Once both inner and outer flues are started, press section A onto section B firmly until all lances have snapped into place. Check to make sure they have snapped together (see Figure 22) and the seams are not aligned (see Figure 23). Tug slightly on section A to confirm it has completely locked into place.




Figure 23. Seams

**Note:** Make sure that seams are **NOT** aligned to prevent unintentional disconnection.

For elbows that are changing the flue direction, two screws minimum should be put in the outer flue at the joint to prevent the elbow from rotating.

## D. Install Support Brackets

Refer to Cinch Pipe and Termination Cap installation Instructions.

## E. Install Firestops

**For Horizontal Runs** - Firestops are **REQUIRED** on both sides of a combustible wall through which the flue passes.

**Note:** Model DVP-TRAP2 does not need an exterior firestop on an exterior combustible wall. The firestop is built into the cap.

To install firestops (heat shield) for horizontal runs that pass through either interior or exterior walls:

- Cut a 10 in. x 12 in. (254 mm x 305 mm) hole through the wall.

**Note:** The center of the hole is 1 in. (25 mm) above the center of the horizontal flue pipe.

- Position the firestops on both sides of the hole previously cut and secure the firestops with nails or screws.
- The heat shields of the firestops **MUST BE** placed towards the bottom of the firestop.
- Continue the flue run through the firestop.

**Note:** There must be **NO INSULATION** or other combustibles inside the framed firestop opening.




Figure 24. 254 mm x 305 mm Hole and Flue Pipe




Figure 25. Heat Shield, Interior & Exterior Firestops

**For Vertical Runs** - One firestop is **REQUIRED** at the hole in each ceiling through which the flue passes.

To install firestops for vertical runs that pass through ceilings:

- Position a plumb bob directly over the center of the vertical flue component.
- Mark the ceiling to establish the centerpoint of the flue.
- Drill a hole or drive a nail through this center point.
- Check the floor above for any obstructions, such as wiring or plumbing runs.
- Reposition the heater and flue system, if necessary, to accommodate the ceiling joists and/or obstructions.
- Cut a 10" x 10" (254 mm X 254 mm) hole through the ceiling, using the firestop pipe opening as a guide.
- Frame the hole with framing lumber the same size as the ceiling joists.





Figure 26. Hole & New Framing Members

If the area above the ceiling is **NOT** an attic, position and secure the ceiling firestop **ON** the ceiling side of the previously cut and framed hole.




**Figure 27. Ceiling Firestop (Ceiling Side)**

If the area above the ceiling **IS** an attic, position and secure the firestop on top of the previously framed hole.

**NOTE:** Keep insulation away from the flue pipe at least 1 in. (25 mm).

**NOTE:** There must be **NO INSULATION** or other combustibles inside the framed firestop opening.




**Figure 28. Attic Firestop**

## F. Flue Termination

**For Horizontal Terminations** - To attach and secure the termination to the last section of horizontal flue:

- The rear flue heat shield **MUST** be placed one inch above the top of the flue between the wall shield and the base of the termination cap.
- One section of the heat shield is attached to the wall shield. The other is attached to the termination cap in the same manner.
- The heat shield sections will overlap to match the wall thickness (depth).
- If the wall thickness does not allow the required 1-1/2 in. (38 mm) heat shield overlap, an extended heat shield must be used. The extended heat shield will need to be cut to the thickness of the wall and be attached to the wall shield.
- The small leg in the shield rests on top of the flue to properly space it from the pipe section (see Figure 29).



**Figure 29. Flueing through the Wall**


- The termination kit should pass through the wall firestops from the exterior of the building.

- Adjust the termination cap to its final exterior position on the building and interlock the flue sections.



**WARNING: THE TERMINATION CAP MUST BE POSITIONED SO THAT THE ARROW IS POINTING UP.**

- Use a high-temperature sealant gasket to seal between the pipe and exterior firestop.



**Figure 30. Termination Cap**

**For Vertical Terminations** - To locate the flue and install the flue sections:

- Locate and mark the flue center point on the underside of the roof, and drive a nail through the center point.
- Make the outline of the roof hole around the center point nail.
- The size of the roof hole framing dimensions depend on the pitch of the roof. There **MUST BE** a 1 in. (25 mm) clearance from the vertical flue pipe to combustible materials.
- Mark the roof hole accordingly.
- Cover the opening of the installed flue pipes.
- Cut and frame the roof hole.
- Use framing lumber the same size as the roof rafters and install the frame securely. Flashing anchored to the frame must withstand heavy winds.
- Continue to install concentric flue sections up through the roof hole and up past the roof line until you reach the appropriate distance above the roof.



**WARNING: FOLLOWING NATIONAL REGULATIONS AND CODES OF PRACTICE FOR MINIMUM CLEARANCES FROM GAS TERMINALS, AND PLACEMENT OF GAS TERMINAL.**


**NOTE:** This also pertains to vertical flue systems installed on the outside of the building.

To seal the roof hole, and to divert rain and snow from the flue system:



- Attach a flashing to the roof using nails, and use a non-hardening flexible joint sealant around the edges of the flashing base where it meets the roof.
- Attach a storm collar over the flashing joint to form a water-tight seal. Place non-hardening flexible joint sealant around the joint, between the storm collar and the vertical pipe.
- Slide the termination cap over the end of the flue pipe and snap into place.

**NOTICE:** Failure to properly caulk the roof flashing and pipe seams could permit entry of water.

- Caulk the gap between the roof flashing and the outside diameter of the pipe.
- Caulk the perimeter of the flashing where it contacts the roof surface. See Figure 31.
- Caulk the overlap seam of any exposed pipe sections that are located above the roof line.



**Figure 31**



### 1.5 CONNECTING THE GAS SUPPLY

The gas is introduced to the appliance on the left hand side (see Figure 33). After the gas pipe installation is complete, check carefully all gas connections for leaks with a soap solution. **DO NOT USE AN OPEN FLAME.**

**Note:** Have the gas supply line installed in accordance with local building codes by a qualified installer approved and/or licensed as required by the locality.

**Note:** Before the first firing of the appliance, the gas supply line should be purged of any trapped air.

**Note:** Consult local building regulations to properly size the gas supply line leading to the (Rp 1/2 in.) hook-up at the unit.

Incoming gas line should be piped into the valve compartment and connected to the ISO 7-Rp 1/2 (BSP Rp 1/2) threaded gas inlet connection on the manual shutoff valve.


**IMPORTANT NOTICE: (Items 1, 2 and 3 applies to ALL Heat & Glo gas appliances)**

- 1/2 in. GAS LINE:** Run through cavity 70 mm above finished hearth level, **NOT RIGID, NOT CLIPPED**, with minimum 500 mm into cavity and 120 mm back from plaster face.
- PVC (COMPOSITE) GASLINE** must terminate minimum 500 mm short of gas heater. Copper pipe **MUST** be the final connection to the gas heater.
- ISOLATING SWITCH:** Location within 1 metre of fireplace, subject to mantelpiece etc. Check to ensure it remains clear of any mantelpiece installation.

Leak test all gas line points and the gas control valve prior to and after starting the gas appliance.

## 1.6 IGNITION SYSTEM WIRING

- This gas heater is equipped with an electronic ignition system which operates on a 6 volt system.
- This appliance requires 220/240 VAC to be wired to the factory installed junction cord. Check factory installed power cord for damage before using.




**⚠ WARNING**

Shock hazard.

- Replace damaged wire with type 105° C (221° F) rated wire.
- Wire must have high temperature insulation.

CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.





## 1.7 Fan WIRING

These heaters have a factory installed electrical junction cord, variable speed fan and temperature sensing remote. These components are located behind the front. Use of the fan requires that the junction cord (factory installed) be connected to 220/240 VAC service before permanently enclosing the heater. The access hole for connecting the service wires is found on the lower exterior side of the appliance. See Figure 33. Figure 35 shows the fan and junction cord wiring diagram.

**NOTE:** If the supply cord is damaged, it must be replaced by the manufacturer, an authorized service agent, or a similarly qualified person in order to avoid a hazard.

**Note:** if any of the original wire as supplied with the appliance must be replaced, it must be replaced with type 105 °C (221 °F) rated wire. Wires must have high temperature insulations.




Figure 35. Fan and Junction Cord Wiring Diagram

## 1.7 MANTEL CLEARANCES

Clearance to a mantelpiece is 279 mm. See Figure 35.

If joints between the finished walls and the heater surround (top and sides) are sealed, a 149 °C (300 °F) minimum sealant material must be used. These joints are not required to be sealed. Only non-combustible material (using 149 °C (300 °F) minimum adhesive, if needed) can be applied as facing to the heater surround (see Figure 38).




Figure 37






Figure 38

## 1.9 LOG PLACEMENT



## Log Assembly: LOG-ST-CE



**CAUTION:** Logs are fragile. Carefully remove the log packages from the heater and the tags from their packages. Handle logs gently. Place the logs in the heater by following the steps shown. Replace the glass door and dress guard previously removed prior to lighting the unit. Be certain the gas logs are properly positioned. Logs #4 and #5 are the same log. See Service Parts pages for individual assembly photos.




**LOG #1 (SRV2068-700):** Place log #1 behind grate tabs on the second and third grate bars on the left rear corner. Position so that the bottom grooves fit over bars and the log is snug against the grate tabs.



**LOG #2 (SRV2068-701):** Locate log #2 in left front corner of the log grate using bottom grooves for placement. Push log against grate tabs on first and second bars.



**LOG #3 (SRV2068-702):** Position log #3 across the third, fourth and fifth grate bars and push towards the rear against the grate tabs on bars three and five.



**LOG #4 (SRV2068-703):** Place log #4 in the right rear corner of the log grate using bottom grooves for placement. Align log #4 by using the grate corner and rear cross bar as stops.



**LOG #5 (SRV2068-703):** Place log #5 on top of flat spot on log #1 and against the inside of log #2. Be careful not to reposition log #2 when placing this log.



**LOG #6 (SRV582-705):** Position log #6 on top of the groove in log #3 with the forked end resting on the grate assembly as shown.

### 1.10. Installation / Removal of Optional Vanity Panel

- Remove packaging from around the vanity panel.
- Remove front from appliance.
- Locate valve mount bracket.

If necessary, loosen wing nut on bracket and rotate ground wire as shown in Figure 39. Tighten wing nut. Note hole used for fastening vanity panel.

- Place vanity panel in appliance on right side of component cavity, and slide left into position as shown in Figure 40.
- Attach with 1/4 in. (6 mm) hex fastener (in manual bag) until snug.




Figure 39 Wing Nut on Bracket




Figure 40 Hex Fastener

- Reattach front.

## 1.11. Control Module Heat Shield Installation

**CAUTION! Risk of Cuts, Abrasions or Flying Debris.**

*Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.*

- Remove black sheet metal plate from manual bag. Bend (3) tabs approximately 90 degrees on plate to form shield as shown in Figure 41.




Figure 41. Heat Shield Bends

- Position heat shield in appliance over control module, being careful not to pinch any wires. The (2) narrow legs of the heat shield are facing the rear of the appliance. See Figure 42.



Figure 42. Heat Shield Placement

## 1.12 INSTALLER TESTING

The space heater must be tested and be operating according to manufacturers specifications prior to the installer leaving the site. Note: the tips of the flames should never hit the top of the firebox after the unit has warmed up. Please contact your dealer or a qualified service person to replace injector or adjust valve.

Upon completing the gas line connection, a small amount of air will be in the lines. When first lighting the pilot, it will take a few minutes for the lines to purge themselves of this air. Once the purging is complete, the pilot and burner will light and operate as indicated in the Lighting Instructions.

Subsequent lightings of the appliance will not require such purging.

Follow the Safety Information and Lighting Instructions pages of this manual to light the appliance.

To obtain proper operation, it is imperative that the pilot and main burner flame characteristics are steady, not lifting or floating. Typically, the top 3/8 inch (9.5 mm) of the flame sensor rod should be engulfed in the pilot flame (see Figure 43). See Table 1 for pressure requirements. See Table 2 for primary aeration settings.

Follow TROUBLESHOOTING section for adjusting the appliance to operate properly.



Figure 43. Pilot Assembly

Table 1.

	Natural Gas	Propane Gas
Inlet Gas Pressure	1.13 -3.40 kPa	2.75 -3.40 kPa
* Outlet (Manifold) Gas Pressure	.80 kPa	2.40 kPa
Max. Gas Consumption	44.0 MJ/h	42.5 MJ/h
Burner Injector	#30 (3.26 mm)	#49 (1.85 mm)

\* The allowable Outlet (Manifold) Gas Pressure ranges are: Natural Gas .80 - .95 kPa (.87 kPa nominal) and Propane. Certification testing setpoint values are shown.

An in-line regulator MUST be installed if the gas pressure exceed **3.40 kPa**. Failure to install a regulator could damage valve.

Table 2 .

Gas Type	Aeration Setting
Natural Gas	1/2 in. (13 mm)
Propane Gas	Full Open

## 2.0 OPERATING INSTRUCTIONS

This appliance is a balanced flue heater and is designed to operate with all combustion air being siphoned from the outside of the building and all exhaust gases expelled to the outside of the building.

**WARNING: THIS UNIT IS NOT FOR USE WITH SOLID FUEL.**

The control system for this model employs an electronic pilot ignition. It consists of a 6V gas control valve/variable regulator, an electronic module, a thermocouple and a remote control. The controls are located in the compartment behind the front, and access is gained by lifting the door up.

**WARNING: DO NOT CONNECT 220/240 VAC TO THE GAS CONTROL VALVE OR CONTROL WIRING SYSTEM OF THIS UNIT.**

When lit for the first time, the appliance will emit a slight odor for an hour or two. This is due to paint and lubricants used in the manufacturing process. Additionally, for the first few minutes after each lighting, vapor could condense and fog the glass and the flames may be blue. After a few minutes this moisture will disappear and within 15-30 minutes the flames should become yellow.

The heater may produce a noise, caused from metal expansion and contraction as it heats up and cools down. This noise is similar to one that a furnace or heat duct may produce and does not affect the operation or longevity of the heater.

**NOTE:** An inline fuel pressure regulator is recommended to limit NG inlet pressure to 2.49 kPa, and LP inlet pressure to 3.25 kPa, to ensure optimum product performance. The inline fuel pressure regulator may be needed if any of the following symptoms exist: pilot jetting, a highly visible pilot flame, flame variation, etc. The inline pressure regulator should be installed in the gas line upstream of the appliance gas valve either at the appliance or in the utility room. Final main and manifold gas pressure must be tested with inline pressure regulator installed.




Figure 44

## ⚠ WARNING



### HOT SURFACES!

Glass and other surfaces are hot during operation AND cool down.

### Hot glass will cause burns.

- **DO NOT** touch glass until it is cooled
- NEVER allow children to touch glass
- Keep children away

- CAREFULLY SUPERVISE children in same room as fireplace.
- Alert children and adults to hazards of high temperatures.

### High temperatures could ignite clothing or other flammable materials.

- Keep clothing, furniture, draperies and other flammable materials away.

***This appliance has been supplied with an integral barrier to prevent direct contact with the fixed glass panel. DO NOT operate the appliance with the barrier removed.***

## 2.1 OPERATING CAUTIONS

- This appliance could exhibit a slight carbon deposition.
- Do not place articles on or against this appliance.
- Do not use or store flammable materials near this appliance.
- Do not spray aerosols in the vicinity of this appliance while it is in operation.

- The dress guard is fitted to this appliance to reduce the risk of fire or injury from burns and no part of it should be permanently removed. For protection of young children or the infirm, a secondary guard is required.
- The dress guard must be in place and sealed and the fixed mesh trim assembly must be in place on the heater before the unit can be placed into safe operation.
- Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the unit and to replace any part of the control system and any gas control which has been underwater.
- Do not operate this appliance with the glass door removed, cracked, or broken. Replacement of the glass door should be done by a licensed or qualified person. Do not strike or slam the glass door.
- The glass door assembly shall only be replaced as a complete unit as supplied by the gas heater manufacturer. No substitute materials may be used.

## 2.2. SAFETY & LIGHTING INFORMATION

Follow **SAFETY INFORMATION** and **LIGHTING INSTRUCTIONS** to light the appliance.

By design, the flame pattern will not be identical from unit to unit. Additionally, flame pattern may vary depending on installation type and weather conditions.

**NOTE: THE TIPS OF THE FLAMES SHOULD NEVER HIT THE TOP OF THE FIREBOX.**



## LIGHTING INSTRUCTIONS (IPI)

### FOR YOUR SAFETY READ BEFORE LIGHTING




**WARNING:** If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- A. This appliance is equipped with an intermittent pilot ignition (IPI) device which automatically lights the burner. **DO NOT** try to light the burner by hand.
  - B. **BEFORE LIGHTING**, smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
- WHAT TO DO IF YOU SMELL GAS**
- **DO NOT** try to light any appliance.
  - **DO NOT** touch any electric switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, **DO NOT** try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
  - D. **DO NOT** use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

### LIGHTING INSTRUCTIONS (IPI)

1. This appliance is equipped with an ignition device which automatically lights the burner. **DO NOT** try to light the burner by hand.
2. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, **STOP!** Follow "B" in the Safety Information located on the top of this label. If you do not smell gas, go to next step.
3. To light the burner:  
Equipped with wall switch: Turn ON/OFF switch to ON.  
Equipped with remote or wall control: Press ON or FLAME button.  
Equipped with thermostat: Set temperature to desired setting.
4. If the appliance does not light after three tries, call your service technician or gas supplier.

**GAS  
VALVE**



### TO TURN OFF GAS TO APPLIANCE

1. Equipped with wall switch: Turn ON/OFF switch to OFF.  
Equipped with remote or wall control: Press OFF button.  
Equipped with thermostat: Set temperature to lowest setting.
2. Service technician should turn off electric power to the control when performing service.



# DANGER



**HOT GLASS WILL CAUSE BURNS.  
DO NOT TOUCH GLASS UNTIL COOLED.  
NEVER ALLOW CHILDREN TO TOUCH GLASS.**

A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and shall be installed for the protection of children and other at-risk individuals.

## WARNING:

**DO NOT CONNECT LINE VOLTAGE (110/120 VAC OR 220/240 VAC) TO THE CONTROL VALVE.**

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with this appliance. For assistance or additional information, consult a qualified installer, service agency or the gas supplier.

This appliance needs fresh air for safe operation and must be installed so there are provisions for adequate combustion and ventilation air.

If not installed, operated, and maintained in accordance with the manufacturer's instructions, this product could expose you to substances in fuel or fuel combustion which are known to the State of California to cause cancer, birth defects, or other reproductive harm.

Keep burner and control compartment clean. See installation and operating instructions accompanying appliance.

## CAUTION:

Hot while in operation. **DO NOT** touch. Keep children, clothing, furniture, gasoline and other liquids having flammable vapors away.

**DO NOT** operate the appliance with fixed glass assembly removed, cracked or broken. Replacement of the fixed glass assembly should be done by a licensed or qualified service person.

### NOT FOR USE WITH SOLID FUEL

For use with natural gas and propane. A conversion kit, as supplied by the manufacturer, shall be used to convert this appliance to the alternate fuel.

Also Certified for Installation in a Bedroom or a Bedsitting Room.

This appliance must be installed in accordance with local codes, if any; if none, follow the *National Fuel Gas Code, ANSIZ223.1/NFPA 54, or the National Gas and Propane Installation code, CSA B149.1.*

For additional information on operating your  
Hearth & Home Technologies fireplace, please refer to [www.fireplaces.com](http://www.fireplaces.com).

593-913i

## 2.3 CONTROL MODULE OPERATION

1. The control module has an ON/OFF/REMOTE selector switch that must be set. See Figure 43.

**OFF Position:** Appliance will ignore all power inputs and will not respond to any commands from a wall switch or optional remote. The unit should be in the OFF position during installation, service, battery installation, fuel conversion, and in the event that the control goes into LOCK-OUT mode as a result of an error code.

**ON Position:** Appliance will ignite and run continuously in the HI flame setting, with no adjustment in flame output. This mode of operation is primarily used for initial installation or power outage operation with battery backup.

**REMOTE Position:** Appliance will initiate commands from a wired wall switch and/or one of the optional wireless remote options.

2. A wall switch can be wired into the control module brown and red wires. See Figure 44.
3. If using a wired wall switch with the module in REMOTE mode, the flame output can be adjusted with the HI/LO selector switch on the module. See Figure 45. Note that the flame HI/LO selector switch will become inactive once an optional remote control (RC200/RC300) is programmed to the control module. Note that the control module will always ignite the fireplace on HI and remain so for the initial 10 seconds of operation. If the HI/LO is switched to the LO position, the flame output will automatically drop to the lowest setting after the flame has been established for 10 sec. After this 10 second period, the flame can be adjusted from HI to LO with the switch.
4. The control module has safety feature that automatically shuts down the fireplace after 9 hours of continuous operation without receiving a command from the wall switch or optional remote.
5. If you intend to use both a wired wall switch and an optional remote control to operate your fireplace, the wall switch will override any commands given by the remote.
6. The module has the capability to recognize potential malfunctions. If these occur, it will fail to ignite and/or respond to a command to ignite via the wall switch and/or optional remote. In this case, the module may have gone into LOCK-OUT mode. In this state, it will emit a LED error code. To reset the error code, switch the selector to OFF, and then back to REMOTE or ON. If the ignition command again fails, the module will emit an LED error code, prior to going back into LOCK-OUT mode. Contact your dealer for service if this occurs.




Figure 45. Control Module

### Nine Hour Safety Shutdown Feature

This appliance has a safety feature that automatically shuts down the fireplace after 9 hours of continuous operation without receiving a command from the RC300AU remote.

## 2.4 REMOTE CONTROL OPERATION

Hearth & Home Technologies disclaims any responsibility for, and the warranty will be voided by, the following actions:

- Installation and use of any damaged system component.
- Modification of the system component.
- Installation other than as instructed by Hearth & Home Technologies.
- Installation and/or use of any component part not approved by Hearth & Home Technologies.

**Any such action could cause a fire hazard.**

- Read, understand and follow these instructions for safe installation and operation.

### Fireplace Specific Information

Standard fireplace features vary. Consult the installation manual for available options.

The included **AUX300CE** receiver provides additional features: Fan control and two Aux functions.

The **RC300AU** remote control system functions include: On/Off, Thermostat Mode, Timer Countdown, and Flame Adjustment (for fireplaces with variable flame).

### Kit Contents

#### RC300AU

- RC300AU Transmitter
- AAA Batteries (3)
- Wall Holder
- Drywall Anchor (2)
- Screws (2)

## Introduction

The RC300AU multifunctional remote control is designed to control pilot light, flame height, Fan speed, and up to two 220/240 VAC auxiliary functions on your gas fireplace. The RC300AU is equipped with thermostat functions which can automatically control the temperature in the room in which it is installed. The control is only for use with the Hearth & Home Technologies IntelliFire™ Plus system (IPI). The AUX300CE module is rated for 220/240 VAC, 50-60 Hz, and is required for operation of this remote control device.

### Installation Precautions

The installation of this remote control must be performed by a qualified service technician. This remote control is tested and safe when installed in accordance with this installation manual. Do not install any components that may be damaged.

Do not modify, disassemble, or substitute any of the components included with this kit. Installation of this unit must be done by a qualified service technician.

Placement of this remote control may affect performance. An assessment of the space should be done prior to installation for optimum performance.

### Determine Location

Determine the location for the remote control. The selected location should be in the same space as the gas fireplace. Never place this unit in a separate room. The remote control must be placed within 30 feet (9.14 m) of the fireplace but should not be exposed to extreme heat.

The RC300AU is approved for interior installation and should not be used in exterior applications.

- Keep remote control out of reach of children.

## FCC Requirements

**WARNING! Risk of Fire!** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules and EN298 for multi-functional control. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, could cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Contact the dealer or an experienced radio TV technician for help.

## Changing Temperature Scale

To change the temperature display between Celsius and Fahrenheit, remove the battery cover from the back of the remote control and slide the switch to your desired temperature scale (see Figure 46). The screen will automatically change the indicators on the room temperature and set temperature portion.




Figure 46. Temperature Scale

## Installation of Remote Control Housing

**CAUTION! Risk of Fire! DO NOT** install damaged or modified components. Warranty will be voided if damaged or modified components are installed.

1. Remove remote control components from packaging.
2. Remove battery cover from the back of the remote by sliding it down and install 3 AAA batteries.

To prevent unintended operation when not using your fireplace for an extended period of time (summer months, vacation, trips, etc):

- Remove batteries from remote control.
  - Unplug switching adapter and remove back-up batteries.
3. Secure the remote control housing on a flat wall surface using the two screws and wall anchors provided. See Figure 47.




Figure 47. Mounting Remote Control Housing

4. Place remote control inside housing. See Figure 48.




Figure 48. Remote in Housing

5. Close the housing door. See Figure 49.



**Figure 49. Mounting Remote Control Housing  
AUX300CE Module Installation**


- Insert the 4 hole harness from the AUX300CE module into the 4 pin plug on the control module. See Figure 50.



**Figure 50. AUX 300 module installation**

### Fan Installation

- Insert the 3 prong plug from the fan into the receptacle located in the AUX300CE module. See Figure 51.
- Insert 3 prong plug from AUX300CE module into REM/AUX receptacle of fireplace junction cord.



**Figure 51. Plug Fan into AUX300CE Module**


### Programming the RC300AU to the Control Module

**CAUTION! Risk of burns! DO NOT** program the remote control to the control module when fireplace is hot.

- Verify the ON/OFF/REMOTE switch is in the REMOTE position. Green LED light will blink three times and the control module will beep once 5 seconds later when ready. See Figure 52.
- Using a small item (such as a paper clip) press and release the LEARN button located near the ON/OFF/REMOTE switch. See Figure 52.
- Control module will beep once and LED will blink green for 10 seconds.
- While the LED is blinking, press the POWER button on the remote control. A double beep will come out of the control module to indicate that it has been programmed successfully.


**NOTICE:** Up to three remote controls can be programmed into the control module. Simply press a button on the other remote controls during the 10 second programming process to add another remote into the system. It is recommended to program only one RC300AU remote control.

To clear memory in the control module, use a small item (such as a paper clip) to press and release the LEARN button. Control module will beep once and LED will blink green for 10 seconds **DO NOT** press any buttons on the remote during the ten seconds that the green LED blinks. The memory will be cleared. Note that the RC300AU will not be programmed if it's in STANDBY mode. Press the ON/OFF button twice to switch to IDLE mode.



**Figure 52. Programming RC300AU**

## Display Screen




## Function Buttons

- POWER** Use POWER button to turn the unit on and off.
- Menu** Use MENU button to display the menu functions. Only functions that can be activated will be displayed. *For example: Flame Height will not be displayed when the remote status is OFF.*
- Select** Use the SELECT button to select the current feature.
- UP** Use the UP and DOWN arrows to toggle through the menu functions and value selections in the submenus.
- DOWN**


## Idle When Remote is in ON Mode

The remote control will go into an idle mode if no buttons are pressed within 5 seconds. Press any button to resume full functionality. In idle mode only active functions will show on the screen.



## Standby mode

The remote control will go into a standby mode if no buttons are pressed within 5 minutes. Press the POWER button to reactivate the remote control to ON mode. Active functions will be displayed



## About ON Mode

- All functions can be accessed when the remote control is in the ON mode.
- Only active functions will be displayed when the remote control is in the ON mode. For example: if the fan is the only function that's active, the fan icon and flame will be the only icon shown in the display.

## About OFF Mode

Only the following functions can be accessed in the OFF mode:

- AUX1
- AUX2

Only active functions will be displayed when the remote control is in the OFF mode.

## Turning ON the Fireplace

- Press the **POWER** button to turn the fireplace ON. The fireplace will first ignite the pilot. Once the pilot flame is established the main burner will be lit.

**NOTICE:** Whenever the fireplace is cycled from OFF to ON, the main burner will light on high for 10 seconds before returning to the previous user setting.

## Adjusting Flame Height

- Press the **MENU** button to activate the menu.
- Using the **UP** and **DOWN** arrows highlight the **FLAME** icon and press **SELECT**.
- Use the **UP** and **DOWN** arrows to adjust the **FLAME HEIGHT**, then press **SELECT**. The **FLAME HEIGHT** can be adjusted to 5 different settings.

**NOTICE:** FLAME HEIGHT will not be adjustable for first ten seconds when fireplace is turned on.

**NOTICE:** The system will remember the previous FLAME HEIGHT setting and will automatically adjust after 10 seconds.

## Adjusting Fan Speed

- Press the **MENU** button to activate the menu.
- Using the **UP** and **DOWN** arrows highlight the **FAN** icon and press **SELECT**.
- Use the **UP** and **DOWN** arrows to adjust the **FAN SPEED**, then press **SELECT**. The **FAN SPEED** can be adjusted to 3 different settings: HIGH, MEDIUM, LOW.

**NOTICE:** The fan has a timer built into the control module. After the fireplace is turned ON the timer will wait for 3 minutes before turning on the fan. In addition, the fan will remain on for 12 minutes after the fireplace has been turned OFF.

**NOTICE:** Whenever the fan is turned ON, the FAN will start up on the high setting for 10 seconds before adjusting to the previous user setting.

## AUX1 Function (Unit dependent Function)

- Press the **MENU** button to activate the menu.
- Using the **UP** and **DOWN** arrows highlight the **AUX1** icon and press **SELECT**.
- Use the **UP** and **DOWN** arrows to adjust the **AUX1** output, then press **SELECT**. The **AUX1** function can be adjusted to 4 different settings: HI, MED, LOW and OFF.

## AUX2 Function (Unit dependent Function)

- Press the **MENU** button to activate the menu.
- Using the **UP** and **DOWN** arrows highlight the **AUX2** icon and press **SELECT**.
- Use the **UP** and **DOWN** arrows to turn the **AUX2 ON** or **OFF**, then press **SELECT**. The **AUX2** function can be either be turned **ON** or **OFF**.

**NOTICE:** When the fireplace is turned OFF both AUX1 and AUX2 will be turned off. The AUX1 and AUX2 functions can be activated from the remote's OFF mode, when the flame is off. When the fireplace is turned back ON, the AUX1 and AUX2 settings will be restored to the previous setting.

## Adjusting Thermostat

- Press the **MENU** button to activate the menu.
- Using the **UP** and **DOWN** arrows highlight the **THERMO** icon and press **SELECT**.
- Use the **UP** and **DOWN** arrows to turn the **THERMO ON** or **OFF**, then press **SELECT** (the **SET TEMP** will start blinking). Using the **UP** and **DOWN** arrows select the desired temperature and press **SELECT**.

**NOTICE:** If the **THERMO** function is on, the **SET TEMP** can be adjusted at any time by pressing the **UP** and **DOWN** arrows.

**NOTICE:** As the **ROOM TEMP (RT)** approaches **SET TEMP (ST)**, the remote system will automatically adjust the flame height. If the **RT** rises above **ST**, the fireplace will shut down the main burner. After this, the fireplace will turn back on after the **RT** drops below the **ST**.

**NOTICE:** The system will remember the previous **TEMPERATURE** setting when **THERMOSTAT** mode is cycled **ON** or **OFF**.

**NOTICE:** If your installation includes an optional wired **ON/OFF** wall switch, it should be in the **OFF** position when using the **RC300AU** in thermostat mode.

## Adjusting Timer

- Press the **MENU** button to activate the menu.
- Using the **UP** and **DOWN** arrows highlight the **TIMER** icon and press **SELECT**.
- Use the **UP** and **DOWN** arrows to turn the **TIMER ON** or **OFF**, then press **SELECT**. Using the **UP** and **DOWN** arrows select the desired set time and press **SELECT**. Timer operates in increments of 15, 30, 45, 60, 90, 120 and 180 minutes.

## Setting the Child Lock

- Press and hold the **MENU** and **UP** arrow buttons simultaneously for 4 seconds to enable or disable the child lock feature.

**NOTICE:** No functions will be usable until child lock feature is disabled.

## Power Outage

- If fireplace battery backup system IS installed at time of power outage, fireplace operation will not be interrupted.
- If fireplace battery backup system IS NOT installed at time of power outage, fireplace will shut off. To resume fireplace operation, install battery backup.

**NOTICE:** Battery polarity must be correct or module damage will occur.

## Manual Fireplace Shutoff

In the unlikely event that the remote wall switch malfunctions and will not turn off the fireplace, call your dealer for service assistance. In the meantime, you may choose one of the following actions to turn off the fireplace:

**CAUTION! Risk of burns! Fireplace surfaces are hot when operating and during cool down. Use care and wear gloves when opening the front and accessing components inside the fireplace.**

Check remote screen for battery level indicator, replace the batteries if low battery is indicated. See Figure 49.

### Turn off the control module:

- Open or remove the decorative front to access the control module.
- Move switch to **OFF**. See Figure 45.

### Disconnect power to the control module:

- Open or remove the decorative front to access power cord to the junction cord and/or back-up batteries.
- Unplug the control module and/or remove back-up batteries.

### Shut off gas to the appliance:

- Open or remove the decorative front and locate the gas shut-off valve to the left of the gas control.
- Rotate the shut off valve 90 degrees to turn off gas supply.

### Turn off power to the fireplace (if back-up batteries are not installed):

- Locate house circuit breaker for fireplace.
- Turn off the circuit breaker.



### 3.0 SERVICING AND MAINTENANCE

1. **HEATER SERVICING:** Frequency of heater servicing will depend upon use and type of installation.
2. **IMPORTANT:** TURN OFF GAS BEFORE SERVICING APPLIANCE. IT IS RECOMMENDED THAT A COMPETENT SERVICE TECHNICIAN PERFORM SERVICE CHECK-UPS AT THE BEGINNING OF EACH HEATING SEASON.
3. The appliance and flue system should be inspected before initial use and at least annually by a qualified field service person.
4. Inspect the external flue cap on a regular basis to make sure that no debris is interfering with the air flow.
5. Keep the control compartment, logs, and burner area surrounding the logs clean by vacuuming or brushing at least twice a year.

**CAUTION:** THE LOGS GET VERY HOT - HANDLE ONLY WHEN COOL.



**WARNING: DO NOT USE ABRASIVE CLEANERS ON THE GLASS DOOR ASSEMBLY. DO NOT ATTEMPT TO CLEAN THE GLASS DOOR WHEN IT IS HOT.**

6. The glass door should be cleaned using a household glass cleaner. **DO NOT** handle or attempt to clean the glass when it is **HOT**.
7. Visually inspect the flexible power supply cord; if damaged, contact the service agent for a special replacement cord assembly.

8. In order to properly clean the burner and pilot assembly, turn off the gas to the unit and remove the logs exposing the burner and pilot assembly. Clean all foreign materials from top of burner. Check to make sure that the burner orifice is clean.
9. Visually inspect the pilot periodically. Brush or blow away any dust or linen accumulations. If the pilot orifice is plugged, disassembly may be required to remove any foreign materials from the orifice or tubing. When the appliance is put back in service, check burner flame patterns. Flames should be steady, not floating.

To obtain proper operation, it is imperative that the pilot and main burner flame characteristics are steady, not lifting or floating. Typically, the top 3/8 inch of the thermocouple should be engulfed in the pilot flame (See Figure 54).



Figure 54

### 3.1. REMOVAL OF DOORS FOR SERVICING


**NOTICE:** To access the gas controls, the entire front trim door must be removed.

#### A. Trim door and Glass Door

- Lift the front trim door up and out away from the appliance side surrounds. Replace the door when servicing is complete.
- Note carefully how the glass assembly is held in place. Release the four spring latches at the bottom and top of the glass door. Carefully lift the glass up and out away from the appliance. See Figure 55.

#### B. Optional Vanity Panel


- To access the valve, it may be necessary to remove the vanity panel. See Section 14E for Installation / Removal of Vanity Panel.



### 3.2. REMOVAL OF COMPONENTS FOR SERVICE

#### A. Burner

- Remove the logs and grate.
- Remove the cover plates at the ends of the burner.
- Remove the four retaining screws in the burner corners. Remove two pilot bracket retaining screws (see Figure 56.) Slide the burner away from the burner orifice.



**CAUTION:** ALL SCREWS WHICH WERE REMOVED MUST BE REPLACED.

#### B. Pilot Assembly/Ignition System

- Remove the log set, log grate, base pan and burner.
- Disconnect the gas supply tube from the underside of the gas valve.
- Disconnect the ignition cable and thermocouple retaining nut.
- Unscrew the pilot assembly bracket and remove.

### 3.3 PARTS REPLACEMENT

#### A. Fan/Switches

- Unplug the fan wires from the junction cord wires by pulling the male and female connectors apart and slide the fan out the front of the controls compartment.
- Disconnect the wires from the fan speed control switch, pull off the knob and remove the nut holding the speed control to the bracket.
- Disconnect the wires from the fan temperature sensor switch and remove the nut holding the switch bracket onto the side of the firebox.

### 3.4 ADJUSTMENTS AND REPLACEMENT PARTS

Adjustments and replacement parts for this appliance should only be done by a qualified service person. A wiring diagram for the appliance is shown in **SECTION 2.0 OPERATING INSTRUCTIONS**. A replacement part table is shown in **SECTION 4.0** of this manual.

### 3.5. MAINTENANCE TASKS



Inspect	Maintenance Tasks
Doors	1. Inspect for scratches, dents or other damage and repair as necessary.
	2. Verify no obstructions to airflow.
	3. Verify maintenance of proper clearance to combustible household objects.
Gasket Seal, Glass Assembly and Glass	1. Inspect gasket seal and its condition.
	2. Inspect glass panels for scratches and nicks that can lead to breakage when exposed to heat.
	3. Confirm there is no damage to glass or glass frame. Replace as necessary.
	4. Verify that latches engage properly, clip studs are not stripped, and glass attachment components are intact and operating properly. Replace as necessary.
	5. Clean glass. Replace glass assembly if severely coated with silicate deposits that cannot be removed.
Valve Compartment and Firebox Top	1. Vacuum and wipe out dust, cobwebs, debris or pet hair. Use caution when cleaning these areas. Screw tips that have penetrated the sheet metal are sharp and should be avoided.
	2. Remove any foreign objects.
	3. Verify unobstructed air circulation.
Logs	1. Inspect for broken, damaged, or missing logs. Replace as necessary.
	2. Verify correct log placement and no flame impingement causing sooting. Correct as necessary.
Firebox	1. Inspect for paint condition, warpage, corrosion or perforation. Sand and repaint as necessary.
	2. Replace appliance if firebox has been perforated.
Burner Ignition and Operation	1. Verify burner is properly secured and aligned with pilot or igniter.
	2. Clean off burner top, inspect for plugged ports, corrosion or deterioration. Replace burner if necessary.
	3. Replace ember materials with new dime-size and shape pieces. Do not block ports or obstruct lighting paths.
	4. Check for smooth lighting and ignition carryover to all ports. Verify there is no ignition delay.
	5. Inspect for lifting or other flame problems.
	6. Inspect orifice for soot, dirt or corrosion.
	7. Verify manifold and inlet pressures. Adjust regulator as required.
	8. Inspect pilot flame strength. Clean or replace orifice as necessary.
	9. Inspect thermocouple/thermopile or IPI sensor rod for soot, corrosion and deterioration. Polish with fine steel wool or replace as required.
Flueing	1. Inspect venting for blockage or obstruction such as bird nests, leaves, etc.
	2. Confirm that termination cap remains clear and unobstructed by plants, etc.
	3. Verify that termination cap clearance to subsequent construction (building additions, decks, fences or sheds) has been maintained.
	4. Inspect for corrosion or separation.
	5. Verify weather stripping, sealing and flashing remains intact.
Remote controls	1. Verify operation of remote.
	2. Replace batteries in remote transmitters and battery-powered receivers.

### 3.6 TROUBLESHOOTING

#### IntelliFire™ Plus Ignition System

Symptom	Possible Cause	Corrective Action
1. Pilot won't light. The ignitor/module makes noise, but no spark.	A. Incorrect wiring.	Verify "S" wire (white) for sensor and "I" wire (orange) for ignitor are connected to correct terminals on module and pilot assembly.
	B. Loose connections or electrical shorts in the wiring.	Verify no loose connections or electrical shorts in wiring from module to pilot assembly. Verify connections underneath pilot assembly are tight; also verify igniter and flame sense wires are not grounding out to metal chassis, pilot burner, pilot enclosure, mesh screen if present, or any other metal object.
	C. Ignitor gap is too large.	Verify gap of igniter to right side of pilot hood. The gap should be approximately .17 in. or 1/8 in. (3 mm).
2. Pilot won't light, there is no noise or spark.	A. No power, transformer installed incorrectly, or depleted batteries.	Verify that transformer is installed and plugged into module. Check voltage of transformer at connection to module. Acceptable readings of a good transformer are between 6.4 and 6.6 volts DC. Battery power supply voltage must be at least 4 volts. If below 4 volts, replace batteries.
	B. A shorted or loose connection in wiring configuration or wiring harness.	Remove and reinstall the wiring harness that plugs into module. Verify there is a tight fit. Verify pilot assembly wiring to module. Remove and verify continuity of each wire in wiring harness. Replace any damaged components.
	C. Improper wall switch wiring.	Verify that 240/VAC power is "ON" to junction cord.
	D. Module not grounded.	Verify black ground wire from module wire harness is grounded to metal chassis of appliance.
3. Pilot sparks, but Pilot will not light.	A. Gas supply.	Verify that incoming gas line ball valve is "open". Verify that inlet pressure reading is within acceptable limits.
	B. Ignitor gap is too large.	Verify gap of igniter to right side of pilot hood. The gap should be approximately .17 in. or 1/8 in. (3 mm).
	C. Module is not grounded.	Verify module is securely grounded to metal chassis of appliance.
	D. Pilot valve solenoid	Verify that 1.5 to 1.8 VDC is supplied to pilot solenoid from module. If below 1.5 volts, replace module. If 1.5 volts or greater, replace valve.
4. Pilot lights but continues to spark, and main burner will not ignite. (If the pilot continues to spark after the pilot flame has been lit, flame rectification has not occurred.)	A. A shorted or loose connection in flame sensing rod.	Verify all connections to wiring diagram in manual. Verify connections underneath pilot assembly are tight. Verify flame sense or igniter wires are not grounding out to metal chassis, pilot burner, pilot enclosure or screen if present, or any other metal object.
	B. Poor flame rectification or contaminated flame sensing rod.	With fixed glass assembly in place, verify that flame is engulfing flame sensing rod on left side of pilot hood. Flame sensing rod should glow shortly after ignition. With a multi-meter, verify that current in series between module and sense lead is at least 0.14 microamps. Verify correct pilot orifice is installed and gas inlet is set to pressure specifications. Polish flame sensing rod with fine steel wool to remove any contaminants that may have accumulated on flame sensing rod.
	C. Module is not grounded.	Verify module is securely grounded to metal chassis of appliance. Verify that wire harness is firmly connected to the module.
	D. Damaged pilot assembly or contaminated flame sensing rod.	Verify that ceramic insulator around the flame sensing rod is not cracked, damaged, or loose. Verify connection from flame sensing rod to white sensor wire. Polish flame sensing rod with fine steel wool to remove any contaminants that may have accumulated on flame sensing rod. Verify continuity with a multi-meter with ohms set at lowest range. Replace pilot if any damage is detected.

### Log Set Assembly



**IMPORTANT: THIS IS DATED INFORMATION.** Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
	Log Set Assembly		LOGS-ST-CE
1	Log #1	<b>Pre 5/15/16, Must order complete assembly</b>	SRV2068-700
2	Log #2		SRV2068-701
3	Log #3		SRV2068-702
4	Log #4		SRV2068-703
5	Log #5		SRV2068-703
6	Log #6		SRV582-705
7	Insulation Board		2005-272
8	Grate		2068-020
9	Side Refractory	Qty 2 req	SRV2005-730
10	Glass Door Assembly	Qty 2 req	GLA-6TRXI
11	Door Assembly	Qty 2 req	2082-070
12	Burner Assembly N		SRV2082-014
	Burner Assembly Propane		SRV2082-015
13	Vanity Panel		SRV2078-182-BK
	Lower Door		2082-042
	Dress Guard		2068-040


Additional service part numbers appear on following page.

8/19

No one builds a better fire

Beginning Manufacturing Date: Mar 2011  
Ending Manufacturing Date: Active

### #14 Valve Assembly



**IMPORTANT: THIS IS DATED INFORMATION.** Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
14.1	Pilot Bracket		2082-118
14.2	Pilot Assembly N, 24"		2166-370
	Pilot Assembly Propane, 24"		2166-371
<b>Pre SN #0022998833 Must order both pilot assembly and pilot bracket</b>			
14.3	Burner Support	Pre 0022998833	2082-112
		Post 0022998833	2082-212
14.4	Flexible Gas Connector		530-302A
14.5	3-Hole Grommet		SRV2118-420
14.6	Orifice N (#30C)		582-830
	Orifice Propane (#49C)		SRV582-849
14.7	Burner Leg	Pre 0022998833	2082-113
		Post 0022998833	2082-213
14.8	Wire Harness		2166-304
14.9	Jumper Wire		SRV2187-198
14.10	Battery Pack**		SRV2166-323
14.11	Jumper to Fan		2166-375
14.12	Transformer		SRV2326-131
14.13	Aux 300 CE, Pre Sn # 0023019789 must also order Jumper Wire (2222-375)		2166-340
14.14	Module, Gray		2166-306
14.15	Male Connector	Pkg of 5	303-315/5
14.16	Valve N		2166-302
	Valve Propane		2166-303
14.17	Gas Shutoff Assembly		2098-034
14.18	Valve Bracket		2118-104A

\*\*Fuse for battery pack can be sourced locally, not a warranty item.

Additional service part numbers appear on following page.



## Limited Lifetime Warranty

# AUSTRALIAN WARRANTY INFORMATION

Hearth & Home Technologies (HHT)  
 7571 215th Street West, Lakeville, MN 55044  
 0011-1-651-345-1777  
 www.hearthnhome.com

HHT extends the following manufacturer's warranty for HHT gas, wood, pellet, coal and electric hearth appliances that are purchased from an HHT authorized dealer.

HHT warrants to the original owner of the HHT appliance at the site of installation, and to any transferee taking ownership of the appliance at the site of installation within two years following the date of original purchase, that the HHT appliance will be free from defects in materials and workmanship at the time of manufacture.

After installation, if covered components manufactured by HHT are found to be defective in materials or workmanship during the applicable warranty period, HHT will, at its option, repair or replace the covered components. HHT, at its own discretion, may fully discharge all of its obligations under this manufacturer's warranty by replacing the product itself or refunding the verified purchase price of the product itself. The maximum amount recoverable under this warranty is limited to the purchase price of the product. This warranty is subject to conditions, exclusions and limitations as described below.

Warranty coverage begins on the date of original purchase. In the case of new home construction, coverage under this manufacturer's warranty begins on the date of first occupancy of the dwelling or six months after the sale of the product by an independent, authorized HHT dealer/ distributor, whichever occurs earlier. The warranty period for this manufacturer's warranty shall commence no later than 24 months following the date of product shipment from HHT, regardless of the installation or occupancy date. The manufacturer's warranty period for parts and labour for covered components is produced in the following table.

The term "Limited Lifetime" in the table below is defined as: 20 years from the beginning date of warranty coverage for gas appliances, and 10 years from the beginning date of warranty coverage for wood, pellet and coal appliances. These time periods reflect the minimum expected useful lives of the designated components under normal operating conditions.

Warranty Period		HHT Manufactured Appliances and Venting							Components Covered
Parts	Labor	Gas	Wood	Pellet	EPA Wood	Coal	Electric	Venting	
1 Year		X	X	X	X	X	X	X	All Parts and Material Except as covered by Conditions, Exclusion, and Limitations listed
2 years				X	X	X			Igniters, Electronic Components, and Glass
		X	X	X	X	X			Factory-installed fans
			X						Molded refractory panels
3 years				X					Firepots and burnpots



Warranty Period		HHT Manufactured Appliances and Venting							Components Covered
Parts	Labor	Gas	Wood	Pellet	EPA Wood	Coal	Electric	Venting	
5 years	1 years			X	X				Castings & baffles
7 years	3 years		X	X	X				Manifold tubs HHT chimney and termination
10 years	1 year	X							Burners, logs and refractory
Limited Lifetime	3 year	X	X	X	X	X			Firebox and heat exchanger
90 Days		X	X	X	X	X	X	X	All Replacement Parts beyond warranty period

### **OTHER RIGHTS**

The HHT manufacturer's warranty is in addition to other rights and remedies that you may have under Australian law.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### **WARRANTY CONDITIONS AND EXCLUSIONS:**

- The HHT manufacturer's warranty only covers HHT appliances that are purchased through an HHT authorized dealer or distributor. A list of HHT authorized dealers is available on the HHT branded websites.
- This warranty is only valid while the HHT appliance remains at the site of original installation.

### **WARRANTY EXCLUSIONS:**

This HHT manufacturer's warranty does not cover the following:

- Changes in surface finishes as a result of normal use. As a heating appliance, some changes in color of interior and exterior surface finishes may occur. This is not a flaw and is not covered under warranty.
- Damage to printed, plated, or enamelled surfaces caused by fingerprints, accidents, misuse, scratches, melted items, or other external sources and residues left on the plated surfaces from the use of abrasive cleaners or polishes.
- Repair or replacement of parts that are subject to normal wear and tear during the warranty period. These parts include: paint, wood, pellet and coal gaskets, firebricks, grates, flame guides, light bulbs, batteries and the discoloration of glass.
- Expansion, contraction, or movement of certain parts causing noise. These conditions are normal and complaints related to this noise are not covered by this warranty.
- Damages resulting from: (1) failure to install, operate, or maintain the appliance in accordance with the installation instructions, operating instructions, and listing agent identification label furnished with the appliance; (2) failure to install the appliance in accordance with local building codes; (3) shipping or improper handling; (4) improper operation, abuse, misuse, continued operation with damaged, corroded or failed components, accident, or improperly/incorrectly performed repairs; (5) environmental conditions, inadequate ventilation, negative pressure, or drafting caused by tightly sealed constructions, insufficient make-up air supply, or handling devices such as exhaust fans or forced air furnaces or other such causes; (6) use of fuels other than those specified in the operating instructions; (7) installation or use of components not supplied with the appliance or any other components not expressly authorized and approved by HHT (8) modification of the appliance not expressly authorized and approved by HHT in writing; and/or (9) interruptions or fluctuations of electrical power supply to the appliance.

- Non HHT venting components, hearth components or other accessories used in conjunction with the appliance.
- Any part of a pre-existing fireplace system in which an insert or a decorative gas appliance is installed.
- Removal, installation, reinstallation, set up or any other costs associated with a claim including travel and shipping charges for parts
- HHT's obligation under this warranty does not extend to the appliance's capability to heat the desired space. Information is provided to assist the consumer and the dealer in selecting the proper appliance for the application. Consideration must be given to appliance location and configuration, environmental conditions, insulation and air tightness of the structure.

**This warranty is void if:**

- The appliance has been over-fired or operated in atmospheres contaminated by chlorine, fluorine, or other damaging chemicals. Over-firing can be identified by, but not limited to, warped plates or tubes, rust colored cast iron, bubbling, cracking and discoloration of steel or enamel finishes.
- The appliance is subjected to prolonged periods of dampness or condensation.

There is any damage to the appliance or other components due to water or weather damage which is the result of, but not limited to, improper chimney or venting installation.

**HOW TO CLAIM**

- To make a claim against this warranty, contact your local distributor during regular business hours. See addresses below for a dealer nearest you. (Vic) Pty Ltd ACN 005 872 159 (Jetmaster).
- Additional service fees may apply if you are seeking warranty service from a dealer other than the dealer from whom you originally purchased the product.
- Check with Jetmaster in advance for any costs to you when arranging a warranty call. Travel and shipping charges for parts are not covered by this manufacturers' warranty.
- HHT and Jetmaster will assess your claim. HHT or Jetmaster may need to inspect the product as part of the assessment of your claim. If the product requires inspection, HHT or Jetmaster will discuss with you the best way for this to occur.
- To make a claim under this manufacturer's warranty, you must be able to prove when you purchased the product. The easiest way to do this is through your original proof of purchase, for example your invoice or receipt. However, if you do not have your original proof of purchase HHT or Jetmaster may accept other evidence of the date of purchase.

**Melbourne**

Jetmaster  
444 Swan Street  
Richmond 3121  
(03) 9429-5573

**Perth**

Fireplace Corner  
277 Lord Street  
East Perth 6000  
(08) 9228-2600

**Sydney**

Jetmaster  
55 Marickville Rd.  
Marickville 2204  
(02) 9505-8505

