

No one builds a better fire

# **TIARA I-C**

DIRECT VENT ROOM HEATER

# Models: **TIARAI-BK-C TIARAI-BR-C TIARAI-CES-C**



# **Owner's Manual**

Installation and Operation





Intertek



maintenance instructions included.

follow these instructions for safe installation and operation.

CAUTION DO NOT DISCARD THIS MANUAL

Important operating and . Read, understand and . Leave this manual with party responsible for use and operation.

WARNING: If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury, or death.

- · Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- What to do if you smell gas
  - Do not try to light any appliance. Do not touch any electrical switch. Do not use any phone in your building.
  - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.



Installation and service of this appliance should be performed by gualified personnel. Hearth & Home Technologies suggests NFI certified or factory-trained professionals, or technicians supervised by an NFI certified professional.



This appliance is only for use with the type(s) of gas indicated on the

Z240MH.

rating plate.

Read this manual before installing or operating this appliance. Please retain this owner's manual for future reference.

# Congratulations

Congratulations on selecting a Heat & Glo gas appliance an elegant and clean alternative to wood burning appliances. The Heat & Glo gas appliance you have selected is designed to provide the utmost in safety, reliability, and efficiency.

As the owner of a new appliance, you'll want to read and carefully follow all of the instructions contained in this *Owner's Manual*. Pay special attention to all Cautions and Warnings.

This Owner's Manual should be retained for future reference. We suggest that you keep it with your other important documents and product manuals.

Your new Heat & Glo gas appliance will give you years of durable use and trouble-free enjoyment. Welcome to the Heat & Glo family of gas appliance products!

# SAMPLE OF SERIAL NUMBER / SAFETY LABEL LOCATION: HANG TAG ATTACHED TO REAR OF APPLIANCE



#### Safety Alert Key:

- DANGER! Indicates a hazardous situation which, if not avoided will result in death or serious injury.
- WARNING! Indicates a hazardous situation which, if not avoided <u>could</u> result in death or serious injury.
- CAUTION! Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
- NOTICE: Indicates practices which may cause damage to the fireplace or to property.

# - TABLE OF CONTENTS -

#### Section 1: Listing and Code Approvals

A. B. C. D. E. F. G.	Appliance Certifications       4         Glass Specifications       4         BTU Specifications       4         High Altitude Installations       4         Non-Combustible Materials       4         Combustible Materials       4         Requirements for the       5
Section 2: A. B. C.	Getting Started Design & Installation Considerations
Section 3: A. B.	Appliance Location & Clearances Selecting Appliance Location7 Clearances to Combustibles7
Section 4: A.	<b>Termination Locations</b> Vent Termination Minimum Clearances8
Section 5: A. B. C. D. E. F. G.	Vent InformationVenting Components10Use of Elbows10Measuring Standards10How to Use the Vent Graph11Venting Guidelines11Horizontal Termination12Vertical Termination15
Section 6: A. B. C.	Gas Information Fuel Conversions23 Gas Pressures25 Gas Connection25
Section 7: A. B. C. D.	Electrical Information Recommendation for Wire

#### Section 8: Appliance Setup

	••	
Α.	Remove Shipping Materials	29
Β.	Accessories	29
C.	Top to Rear Conversion	29
D.	Baffle Installation/Adjustment	30
Ε.	Leg Leveling System	30
F.	Brick Installation	31
G.	Positioning the Logs	31
Η.	Mineral Wool	31
Ι.	Shutter Adjustment	31
J.	Glass Replacement	32
K.	Optional Blower Installation	32
L.	Intake Fuel Restrictor Adjustment	34
Μ.	Warming shelves Instructions	34
	-	

#### **Section 9: Operating Instructions**

Α.	Before Lighting Appliance	35
В.	Controls	35
C.	Lighting Appliance	36
D.	After Appliance is Lit	37
Ε.	Frequently Asked Questions	37

#### 

#### Section 11: Maintaining & Servicing Appliance

A. Maintenance Tasks ......40

#### Section 12: Reference Materials

Α.	Appliance	Dimension Diagram	42
----	-----------	-------------------	----

- B. Vent Components Diagram ......43
- D. Service Parts & Accessories......46
- E. Limited Lifetime Warranty......50F. Contact Information ......52

←

←



## A. Appliance Certification

MODEL:	Tiara I-C Gas Stove	
LABORATORY:	Intertek, Report No. 3198461	
TYPE:	Direct Vent Gas Heater	
STANDARD:	ANSI Z21.88b-2009CSA 2.33b-2009 · UL307bCAN/CBA 2.17-M91	

The product is listed to ANSI standards for "Vented Gas Appliance Heaters" and applicable sections of "Gas Burning Heating Appliances for Manufactured Homes and Recreational Vehicles" and "Gas Fired Appliances for use at High Altitudes".

Manufactured Home or Mobile Home installation may occur only after the home is site located and must conform with the Manufactured Home Construction and Safety Standard, Title 24 CFR, Part 3280, or, when such a standard is not applicable, the Standard for Manufactured Home Installations, ANSI/NCSBCS A225.1, or Standard for Gas Equipped Recreational Vehicles and Mobile Housing, CSA Z240.4.

When installed, the appliance must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70, or the Canadian Electrical Code, CSA C22.1.

## **B. Glass Specifications**

This appliance is equipped with 5mm ceramic glass behind the curved glass. Replace glass only with 5mm ceramic glass. Please contact your dealer for replacement glass.

**NOTE:** This installation must conform with local codes. In the absence of local codes you must comply with the **National Fuel Gas Code, ANSI Z223.1-latest edition** in the U.S.A. and the **CAN/CGA B149 Installation Codes** in Canada.



Do NOT use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the unit and to replace any part of the control system and any gas control which has been under water.

# C. BTU Specifications

<b>Model</b> (US or Canada)	Maximum Input BTU	Minimum Input BTU	Orifice Size (DMS)	*Steady State Efficiency %	**P.4 %
<u>TOP VENT:</u> (NG) (LP)	30,000 28,500	21,000 19,700	.106 .063	80.92 82.44	58.90 60.09
<u>REAR VENT:</u> (NG) (LP)	26,000 26,000	18,000 19,000	.098 .059	80.92 82.44	65.04 66.49

\* Thermal efficiency maximum pipe with blower on.

\*\* Canada minimum pipe.

## D. High Altitude Installations

Intertek listed gas appliances are tested and approved without requiring changes for elevations from 0 to 2000 feet (0 to 609m) in the U.S.A. and 0 to 4500 feet (0 to 1372m) in Canada.

When installing this appliance at an elevation above 2000 feet (609m), it may be necessary to decrease the input rating by changing the existing burner orifice to a smaller size. Input rate should be reduced by 4% for each 1000 feet (305m) above a 2000 foot (609m) elevation in the U.S.A. If the heating value of the gas has been reduced, these rules do not apply. To identify the proper orifice size, check with the local gas utility.

If installing this appliance at an elevation above 4500 feet (1372m) in Canada, check with local authorities.

# E. Non-Combustible Materials

Materials that are reported as passing **ASTM E 136**, **Standard Test Method for Behavior of Materials in a Vertical Tube Furnace at 750°C**, shall be considered non-combustible materials.

# F. Combustible Materials

Materials made of or surfaced with wood, compressed paper, plant fibers, plastics, or other materials that can ignite and burn, whether flame proofed or not, or whether plastered or unplastered shall be considered combustible materials. **NOTE:** The following requirements reference various Massachusetts and national codes not contained in this document.

#### G. Requirements for the Commonwealth of Massachusetts

For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:

#### Installation of Carbon Monoxide Detectors

At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gas fitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gas fitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors.

In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery backup may be installed on the next adjacent floor level.

In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.

#### **Approved Carbon Monoxide Detectors**

Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.

#### Signage

A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS."

#### Inspection

The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a) 1 through 4.

#### Exemptions

The following equipment is exempt from 248 CMR 5.08(2) (a) 1 through 4:

- The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and
- Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separated from the dwelling, building or structure used in whole or in part for residential purposes.

#### MANUFACTURER REQUIREMENTS

#### **Gas Equipment Venting System Provided**

When the manufacturer of Product Approved side wall horizontally vented gas fueled equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:

- Detailed instructions for the installation of the venting system design or the venting system components; and
- A complete parts list for the venting system design or venting system.

#### Gas Equipment Venting System NOT Provided

When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems", the following requirements shall be satisfied by the manufacturer:

- The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and
- The "special venting system" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.

A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/ or all venting design instructions shall remain with the appliance or equipment at the completion of the installation.

#### See Gas Connection section for additional Commonwealth of Massachusetts requirements.



## A. Design & Installation Considerations

Heat & Glo direct vent gas appliances are designed to operate with all combustion air drawn from outside of the building and all exhaust gases expelled to the outside. No additional air source is required.

# CAUTION

Check building codes prior to installation.

- Installation MUST comply with local, regional, state and national codes and regulations.
- Consult local building, fire officials or authorities having jurisdiction about restrictions, installation inspection, and permits.

When planning an installation, it is necessary to determine the following information before installing:

- Where the appliance is to be installed.
- The vent system configuration to be used.
- Gas supply piping.
- Electrical wiring.
- Whether optional accessories devices such as a blower, thermostat or remote control are desired.

Young children should be carefully supervised when they are in the same room as the appliance. Toddlers, young children and others may be susceptible to accidental contact burns. A physical barrier is recommended if there are at risk individuals in the house. To restrict access to an appliance, install an adjustable safety gate to keep toddlers, young children and other at risk individuals out of the room and away from hot surfaces.

# B. Tools and Supplies Needed

Before beginning the installation be sure that the following tools and building supplies are available. Note: Not all tools will apply to every installation.

Reciprocating saw	Variable Speed Drill/Driver
Pliers	Wrench Set
Hammer	Framing Square
Phillips Screwdriver	Framing Material
Flat Blade Screwdriver	Voltmeter
Plumb Line	Gloves
Level	Safety Glasses
Manometer	Tape Measure

Non-corrosive leak check solution or combustible gas detector

Caulking material (300°F minimum continuous exposure rating)

# C. Inspect Appliance & Components



- Carefully remove the appliance and components from the packaging.
- Remove cast front and glass door, and set aside on protective surface.
- Remove log set and component pack from firebox.
- Report to your dealer any parts damaged in shipment, particularly the condition of the glass.
- Read all of the instructions before starting the installation. Follow these instructions carefully during the installation to ensure maximum safety and benefit.



# WARNING

Hearth & Home Technologies disclaims any responsibility for, and the **warranty will be voided** by, the following actions:

- Installation and use of any damaged appliance or vent system component.
- Modification of the appliance or vent system.
- Installation other than as instructed by Hearth & Home Technologies.
- Improper positioning of the gas logs or the glass door.
- Installation and/or use of any component part not approved by Hearth & Home Technologies.

Any such action may cause a fire hazard.





#### NOTE:

• Illustrations reflect typical installations and are <u>FOR</u> <u>DESIGN PURPOSES ONLY.</u>

· Illustrations/diagrams are not drawn to scale.

• Actual installation may vary due to individual design preference.

# A. Selecting Appliance Location

When selecting a location for your appliance it is important to consider the required clearances to walls (see **Figure 3.1**).

NOTE: For actual appliance dimensions refer to Section 12.

# B. Clearances to Combustibles



# 

Fire Risk Provide adequate clearance:

- Around air openings
- To combustibles
- For service access
- Locate appliance away from traffic areas.



# 

Fire Risk.Locate and install appliance to all clearance specifications in manual.



It is permissible to place the appliance on carpet.

# CAUTION

Some carpet materials may be sensitive to radiant heat from the appliance causing discoloration or odor.

**NOTE:** Flooring beneath appliance may reach 90 degrees plus room ambient temperature. Check with flooring manufacturer for maximum temperature allowed on flooring surfaces.





## A. Vent Termination Minimum Clearances





Figure 4.3 specifies minimum vent heights for various pitched roofs.



P

= 8 ft.

1 cap

2 caps

3 caps

4 caps

Q<sub>MIN</sub> = # termination caps X 3

\*\* a vent shall not terminate diretly above a sidewalk or paved driveway which is located between two single family dwellings and serves both dwellings.

= 3 ft. ..... clearance to gas service regula-

tor vent outlet

12 inches (Canada) clearance to non-mechanical air

appliance

supply inlet to building or the

combustion air inlet to any other

\*\*\* only permitted if veranda, porch, deck or balcony is fully open on a minimum of 2 sides beneath the floor, or meets Note 2.

**NOTE 1:** On private property where termination is less than 7 feet above a sidewalk, driveway, deck, porch, veranda or balcony, used of a listed cap is suggested (See vents components pages).

**NOTE 2:** Termination in an alcove space (spaces only open on one side and wit an overhand) are permitted with the dimensions specified for vinyl or non-vinyl siding and soffits.

**NOTE 3:** Location of the vent termination must not interfere with access to the electrical service.

NOTE 4: Local codes or regulations may require different clearances.

**NOTE 5:** Termination caps may be hot. Consider their proximity to doors or other traffic areas.

**NOTE 6: 1)** There must be at least 3 feet minimum between termination caps. **2)** All mechanical air intakes within 10 feet of a termination cap must be a minimum of 3 feet below the termination cap. **3)** All gravity air intakes within 3 feet of a termination cap must be a minimum of 1 foot below the terminatin cap.

12 inches ..... vinyl sidewalls

 $\mathbf{Q}_{\text{MIN}}$ 

3 feet

6 feet

9 feet

12 feet

RMAX

2 x Q ACTUAL

1 x Q <sub>ACTUAL</sub>

2/3 x Q ACTUAL

1/2 x Q\_<sub>ACTUA</sub>

R<sub>MAX</sub> = (2 / # termination caps) x Q<sub>ACTUA</sub>

**WARNING: In the USA**: Vent system termination is **NOT** permitted in screened porches. You must follow side wall, overhang and ground clearances as slated in the instructions.

In Canada: Vent system terminatin is NOT permitted in screed porces Venty system termination is permitted in porch areas with two or more sides open. You must follow side wall, overhang and ground clearances as slated in the instructions.

Hearth & Home Technologies assumes no responsibility for the improper performance of the appliance when the venting system does not meet these requirements.

**CAUTION:** IF EXTERIOR WALLS ARE FINISHED WITH VINYL SIDING, IT IS SUGGESTED THAT A VINYL PROTECTOR KIT BE INSTALLED.

Figure 4.4

Т

J

= 9 inches (U.S.A.)



# A. Venting Components

In order to comply with applicable codes and product warranties, use only following venting components:

- Hearth & Home Technologies (HHT)
- Security Chimney's Secure Vent Chimney System
- Selkirk Metalbestos
- AmeriVent
- Simpson Dura-Vent (SDV)

#### DO NOT USE FIELD-FABRICATED VENTING

**COMPONENTS**. Refer to the venting manufacturer's instructions.

This product is approved to be vented either horizontally, through the side wall or vertically through the roof. You may vent through a Class A or masonry chimney if an approved adapter is used.

This appliance is a direct vent heater. All combustion air must come directly from the outside of the building. The vent pipe for this unit consists of an inner and an outer pipe. The inner pipe carries the appliance exhaust out of the system, and the outer pipe brings fresh combustion air into the appliance.

- A round support box/wall thimble or heat shield is required when the venting passes through a combustible wall.
- A support box or ceiling firestop is required when the venting passes through a ceiling.
- Roof flashing and a storm collar are required when venting passes through the roof.
- Follow instructions provided with the venting for installation of these items.



# 

Fire Risk. Explosion Risk.

Asphyxiation Risk.

Do NOT connect this gas appliance to a chimney flue serving a separate solid-fuel or gas burning appliance.

- Vent this appliance directly outside.
- Use separate vent system for this appliance.
- May impair safe operation of this appliance or other appliances connected to the flue.

# B. Use of Elbows

# CAUTION

ALL vent configuration specifications MUST be followed.

- This product is tested and listed to these specifications.
- Appliance performance will suffer if specifications are not followed.

Diagonal runs have both vertical and horizontal vent aspects when calculating the effects. Use the rise for the vertical aspect and the run for the horizontal aspect. **Figure 5.1.** 

Two  $45^{\circ}$  elbows may be used in place of one  $90^{\circ}$  elbow. On  $45^{\circ}$  runs, one foot of diagonal is equal to 8-1/2 in. (216mm) horizontal run and 8-1/2 in. (216mm) vertical run. A length of straight pipe is allowed between two elbows. **Figure 5.1**.



# C. Measuring Standards

Vertical and horizontal measurements were made using the following standards.

- Pipe measurements are from center line to center line.
- Horizontal terminations are measured to the outside of the mounting surface (flange of termination cap). See Figure 4.1 on page 8.
- Vertical terminations are measured to the top of the last pipe before termination cap.
- Horizontal pipe installed level with 1/4 in. (6mm) rise.

# D. How to Use the Vent Graph

- 1. Measure the distance from the top of appliance to the center of the 90° elbow. On the graph below, draw a horizontal line from that measurement on the vertical axis across until it intersects with the slanted line.
- 2. From the point of this intersection, draw a vertical line to the bottom of the graph.
- 3. The point at which this line meets the bottom line of the graph is the maximum length of the horizontal run.

**EXAMPLE 1:** If the vertical dimension from the center line of the flue vent to the center of the 90° elbow is 7 ft. (2 m), the horizontal run to the outer wall flange must not exceed 13 ft. 2 in. (5m).

**EXAMPLE 2:** If the vertical dimension from the center line of the flue vent is 21 ft. (6m), the horizontal run to the outer wall flange must not exceed 10 ft. (3m).

4. Each 90° elbow is equivalent to 3 ft. (914mm) of vent pipe and each 45° elbow is equivalent to 1 ft. (305mm) of vent pipe, and must be subtracted from vent pipe run. A single vertical to horizontal 90° elbow is already calculated into the allowable 15 ft. (5m) run. Each additional 90° elbow reduces the maximum horizontal distance by 3 ft. (914mm).

Example: The use of 3 elbows would reduce the allowable horizontal run to 9 ft. (3 - 1 = 2 elbows x 3 ft. = 6 ft.; 15 ft. max. - 6 ft. = 9 ft. max.)



# E. Venting Guidelines for Horizontal Runs

Standard Horizontal Run

Max Horizontal Run, Rear Vent	3 ft (914mm)	
Max Horizontal Run	15 ft (5m) when vertical rise is 10 ft (3m	
Max Horizontal Run with 45° Elbow	14 in. (356mm)	
Min Horizontal Run	11 in. (279mm)	
Max Wall Thickness	20 in. (508mm)	
Min Wall Thickness	4 in. (102mm)	
Exterior Vent Diameter	6-5/8 in. (168mm)	
Inner Vent Diameter	4 inches (101mm)	
Rear Vent with Vertical Rise	Min of 2 ft vertical (610mm) must be used prior to any hori- zontal run	
Horizontal Run requires a 1/4 in. (6mm) rise for every 1 ft toward the termination.		
Horizontal Run requires a non-combustible support every 3 ft (914mm), i.e., plumbing tape		

#### Horizontal Run with Snorkel Kit.

A rear vent configuration with 3 ft. (914mm) maximum horizontal run with no vertical pipe and with 1/4 in. (6mm) rise per foot.

- A snorkel kit must be used. Figure 5.3 below and Figure 5.4 on page 12.
- A derating orifice must be installed. The appropriate orifice is supplied with the rear vent kit.



NOTE: IF YOUR INSTALLATION FALLS WITHIN A SHADED AREA ON THE GRAPH, THE FLUE RESTRICTOR MUST BE USED.

INDIVIDUAL INSTALLATIONS MAY VARY. Percentage closed based on full range of the flue restrictor travel.

#### WARNING! Fire Risk!

- · Never allow the vent to run downward.
- This could cause high temperatures and may present the possibility of a house or structure fire.

# F. Horizontal Termination



#### Step 1.

Determine the desired location of the appliance. Check to ensure that wall studs or roof rafters are not in the way when the venting system is attached. If this is the case, you may want to adjust the location of the appliance.

# 



Fire Risk.

Exhaust Fume Risk.

Impaired Performance of Appliance.



- Ensure vent components are locked together correctly.
- Pipe may separate if not properly joined.

## Step 2.

Direct vent pipe is designed with a locking connection. To connect the venting system to the appliance flue outlet, a twist-lock adapter is built into the appliance at the factory. Wall thickness may vary. Remember to include wall thickness in minimum clearances when figuring venting lengths for your installation needs.

**Note:** Female ends of direct vent pipe/elbows are designed to slide straight onto the male ends of adjacent pipes by orienting the pipe indentations so they match and slide into the entry slots on the male ends, see Figure 5.5. Push the pipe sections completely together, then twist-lock one section clockwise approximately one-quarter turn, until the two sections are fully locked. The female locking lugs may not be visible from the outside. They may be located by examining the inside of the female ends.





- Do NOT allow vent to sag below connection point to appliance.
- · Maintain specified slope (if required).

Improper support may allow vent to sag or separate.

#### Step 3.

For installations using a round support box/wall thimble (check pipe manufacturer's instructions), mark the wall for a 10 in. x 10 in. (254mm x 254mm) square hole. The center of the square hole should line up with the center line of the horizontal pipe, as shown in **Figure 5.6**. Cut and frame the hole in the exterior wall where the vent will be terminated. If the wall being penetrated is constructed of non-combustible material, i.e. masonry block or concrete, a 7 in. (178mm) diameter hole is acceptable.



#### NOTE:

- (1) Installation requires a minimum of 6 in. (152mm) horizontal run of vent with a 1/4 in. (6mm) rise run towards the termination. Each 1 ft. (305mm) of horizontal venting must include a 1/4 in. (6mm) rise. Never allow the vent to run downward. This could cause high temperatures and may present the possibility of a house or structure fire.
- (2) The location of the horizontal vent termination on an exterior wall must meet all local and national building codes, and must not be easily blocked or obstructed, see **Figure 4.4 on page 9.**
- (3) For installations requiring a vertical rise on the exterior of the building, a snorkel kit is available with a 14 in. (356mm) and a 36 in. (914mm) tall snorkel termination cap. Follow the same installation procedures as used for standard horizontal terminations. If the snorkel termination must be installed below grade (i.e. basement application), proper drainage must be provided to prevent water from entering the snorkel termination. Do not backfill around snorkel termination.
- (4) Vertical clearances through a wall require 2 in. (51mm) off the top of the venting pipe and 1 in. (25mm) off the sides and bottom.

#### Step 4.

Position the horizontal termination cap in the center of the 10 in. x 10 in. (254mm x 254mm) square hole and run a bead of non-hardening mastic around its outside edges, so as to make a seal between it and the wall, attach termination cap to the exterior wall with the four wood screws provided. The arrow on the vent cap should be pointing up (**Figure 5.7**).



#### NOTES:

- The four wood screws provided should be replaced with appropriate fasteners for stucco, brick, concrete, or other types of sidings.
- (2) A termination cap with a built-in vinyl siding standoff is highly recommended on a building with vinyl siding. The pilot hole will be 2 in. (51mm) closer to the bottom of the square than the top. Using a framing square, draw a 14 in. x 14 in. (356mm x 356mm) square around the pilot hole in the siding. Figure 5.7.



(**NOTE:** Some termination caps may cause the vent pipe to be off center on flashing). Ensure that proper clearances to combustible materials are maintained. If you are not using an approved termination cap with a built-in standoff on a building with vinyl siding, a vinyl siding standoff should be installed between the termination cap and the exterior wall (**Figure 5.99**). Follow manufacturer's instructions for attaching the vinyl siding standoff prevents excessive heat from possibly melting the vinyl siding material. Remove siding from the area where the standoff will be located.

# WARNING! The vent terminal cap shall not be recessed into a wall or siding.



#### Step 5.

Place the wall thimble cover over the pipe assembly and slide the appliance and vent assembly towards the wall, carefully inserting the vent pipe into the vent termination cap assembly. It is important that the vent pipe extend into the vent termination cap a sufficient distance so as to result in a minimum pipe overlap of 1-1/4 in. (32mm). Secure the connection between the vent pipe and the vent termination cap by attaching the two sheet metal strips extending from the vent termination cap assembly into the outer wall of the vent pipe. Use the two sheet metal screws provided to connect the strips to the pipe section (**Figure 5.10**).



**Note:** The attachment from the vent pipe to the vent cap must be sealed with silicone. Venting terminals shall not be recessed into a wall or siding.



# A WARNING

Do NOT connect a pipe section to a termination cap without using the telescoping flue section found on the termination cap.

# 

Burn Risk.

Local codes may require installation of a cap shield to prevent anything or anyone from touching the hot cap.

# G. Vertical Termination

## 1. Direct Vent Pipe



#### Step 1.

Check the installation instructions for required 1 in. (25mm) clearances (air space) to combustibles when passing through ceilings, walls, roofs, enclosures, attic rafters, or other nearby combustible surfaces. **Figure 5.17 on page 17.** Check the instructions below for maximum vertical rise of the venting system, and any maximum horizontal offset limitations. All offsets must fall within the set parameters of the vent graph **Figure 5.2 on page 11**.

**NOTE:** Maximum vertical rise allowable is 40 ft. (12m) **Figure 5.11**).

**NOTE**: Maximum number of 45° elbows permitted for a vertical installation is eight, provided their installation does not decrease maximum allowable horizontal run (as specified by vent graph, on **page 11**).



# 

Fire Risk.

Explosion Risk.

Maintain vent clearance to combustibles as speci-

fied.
Do not pack air space with insulation or other materials.

Failure to keep insulation or other materials away from vent pipe may cause fire.



#### Step 2.

Set the gas appliance in its desired location. Drop a plumb bob down from the ceiling to the position of the appliance flue exit, and mark the location where the vent will penetrate the ceiling. Drill a small hole at this point. Next, drop a plumb bob from the roof to the hole previously drilled in the ceiling, and mark the spot where the vent will penetrate the roof. Determine if ceiling joists, roof rafters, or other framing will obstruct the venting system. You may wish to relocate the appliance, or to offset, as shown in **Figure 5.13 on page16**, to avoid cutting loadbearing members. When location is determined, drill small hole.



#### Step 3.

To install the round support box/wall thimble cover in a flat ceiling, cut a 10 in. (254mm) square hole in the ceiling, centered on the hole drilled in Step 2. Frame the hole as shown in **Figure 5.14**.



#### Step 4.

Assemble the desired lengths of pipe and elbows necessary to reach from the appliance up through the round support box. Ensure that all pipe and elbow connections are in their fully twist-locked position. Assemble as instructed.

#### Step 5.

Cut a hole in the roof centered on the small drill hole placed in the roof in Step 2. The hole should be of sufficient size to meet the minimum requirements for clearance to combustibles, as specified. Continue to assemble lengths of pipe and elbows necessary to reach from the ceiling support box/wall thimble up through the roof line. Galvanized pipe and elbows may be utilized in the attic, as well as above the roofline. The galvanized finish is desirable above the roofline, due to its higher corrosion resistance.

## NOTE:

- If an offset is necessary in the attic to avoid obstructions, it is important to support the vent pipe every 3 ft. (914mm) to avoid excessive stress on the elbows, and possible separation. Wall straps are available for this purpose, Figure 5.13.
- (2) Whenever possible, use 45° elbows, instead of 90° elbows. The 45° elbow offers less restriction to the flow of flue gases and intake air.

#### Step 6.

Slip the flashing over the pipe section(s) protruding through the roof. Secure the base of the flashing to the roof with roofing nails. Ensure the roofing material overlaps the top edge of the flashing as shown in **Figure 5.15**. Verify that the chimney is the required height above the roof. See roof pitch table, **Figure 4.3**, on page 8 of this manual.



#### Step 7.

Continue to assemble pipe sections until the height of the vent (before adding the termination cap) meets the minimum code requirements as outlined in the current CAN/CGA-B149 Installation Codes (in Canada), the National Fuel Gas Code NFPA 54/ANSI Z223.1 (in USA), or local codes. Note that for steep roof pitches, the vent height must be increased. See Roof Pitch Table **Figure 4.3 on page 8.** In high wind conditions, nearby trees adjoining rooflines, steep pitched roofs, and other similar factors can result in poor draft, or down drafting. In these cases increasing the vent height or switching to the high wind termination cap may solve this problem.

#### Step 8.

Slip the storm collar over the pipe, and push it down to the top of the flashing, **Figure 5.16**. Use non-hardening sealant above and below the joint between the storm collar and the pipe.



#### Step 9.

Twist-lock the vent cap and seal.

**Note:** For multi-story vertical installations, a ceiling firestop is required at the second floor, and any subsequent floors, **Figure 5.17**. The opening should be framed to 10 in. x 10 in. (254mm x 254mm) inside dimensions, in the same manner as shown in **Figure 5.13 on page 16**.



# 



Fire Risk. Explosion Risk.

Any occupied areas above the first floor, including closets and storage spaces, which the vertical vent passed through must be enclosed. The enclosure may be framed and sheetrocked with standard construction materials; however, refer to these installation instructions for the minimum allowable clearance between the outside of the vent pipe and the combustible surfaces of the enclosure. Do not fill any of the required air space with insulation.

## 2. Cathedral Ceiling

#### Step 1.

Follow installation Steps 1 and 2 under vertical installation section, **page 15**.

#### Step 2.

Using the plumb-bob, mark the center line of the venting system on the ceiling, and drill a small hole through the ceiling and roof at this point. From the roof, locate the drill hole and mark the outline of the cathedral ceiling support box.

#### Step 3.

Remove shingles or other roof covering as necessary to cut the rectangular hole for the support box. Cut the hole 1/8 in. (3mm) larger than the support box outline.

#### Step 4.

Lower the support box through the hole in the roof until the bottom of the support box protrudes at least 2 in. (51mm) below the ceiling, **Figure 5.18**. Align the support box both vertically and horizontally with a level. Temporarily tack the support box in place through the inside walls and into the roof sheathing.



#### Step 5.

Using tin snips, cut the support box from the top corners down to the roofline, and fold the resulting flaps over the roof sheathing, **Figure 5.19**. Before nailing it to the roof, run a bead of non-hardening mastic around the top edges of the support box to make a seal between it and the roof. Clean out any combustible material from inside the support box.



#### Step 6.

Complete the cathedral ceiling installation by following the same procedures outlined in steps 4 through 8 for vertical installations, **pages 16-17**.

#### Step 7.

Place the support clamp (provided with the support box) inside the support box (at the bottom), and secure to the pipe section. The clamp allows the support box to support the weight of the pipe sections. Continue to add pipe sections until you are above the roofline.

#### Step 8.

Install the black trim collar around the outside of the cathedral ceiling support box **Figure 5.20**. The two pieces of the trim collar slide over one another to allow for easy adjustment around the support box. Using the six screws provided, secure the four corners and the overlapping sections of the trim collar to the ceiling. You may want to predrill the holes for the overlapped sections for ease of installation.



#### 3. Class A Metal Chimney



# CAUTION

Ensure that existing chimney is functionally sound and clean.
Have inspection done by qualified chimney sweep or professional installer BEFORE converting to direct vent appliance.

#### Step 1.

Remove existing chimney cap.

#### Step 2.

Measure the distance from the top of the chimney to the bottom of the ceiling support box, add 3 in. (76mm) to this measurement, and cut a section of 4 in. (101mm) flex pipe to that length (the flex should be fully extended).

#### Step 3.

Connect the end of the flex pipe section to the underside of the top adapter, using four sheet metal screws **Figure 5.22**.



#### Step 4.

Pass the flex pipe down through the center of the chimney system, and center the top adapter on the top of the chimney pipe. Drill four 1/8 in. (3mm) diameter holes through the top adapter, and into the chimney top. Ensure that you are drilling into the metal on the chimney. Twist lock the high wind termination cap onto the top adapter **Figures 5.23 and 5.24**.





#### Step 5.

Pull the flex pipe down through the ceiling support box, until it protrudes approximately 3 in. (76mm). Connect the flex pipe to the retro connector, and attach with sheet metal screws.

#### Step 6.

Push the flex pipe back up into the ceiling support box, center the retro connector, and attach it to the support box with sheet metal screws.

#### Step 7.

The connection between the appliance and the retro connector may be completed with sections of direct vent pipe.

#### 4. Existing Masonry Chimney



#### Step 1.

Before cutting any holes, assemble the desired sections of direct vent pipe to determine the center of the masonry penetration.

#### Step 2.

Once the center point of the penetration has been determined, cut a 6 in. (152mm) diameter hole in the masonry. If the hole is too large, the retro connector might not mount properly; if the hole is too small, the appliance might starve for intake air. If there is a frame wall in front of the masonry wall, cut and frame a 10 in. (254mm) square opening in the wall (centered around the 6 in. (152mm) masonry opening). If there is sheet rock only (no studs) in front of the masonry the 10 in. (254mm) opening is still needed, but does not need to be framed. If the hole is framed a wall thimble is required. This allows the retro connector to mount directly on the masonry and provide the correct clearances to combustibles **Figure 5.26**.



#### Step 3.

Secure the flashing to the top of the masonry chimney using a bead of non-hardening sealant-adhesive. If the flashing is larger than the top of the chimney, cut and fold flashing as needed to fit chimney **Figure 5.27**.



#### Step 4.

To determine the length of flex needed, measure from 3 in. (76mm) above the top of the flashing down to the level of the opening. Add the distance from the center of the chimney out through the wall. Cut a piece of 4 in. (102mm) flex to this length (extended to its nominal length). Be sure to leave 2-3 in. (51-76mm) of flex above the existing chimney to allow for connection to the termination kit.

#### Step 5.

Connect the flex liner to the top adapter using three sheet metal screws **Figure 5.22 on page 19**.

#### Step 6.

Feed the flex liner through the flashing into the chimney. Carefully feed the flex liner down the chimney to the bottom and out the opening in the masonry wall, forming an angle to line up the flex liner with the vent opening on the appliance.



#### Step 7.

If additional lengths of flex liner are needed to span the chimney height, use a flex coupler to connect the pieces of flex liner together. Connect the flex to the coupler by using four sheet metal screws for each side **Figure 5.28 on page 22.** 



#### Step 8.

Secure the top adapter to the flashing. Use three sheet metal screws through the side of the top adapter into the flange on the flashing **Figure 5.29**. Twist lock the high wind termination cap on to the top adapter.



#### Step 9.

Attach the flex to the retro connector. Use three sheet metal screws to attach the flex liner to the connector. Mount the retro connector to the masonry wall using masonry bolts. **Figure 5.30**. Redrill larger holes on connector as needed. Be careful to ensure that the connector is centered in the opening and the mounting holes line up with the masonry wall.



#### Step 10.

Slide wall thimble cover over retro connector and secure with masonry bolts **Figure 5.31**. If you have a framed wall in front of the masonry, use wood screws to mount wall thimble cover to framed wall, over retro connector and 10 in. (254mm) square framed opening **Figure 5.26 on page 21**. If needed, add a section of direct vent pipe to the retro connector in order to extend through the opening in the wall thimble cover.



#### Step 11.

The connection between the appliance and the retro connector may be completed with sections of direct vent pipe.



# A. Fuel Conversions

Before making gas connections ensure that the appliance being installed is compatible with the available gas type.

Any natural or propane gas conversions necessary to meet the appliance and locality needs must be made by a qualified technician using Hearth & Home Technologies specified and approved parts.

#### 1. Converting to LP Gas

NOTE: Gas conversions should only be performed by a qualified service person, and/or where required by state and local codes, licensed installer/service technician. In the Commonwealth of Massachusetts, installation must be performed by a licensed plumber or gas fitter.

<u>**Kit Contents:**</u> Replacement orifice; replacement pilot injector; valve regulator; conversion label.

**Tools Required:** #2 Phillips screwdriver, slotted screwdriver or Torx TH20, 5/32 Allen wrench, 3/32 Allen wrench, 5/8 in. open end wrench, 7/16 in. socket, socket wrench and extension.



Remove 2 Screws

**Figure 6.1** Remove front (if installed), glass, and logs (if installed.) Remove the optional brick set, if installed. Remove the two screws, one on each side of burner. Retain fasteners for reiinstallation. Lift burner up and out of the firebox.



Figure 6.2 Pull off the pilot hood and set it aside.



**Figure 6.3** Use a 5/32 Allen wrench to remove the pilot injector. Replace pilot injector with the one supplied with the appliance (#35 for Propane, #62 for Natural Gas). There is a locating notch on the pilot hood. Replace the pilot hood, snapping into position.



**Figure 6.4** Remove the main burner orifice using a 5/8 in. wrench. Replace orifice with the proper size as indicated for your gas type and venting.

Installation	Propane (LP)	Natural Gas
Top Vent	.063	.106
Rear Vent	.059	.096

• Re-install burner by placing it into the firebox. Secure in place with the 2 screws previously removed. **DO NOT OVERTIGHTEN.** Re-install the optional brick set, if applicable.

## 2. Valve Regulator Replacement





**Figure 6.5** Remove upper and lower back shield. Loosen the set collars on the extension rods with the 3/32 in. Allen wrench. Remove the rods and adapter caps.



Figure 6.6 Turn control knob to the OFF position, ensure that gas supply to the valve has been turned off. Using a Torx TH20, or slotted screwdriver, remove the three pressure regulator mounting screws (A), pressure regulator tower (B), and diaphragm (C).



Figure 6.7 Ensure that the rubber gasket (**D**) is properly positioned and install the new HI/LO pressure regulator assembly to the valve using the new screws (**E**) supplied with the kit. Tighten screws securely. (Reference torque = 25 in./lb.) Install the enclosed identification label (**F**) to the valve body where it can be seen.

Fill out the conversion label and attach it to the valve cover.

THIS APPLIANCE HAS BEEN	CONVERTED TO	NG LP (CIRCLE ONE)	FUEL:
ORIFICE SIZES: FRONT	MIDDLE	REAR	
MANIFOLD PRESSURE:			
INPUT:			
DATE OF CONVERSION:			
ALTITUDE:			
CONVERTED BY:			
COMPANY NAME:			



# 

Fire Risk. Explosion Risk.

Gas Leak Risk.

- Rubber gasket must be seated properly on valve face.
- Do no install a valve or regulator that has been dropped.

# 

Fire Risk. Explosion Risk.

- If the information in these instructions is not followed exactly, a fire, explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life.
- The qualified service agency is responsible for the proper installation of this conversion kit. The installation is not proper and complete until the operation of the converted appliance is checked as specified in the manufacturer's instructions supplied with the kit.

# **B. Gas Pressures**

Proper input pressures required for optimum appliance performance, gas line sizing requirements need to be followed from NFPA51.



# 

Fire Risk. Explosion Hazard.

High pressure will damage valve.

- Disconnect gas supply piping BEFORE pressure testing gas line at test pressures above 1/2 psig.
- Close the manual shutoff valve BEFORE pressure testing gas line at test pressures equal to or less than 1/2 psig.



# 

Verify inlet pressures.

• High pressure may cause overfire condition.

• Low pressure may cause explosion.

Install regulator upstream of valve if line pressure is greater than 1/2 psig.

Pressure requirements for appliance are shown in the table below.

PRESSURE	NG	LP
Minimum Inlet Pressure	5 inches w.c.	11 inches w.c.
Maximum Inlet Pressure	10 inches w.c.	13 inches w.c.
Manifold Pressure on "HI"	3.5 inches w.c.	10 inches w.c.

If the pressure is not sufficient, ensure:

- 1) The piping used is large enough.
- 2) The supply regulator is adequately adjusted.
- 3) That the total gas load for the residence does not exceed the amount supplied.

The regulator that attaches directly to the residence inlet or to the propane tank is the supply regulator. It should supply gas at the suggested input pressure listed above. Contact the local gas supplier if the regulator is at an improper pressure.

# **C. Gas Connection**

**NOTE:** Have the gas supply line installed in accordance with local building codes, if any. If not, follow ANSI Z223.1. Installation should be done by a qualified installer approved and/or licensed as required by the locality. (In the Commonwealth of Massachusetts, installation must be performed by a licensed plumber or gas fitter.)

**NOTE:** A listed (and Commonwealth of Massachusetts approved) 1/2 inch (13mm) T-handle manual shut-off valve and flexible gas connector are connected to the 1/2 inch (13mm) control valve inlet.

• If substituting for these components, please consult local codes for compliance.



**NOTE:** The gap between the supply piping and gas access hole may be plugged with non-combustible insulation to prevent cold air infiltration.

Leak test all gas line joints and the gas control valve prior to and after starting the appliance.

Before making the gas connection, ensure that the appliance you are installing is designed for the type of gas being supplied. This information can be found on the Ratings Label under the appliance. If the appliance has been converted to propane (LP), the valve cover should have a label stating that the unit has been converted to propane.

Connect the gas line at the 3/8 in. (9.5mm) pipe connector on the valve at the back of appliance. We recommend connecting the appliance with an approved flex gas line. If flex gas lines are not approved in your area, you must connect a hard pipe to the gas hookup.

You must supply a manual shut-off valve in a visible location within 3 feet (914mm) of the appliance.

# A WARNING

Fire or Explosion Risk

- Gas build-up during line purge may ignite.
- Purge should be performed by qualified technician.
- Ensure adequate ventilation.
  - Ensure there are no ignition sources such as sparks or open flame.
- A small amount of air will be in the gas supply lines. When first lighting appliance it will take a short time for air to purge from the lines. When purging is complete the appliance will light and operate normally.

Air only needs to be purged again if the gas valve has been turned to the OFF position.



# 

- · Check all fittings and connections.
- Do not use open flame.
- After the gas line installation is complete, all connections must be tightened and checked for leaks with a commercially-available, non-corrosive leak check solution. Be sure to rinse off all leak check solution following testing.

Fittings and connections may have loosened during shipping and handling.

# 

Fire Risk



Do NOT change the valve settings.

- This valve has been preset at the factory.
- Changing valve settings may result in fire
- hazard or bodily injury.

## **HIGH ALTITUDE INSTALLATIONS**

Intertek Testing Lab listed gas appliances are tested and approved without requiring changes for elevations from 0 to 2000 feet in the U.S.A. and 0 to 4500 feet in Canada.

When installing this appliance at an elevation above 2000 feet, it may be necessary to decrease the input rating by changing the existing burner orifice to a smaller size. Input rate should be reduced by 4% for each 1000 feet above a 2000 foot elevation in the U.S.A. If the heating value of the gas has been reduced, these rules do not apply. To identify the proper orifice size, check with the local gas utility.

If installing this appliance in Canada at an elevation above 4500 feet, check with local authorities.



## A. Recommendation for Wire

See B5 below for recommended maximum lead length (two wire) when using wall thermostat/switch.

**NOTE:** This appliance must be electrically wired and grounded in accordance with local codes or, in the absence of local codes, with **National Electric Code ANSI/NFPA 70-latest edition** or the **Canadian Electric Code, CSA C221.1.** 

WARNING

# B. Connecting to the Appliance



Wire 110v to electrical junction box. Do NOT wire 110v to the valve.

Do NOT wire 110V to wall switch.
Incorrect wiring will damage millivolt systems.



- 1. This appliance may be used with a wall switch, wall mounted thermostat and / or a remote control.
- 2. If using thermostat, use one compatible with a millivolt gas valve system.
- 3. Follow parameters for locating thermostat (see individual thermostat instructions) to ensure proper operation of appliance.
- 4. Use low resistance thermostat wire for wiring from ignition system to the wall switch and thermostat.
- 5. Use the following chart for wire sizing.

Wire Size	Max. Length
16 gauge	65 feet
18 gauge	40 feet
20 gauge	25 feet
22 gauge	18 feet

- 6. Keep wire lengths as short as possible by removing any excess wire length.
- 7. Low voltage and 110 VAC voltage cannot be shared within the same wall box.
- 8. Ensure the thermostat is mounted level for accurate readings.
- 9. The thermostat should be mounted on an inside wall and not in direct line with the appliance convection air.
- 10. If the thermostat is located too close to the appliance, you may need to set the temperature setting slightly higher to maintain the desired temperature in your home.

Do not connect this appliance to a thermostat serving any other appliance.

Bedroom installation in Canada <u>requires</u> this appliance to be connected to a thermostat.



# C. Standing Pilot Ignition System Wiring

This appliance **DOES NOT** require 110 VAC supply for operation. A wiring diagram is shown in **Figure 7.1** on next page.

This appliance is equipped with a millivolt control valve.



# CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

# D. Ignition Module Access and Battery Replacement



Figure 7.2

The Ignition Module (automatic-ignitor) is located on the side of the appliance. This module was incorporated into the design of the Tiara I-C to facilitate "one hand" lighting of the appliance. When the gas control knob is turned to the "Pilot" position, and depressed, the ignitor should begin sparking immediately. If the ignitor does not begin sparking immediately, then it is in need of service.

Replace damaged wire with type 105° C

Wire must have high temperature insulation.

Shock hazard.

rated wire.

•

The ignitor is located on a plate attached to the side of the appliance using two #8 Phillips head screws. To access the ignitor, remove the two screws securing the plate to the side of the appliance and slide the plate out.

The single "AA" 1.5 V battery that powers the ignitor is located in the module. To replace the battery, open the battery compartment and remove old battery. Replace the battery. Make sure the polarity is correct.

# CAUTION

Battery polarity must be correct or module damage will occur.



# **Appliance Setup**

## A. Remove Shipping Materials

Remove shipping materials from inside or underneath the firebox.

#### **B.** Accessories

Install approved accessories per instructions included with accessories. Refer to Section 12 for appropriate accessories.



# 

Shock or fire risk. Use ONLY optional accessories approved for this appliance.

- Using non-listed accessories voids warranty.
- Using non-listed accessories may result in a safety hazard.
- Only Hearth & Home Technologies approved accessories may be used safely.

# C. Top to Rear Vent Conversion

See Service Parts list in Section 12 for Kit information.

<u>**Kit Contents:</u>** Rear vent grille, NG orifice (.096), LP orifice (.059)</u>

**Tools Required:** Power drill; #2 Phillips bit; high-temp sealant (optional).





Figure 8.1 Remove top grille, as highlighted.



**Figure 8.2** Remove vent pipe adapter and gasket by removing 4 screws. Save the screws. (If gasket breaks, apply high-temp sealant to bottom of adapter before installing as shown in Figure 8.8.)



Figure 8.3 Remove the inner collar adapter.



**Figure 8.4** Locate the knock out on rear of appliance. Either remove the four screws holding the back shield in place, saving the screws, OR break the seal on the knock out and discard the knock out.



Figure 8.5 Remove rear access plate and gasket. Save the screws.



**Figure 8.6** Place cover plate and gasket over top vent and attach with the four screws removed in Figure 8.2.



Figure 8.7 Insert inner collar adapter to rear flue vent.



**Figure 8.8** Install vent pipe adapter with gasket or high-temp sealant to rear vent opening. Attach with screws removed in Figure 8.5.

Place grille (without a hole) gently into the opening on top of appliance. Part: RV-GRILLE-T1

D. Baffle Installation/Adjustment



**Figure 8.9** Position baffle on top of baffle retainers on left and right sides. Centering baffle on retainers, ensure that the dark painted bevelled edge and darker painted baffle bottom side faces toward the front viewing area of the firebox. Bend the center tabs up to prevent the baffle from sliding out.

# E. Leg Leveling System



Figure 8.10 Thread Allen bolts through nuts until flush.

**NOTE:** Two Allen bolts and two nuts are included in the component bag. Normally, only one is required on the leg not touching the floor.



**Figure 8.11** Slide assembled nuts and bolts into slots on legs with the nuts on the bottom.



**Figure 8.12** Use a 5/32 in. 4mm) Allen wrench to adjust legs up and down to desired level.

## F. Brick Installation

There are two side bricks. Place the brick in position. The top flange of the brick clip is positioned in a slot in the baffle bracket. The side brick fits behind the brick clip.

**NOTE:** The bricks need to be installed before placing the logs in the firebox.



## G. Positioning the Logs

While still breakable, the logs do not become fragile until after the appliance is burned and they have cured. After curing, any handling must be done with care as breakage can easily occur.

PLEASE NOTE: Logs have been designed to work specifically with the burner of this appliance. Exact placement will ensure proper operation of your gas appliance and reduce sooting.



Figure 8.14 Position rear log (#3) over the two locating pins.



**Figure 8.15** Place right front log (#1) into the depression. The log sits upright and does not lean against log #3.



**Figure 8.16** Place left front log (#2) into the depression. The log sits upright and does not lean against log #3.

# H. Mineral Wool



Explosion Risk.

Follow ember placement instructions in manual.

Do NOT place embers directly over burner ports.

• Replace ember material annually.

Improperly placed embers interferes with proper burner operation.



**Figure 8.17** Apply dime size pieces sparingly along front edge of burner. Do not completely block ports.

## I. Shutter Adjustment



**Figure 8.18** The shutter is located on the underside of the appliance, on the right side. To adjust the shutter, loosen the wingnut.

Moving the shutter bolt to the right closes the shutter. Moving the shutter bolt to the left, will open the shutter. Opening the shutter causes flames to become shorter and blue. Closing the shutter creates taller orange/yellow flames.

**NOTE:** Do not close so much as to cause a sooty flame. Improper adjustment can cause sooting in the firebox and/or on the outside of a house with a horizontal termination.

After adjustment, tighten wingnut to lock in place.

## J. Glass Replacement

- 1. Turn appliance OFF and let cool down before replacing the glass.
- 2. Remove the front by lifting upwards 1/2 in. (13mm) and away from the appliance.
- 3. Remove the glass door by opening the latches located on both the left and right sides at the bottom of the glass. Pull towards you and separate latches from notches.
- 4. The new glass will come installed in a new glass frame. Installation of the new glass and frame is the opposite of the removal.
- 5. Re-install appliance front.

**NOTE:** The glass, gasketing, and frame must be replaced as a complete unit as supplied by the manufacturer.

# Do NOT use substitute material.



# K. Optional Blower Installation

<u>**Kit Contents:**</u> Blower; speed control; lock nut; control knob; ground clip; temperature sensor switch; wing nut; 2 high-temp black wires; 1 high-temp blue wire.

Tools Required: Philips head screwdriver; 1/2 in. wrench.

The GFK-160A blower has been designed to circulate room air through the appliance to enhance heat output.

The blower system operates on 120 VAC, 60 Hz power. This is available through a receptacle in the factory installed junction box on the underside of the appliance.



**Figure 8.19** Compare CONTENTS OF CARTON with the actual parts received. If any parts are missing or damaged, contact your dealer before starting installation. Do not install a damaged blower kit.



**Figure 8.20** From the rear of the appliance, slide the blower into the blower housing with the magnetic strips down. The blower openings should be at the front.

**Figure 8.21** From the front of the appliance, thread the blower cord plug through hole on bottom of cord bracket assembly, and plug blower power cord into blower receptacle labeled "FAN" on power cord.





**Figure 8.22** Slide temperature sensor switch/bracket assembly onto the 10-32 screw located on the left underside of the appliance. Secure the bracket assembly with the wing nut provided.

Disconnect the two wire ends connected together on the power cord. Connect female end to one side of temperature sensor switch.

Connect one end of the black wire provided with the kit to the remaining wire end on power cord.

Feed loose ends of the black and blue wires through the orange grommet in fan housing.



**Figure 8.24** Remove valve access cover from back of appliance by removing the three screws indicated.



**Figure 8.25** Remove the knob and lock nut from the speed control. Install speed control onto access panel with stem sticking out the pre-punched hole. Attach the lock nut tightly and re-attach the knob on the stem.

Attach blue and black wires routed through orange grommet in fan housing to the speed control. Re-install access panel.



#### → Figure 8.23 Blower Wiring Diagram

# L. Intake Fuel Restrictor Adjustment

#### (For top or rear vent installations)

See vent graph for recommendations on page 11 before you begin your adjustment. If your installation falls within the range of the gray shaded area of graph, it may be necessary to make an adjustment to the vertical fuel restrictor to improve the flame appearance in your appliance.

1. Top Vent Installations:



Shown Fully Open

**Figure 8.26** Locate the fuel restrictor adjustment on the intake plenum, accessing through the appliance front. Adjustor is centered at the top of the appliance.

- 1. Let appliance warm up before adjusting.
- 2. Loosen screws using a Phillips head screwdriver.
- 3. Pivot the vertical fuel restrictor in 1/4 in. (6mm) increments while observing the flame activity.
- 4. Turning clockwise to open fuel restrictor = less flame height and more blue in flame color.
- 5. Turning counterclockwise to close fuel restrictor = increased flame height and more yellow in flame color.
- 6. Make adjustment until flame size and activity suits your personal preference, and then retighten screws on adjustment control.
- 2. Rear Vent Installations:



**Figure 8.27** The rear vent fuel restrictor is located in the back of the firebox. It is recommended to make adjustment prior to installation.

- 1. Remove front/glass/ logs and brick (if installed).
- 2. Loosen screws and slide up to suggested settings.
- 3. Tighten screws
- 4. Re-install front/glass/logs and brick (if applicable).

## M. Warming Shelves Installation

<u>**Kit Contents:**</u> (2) Warming shelves, (2) brackets, and (4) 1/4 in. Phillips Head screws.

Tools Required: Phillips Head screwdriver.











**Figure 8.30** Gently lift cast top off of appliance and set aside. Install warming shelf to appliance gently aligning the shelf with the tabs that are in place on the side of the appliance. Use the leveling screw located in the center of the warming shelf to adjust the shelf to its desired position.



**Figure 8.31** Align bracket to firebox and gently tighten the screw to hold it in place. Reassemble the appliance.



# A. Before Lighting Appliance

Read this entire manual prior to using the appliance. Failure to follow the instructions may result in property damage, bodily injury, or even death.

- Remove all shipping materials from inside and/or underneath the firebox.
- Review proper placement of logs, mineral wool.
- Check the wiring.
- Check the baffle adjustment.
- Ensure that there are no gas leaks.
- Ensure that the glass is sealed and in the proper position.
- Ensure that the flow of combustion and ventilation air is not obstructed (front grilles and vent caps).



# 

Glass door must be in place when appliance is operating.

Risk of: • Combustion Fumes

Fire

Do NOT operate appliance with glass door removed.

- Open viewing glass for servicing only.
- Glass door MUST be in place and sealed before operating appliance.
- Only use glass door certified for use with appliance.
- Glass replacement should be done by qualified technician.

# 



#### HOT! DO NOT TOUCH. SEVERE BURNS MAY RESULT. CLOTHING IGNITION MAY RESULT.

Glass and other surfaces are hot during operation and cool down.

- Keep children away.
- CAREFULLY SUPERVISE children in same room as appliance.
- Alert children and adults to hazards of high temperatures.
- Do NOT operate with protective barriers open or removed.
  Keep clothing, furniture, draperies and other combustibles away.

# 

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with this appliance. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

# 

Do NOT use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

# **B.** Controls

**FAN SPEED:** This knob controls the speed of the blower that pushes the heated air into the room.

**MAIN BURNER:** This control is used to turn the appliance on and off.

**PILOT IGNITOR**: The pilot ignitor is used only to start the pilot. When the valve control knob is turned to the pilot position and fully depressed press the piezo ignitor repeatedly creating a blue spark directly next to the pilot, igniting the pilot flame.

**VALVE CONTROL**: This knob is used to control gas to the appliance and for starting the pilot. There are three positions, **ON**, **OFF**, **& PILOT**. The indicator on the valve indicates the position of the knob.

**COMFORT CONTROL**: This knob controls the flame height from low ("LO") to high ("HI").

**NOTE:** If using a remote control wall switch, or thermostat, the On/Off Switch must be left "OFF". Turning the On/Off Switch to "ON" will keep the appliance on continually.

# FOR YOUR SAFETY READ BEFORE LIGHTING

# WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life

- A. This appliance has a pilot that must be lit manually. When lighting the pilot, follow these instructions exactly.
- B. **BEFORE LIGHTING**, smell around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

#### WHAT TO DO IF YOU SMELL GAS:

- \* Do not try to light any appliance.
- \* Do not touch any electric switch, do not use any phone in your building.
- \* Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- \* If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

# **LIGHTING INSTRUCTIONS**

- 1. STOP! Read the safety information above on this label.
- 2. Set the thermostat to the lowest setting (if applicable) and turn off the switch at the control panel.
- 3. Disconnect the power from the appliance.
- 4. Open the door of the appliance. May need to remove face/front first.
- 6. Wait five (5) minutes to clear out any gas. Smell for gas, including near the floor. If you smell gas, STOP! Follow "B" of the safety information above. If you don't smell gas go to the next step.
- 7. Push gas control knob in and turn counterclockwise 🦟 to the pilot position. NOTE: Knob cannot be turned unless knob is pushed in slightly. Do not force.
- 8. PIEZO IGNITER: Press down on the gas control knob in pilot position and simultaneously press the piezo igniter. (This may take many repetitions for lighting.)
  - ELECTRONIC IGNITER: If the unit is equipped with an electronic igniter it should begin sparking right away.
- 9. The pilot should be visible through the door opening.
- After the pilot is lit, continue holding control knob down for approximately 30 seconds. Release the knob and it will pop back up. Pilot should remain lit. If it goes out, repeat steps 7 through 9.
  - \* If the knob does not pop up when released, stop and immediately call your service technician or gas supplier.
- 11. Re-install door and face. <u>Wait five minutes to allow pilot flame to stabilize and</u> <u>establish proper draft.</u>
- 12. Push down and turn gas control knob counterclockwise  $\checkmark$  to "ON".
- 13. Push burner rocker switch on the control panel to "ON". If thermostat is to be used, leave switch in "OFF" position and set the thermostat to desired setting.
- 14. Reconnect electrical power to appliance.

# TO TURN OFF GAS TO APPLIANCE

- 1. Set the thermostat to lowest setting.
- 2. Turn off all electric power to the appliance if service is to be performed.
- 3. Push in gas control knob slightly and turn clockwise  $\frown$  to "OFF" position.



# D. After Appliance is Lit

#### **Initial Break-in Procedure**

When you light your appliance, you may notice that it produces heat which does have an associated odor or smell. If you feel this odor is excessive it may require the initial three to four hour continuous burn on high followed by a second burn up to 12 hours to fully drive off any odor from paint and lubricants used in the manufacturing process. Condensation on the glass is normal.

**NOTE:** The appliance should be run three to four hours on the initial start-up. Turn it off and let it cool completely. Remove and clean the glass. Replace the glass and run the appliance for an additional 12 hours. This will help to cure the products used in the paint and logs.

During this break-in period it is recommended that some windows in the house be opened for air circulation. This will help avoid setting off smoke detectors, and help eliminate any odors associated with the appliance's initial burning.



Do NOT obstruct combustion and ventilation air.

- Do NOT place combustible items on top of or in front of appliance.
- Keep furniture, draperies away from appliance.

# CAUTION

- Prevent accidental appliance operation when not attended.
- Unplug or remove batteries from remote control if absent or if appliance will not be used for an extended period of time.
- · Property damage possible from elevated temperatures.

# CAUTION

Smoke and odors released during initial operation.

- Open windows for air circulation.
- Leave room during initial operation.
- Smoke may set off smoke detectors.

Smoke and odors may be irritating to sensitive individuals.



# 

Fire Risk. Keep combustible materials, gasoline and other flammable vapors and liquids clear of appliance.

- Do NOT store flammable materials in the appliance's vicinity.
- Do NOT use gasoline, lantern fuel, kerosene, charcoal lighter fluid or similar liquids in this appliance.
- · Combustible materials may ignite.

# E. Frequently Asked Questions

ISSUE	SOLUTIONS
Condensation on the glass	This is a result of gas combustion and temperature variations. As the appliance warms, this condensation will disappear.
Blue flames	This is a result of normal operation and the flames will begin to yellow as the appliance is allowed to burn for 20 to 40 minutes.
Odor from appliance	When first operated, this appliance may release an odor for the first several hours. This is caused by the curing of the paint and the burning off of any oils remaining from manufacturing. If appliance has not been used for some time, dust can build up and cause an odor.
Film on the glass	This is a normal result of the curing process of the paint and logs. Glass should be cleaned within 3 to 4 hours of initial burning to remove deposits left by oils from the manufacturing process. A non-abrasive cleaner such as gas appliance cleaner may be necessary. See your dealer.
Metallic noise	Noise is caused by metal expanding and contracting as it heats up and cools down, similar to the sound produced by a furnace or heating duct. This noise does not affect the operation or longevity of the appliance.

# **10** Troubleshooting

With proper installation, operation, and maintenance your gas appliance will provide years of trouble-free service. If you do experience a problem, this troubleshooting guide will assist a qualified service person in the diagnosis of a problem and the corrective action to be taken. This troubleshooting guide can only be used by a qualified service technician.

Symptom	Possible Cause	Corrective Action
1. After repeated trig- gering of the piezo	a. Defective ignitor.	Check the spark at the electrode and pilot. If no spark and electrode wire is properly connected, replace the ignitor.
button, the spark ignitor will not light the pilot.	b. Defective pilot or misaligned electrode (spark at electrode).	Using a match, light the pilot. If the pilot lights, turn off the pilot and trigger the piezo button again. If the pilot lights, an improper gas/air mixture caused the bad lighting and a longer purge period is recommended. If the pilot will not light, ensure the gap at the electrode and pilot is one-eighth (1/8) inch to have a strong spark. If the gas is OK, replace the pilot.
	c. No gas or low gas pressure.	Check the remote shut-off valve from the appliance. Usually, there is a valve near the gas main. There can be more that one (1) valve from the appliance and the main.
	d. No LP in tank.	Check the LP (propane) tank. You may be out of fuel.
2. The pilot will not stay lit after carefully follow- ing the lighting instruc-	a. Defective thermo- couple.	Check that the pilot flame impinges on the thermocouple. Clean and / or adjust the pilot for maximum flame impingement.
tions.		Ensure that the thermocouple connection at the gas valve is fully inserted and tight (hand tighten plus 1/4 turn).
		Disconnect the thermocouple from the valve, place one millivolt lead wire on the tip of the thermocouple and the other meter wire on the thermocouple copper lead. Start the pilot and hold the valve knob in. If the millivolt reading is less than 15mV, replace the thermocouple.
	b. Defective valve.	If the thermocouple is producing more than 15 millivolts, replace faulty valve.
3. The pilot is burning, there is no gas to the burner, the valve knob is in the ON position, and the ON/OFF switch is in	a. ON/OFF switch or wires defective.	Check the ON/OFF switch and wires for proper connections. Place the jumper wires across the terminals at the switch. If the burner comes on, replace the defective switch. If the switch is OK, place the jumper wires across the switch wires at the gas valve. IF the burner comes on, the wires are faulty or connections are bad.
the ON position.	b. Thermopile may not be generating sufficient millivoltage.	If the pilot flame is not close enough physically to the thermopile, adjust the pilot flame.
		Be sure the wire connections from the thermopile at the gas valve ter- minals are tight and that the thermopile is fully inserted into the pilot bracket.
		Check the thermopile with a millivolt meter. Take the reading at TH- TP&TP terminals of the gas valve. The meter should read 325 millivolts minimum, while holding the valve knob depressed in the pilot position, with the pilot lit, and the ON/OFF switch in the OFF position. Replace the faulty thermopile if the reading is below the specified minimum.
		With the pilot in the ON position, disconnect the thermopile leads from the valve. Take a reading at the thermopile leads. The reading should be 325 millivolts minimum. Replace the thermopile if the reading is below the minimum.

Symptom	Possible Cause	Corrective Action
3. (Continued)	c. Defective valve.	Turn the valve knob to the ON position. Place the ON/OFF switch in the ON position. Check the millivolt meter at the thermopile terminals. The millivolt meter should read greater than 125mV. If the reading is acceptable, and if the burner does not come on, replace the gas valve.
	d. Plugged burner orifice.	Check the burner orifice for stoppage. Remove stoppage.
	e. Wall switch or wires are defective.	Follow the corrective action in Symptom and Possible Cause 1.a. Check the switch and wiring. Replace where defective.
4. Frequent pilot outage problem.	a. Pilot flame may be too high or too low, or blowing (high), causing safety pilot to drop out.	Clean and adjust the pilot flame for maximum flame impingement on thermocouple. Follow lighting instructions carefully.
5. The pilot and main	a. No LP in tank.	Check the LP (propane) tank. Refill the fuel tank.
burner extinguish while in operation.	b. Inner vent pipe leaking exhaust gases back into the system.	Check for proper vent connection at flue collar and all vent joints.
	c. Horizontal vent improperly pitched.	The horizontal vent cap should slope down only enough to prevent any water from entering the appliance.
	d. Bad thermopile or thermocouple.	Replace if necessary.
	e. Improper vent cap installation.	Check for proper installation and freedom from debris or blockage.
6. Glass soots.	a. Flame impinge- ment.	Adjust the log set so that the flame does not excessively impinge on it. Check that logs are placed according to installation instructions.
	b. Improper shutter setting.	Adjust the air shutter at the base of the burner.
	<ul> <li>c. Debris around opening at base of burner.</li> </ul>	Inspect the opening at the base of the burner. NO MATERIAL SHOULD BE PLACED IN THIS OPENING.
7. Flame burns blue and lifts off burner.	<ul> <li>a. Insufficient</li> <li>oxygen being sup-</li> <li>plied.</li> </ul>	Ensure that the vent cap is installed properly and free of debris. Ensure that the vent system joints are tight and have no leaks.
		the air holes in the center of the base pan beneath the burner.
		Ensure that the glass is tightened properly on the appliance, particularly on top corners.

# Maintaining and Servicing Your Appliance

Although the frequency of your appliance servicing and maintenance will depend on use and the type of installation, a qualified service technician should perform an appliance check-up at the beginning of each heating season.

# 

Risk of injury or property damage. **Before servicing:** 

- Turn off gas.
- Turn off electricity to appliance.
- Ensure appliance is completely cooled.

#### After servicing:

- · Replace front and glass, if removed.
- · Reseal and reinstall any venting removed for servicing.



Annual inspection by qualified technician recommended.

#### Check:

- · Condition of glass, glass assembly and glass seal.
- · Obstructions of combustion and ventilation air.
- Obstructions of termination cap.
- Burner ignition and operation.
- Burner air shutter adjustment
- Gas connections and fittings.

#### Clean:

- Glass
- Air passageways, grilles, control compartment
- Burner, burner ports. USE CAUTION WHEN CLEANING/ HANDLING CERAMIC BURNER.

#### Risk of:

- Fire
- Delayed ignition or explosion
- Exposure to combustion fumes
- Odors

# 

Inspect external vent cap regularly.

- Ensure no debris blocks cap.
- Combustible materials blocking cap may ignite.
- Restricted air flow affects burner operation.



# CAUTION

Handle glass assembly with care.

NOTE: Clean glass after initial 3-4 hours operation. Longer operation without cleaning glass may cause a permanent white film on glass.

#### When cleaning glass door:

- Avoid striking, scratching or slamming glass.
- Do NOT use abrasive cleaners.
- Use a hard water deposit glass cleaner on white film.
- Do NOT clean glass when hot.
- Turn off appliance after 3-4 hours of operation and ALLOW TO COOL.
- Remove and clean glass assembly.
- Replace glass assembly and operate appliance for additional 12 hours.
- Refer to maintenance instructions.



# A. Maintenance Tasks

Inspect	Maintenance Tasks				
Doors	1. Inspect for scratches, dents or other damage and repair as necessary.				
	2. Verify no obstructions to air flow.				
	3. Verify maintenance of proper clearance to combustible household objects.				
Gasket Seal, Glass	1. Inspect gasket seal and its condition.				
Assembly and Glass	2. Inspect glass for scratches and nicks that can lead to breakage when exposed to heat.				
	3. Confirm there is no damage to glass or glass frame, Replace as necessary.				
	4. Verify that latches engage properly and glass attachment components are intact and operat- ing properly. Replace as necessary.				
	5. Clean glass. Replace glass assembly if severely coated with silicate deposits that cannot be removed.				
Valve Compartment and Firebox Top	1. Vacuum and wipe out dust, cobwebs, debris or pet hair. Use caution when cleaning these areas. Screw tips that have penetrated the sheet metal are sharp and should be avoided.				
	2. Remove any foreign objects.				
	3. Verify unobstructed air circulation.				
Logs	1. Inspect for broken, damaged, or missing logs. Replace as necessary.				
	2. Verify correct log placement and no flame impingement causing sooting. Correct as necessary.				
Firebox	1. Inspect for paint condition, warpage, corrosion or perforation. Sand and repaint as necessary.				
	2. Replace appliance if firebox has been perforated.				
Burner Ignition and	1. Verify burner is properly secured and aligned with pilot or igniter.				
Operation	2. Clean off burner top, inspect for plugged ports, corrosion or deterioration. Replace burner if necessary. <b>USE CAUTION WHEN CLEANING/HANDLING CERAMIC BURNER.</b>				
	3. Replace ember material with new dime-size and shape pieces. Do not block ports or obstruct lighting paths.				
	4. Check for smooth lighting and ignition carryover to all ports. Verify there is no ignition delay.				
	5. Inspect for lifting and other flame problems.				
	6. Inspect orifice for soot, dirt or corrosion.				
	7. Verify manifold and inlet pressures. Adjust regulator as required.				
	8. Inspect pilot flame strength. Clean or replace orifice as necessary.				
	9. Inspect thermocouple/thermopile sensor rod for soot, corrosion and deterioration. Polish with fine steel wool or replace as required.				
	10. Verify millivolt output. Replace as necessary.				
Venting	1. Inspect venting for blockage or obstruction such as bird nests, leaves, etc.				
	2. Confirm that termination cap remains clear and unobstructed by plants, etc.				
	3. Verify that termination cap clearance to subsequent construction (building additions, decks, fences or sheds) has been maintained.				
	4. Inspect for corrosion or separation.				
	5. Verify weather stripping, sealing and flashing remains intact.				
Remote Controls	1. Verify operation of remote.				
	2. Replace batteries in remote transmitters and battery-powered receivers.				



# A. Appliance Dimension Diagram

Dimensions are actual appliance dimensions. Use for reference only. For clearances to combustibles refer to Section 3.



## **B. Vent Components Diagram**



# C. Vent Components List

Description	HHT SLP M= Multi Pack (6)	Simpson Dura-Vent <sup>®</sup> DirectVent Pro
4" Pipe Length, Galvanized	SLP4M	-
4" Pipe Length, Black	SLP4-BK	-
6" Pipe Length, Galvanized	SLP6M	46-DVA-06
6" Pipe Length, Black	SLP6-BK	46-DVA-06B
9" Pipe Length, Galvanized	-	46-DVA-09
9" Pipe Length, Black	-	46-DVA-09B
12" Pipe Length, Galvanized	SLP12M	46-DVA-12
12" Pipe Length, Black	SLP12-BK	46-DVA-12B
18" Pipe Length, Galvanized	-	46-DVA-18
18" Pipe Length, Black	-	46-DVA-18B
24" Pipe Length, Galvanized	SLP24M	46-DVA-24
24" Pipe Length, Black	SLP24-BK	46-DVA-24B
36" Pipe Length, Galvanized	SLP36M	46-DVA-36
36" Pipe Length, Black	SLP36-BK	46-DVA-36B
48" Pipe Length, Galvanized	SLP48M	46-DVA-48
48" Pipe Length, Black	SLP48-BK	46-DVA-48B
Adjustable Length, 3"-6", Black	SLP6A-BK	-
Adjustable Length, 3"-6", Galvanized	SLP6AM	-
Adjustable Length, 3"-7", Galvanized	-	46DVA-08A
Adjustable Length, 3"-7", Black	-	46DVA-08AB
Adjustable Length, 3"-12", Black	SLP12A-BK	-
Adjustable Length, 3"-12", Galvanized	SLP12AM	-
Adjustable Length, 3"-14.5", Galvanized	-	46DVA-16A
Adjustable Length, 3"-14.5", Black	-	46DVA-16AB
Adjustable Length, 16", Galvanized	-	46DVA-16A
Adjustable Length, 16", Black	-	46DVA-16AB
2' Flexible Pipe Length	SLP-FLEX-2	-
3' Flexible Pipe Length	SLP-FLEX-3	-
5' Flexible Pipe Length	SLP-FLEX-5	-
10' Flexible Pipe Length	SLP-FLEX-10	-
3" x 35' Flex Extension	-	2280
4" x 35' Flex Extension	-	2281
45° Elbow, Galvanized	SLP45M	-
45° Elbow, Black	SLP45-BK	See Swivel
45° Elbow, Swivel, Galvanized	-	46DVA-E45
45° Elbow, Swivel, Black	-	46DVA-E45B

# C. Vent Components List (continued)

Description	HHT SLP M= Multi Pack (6)	Simpson Dura-Vent <sup>®</sup> DirectVent Pro
90° Elbow, Galvanized	SLP90M	See Swivel
90° Elbow, Black	SLP90-BK	See Swivel
90° Elbow, Swivel, Galvanized	-	46DVA-E90
90° Elbow, Swivel, Black	-	46DVA-E90B
Adjustable Flashing, 0/12-6/12	SLP-RF6M	46DVA-F6
Adjustable Flashing, 7/12-12/12	SLP-RF12M	46DVA-F12
Attic Insulation Shield 12"	SLP-AS2M	-
Attic Insulation Shield, Adjustable 11"-20"	-	46-DVA-IS
Cathedral Support Box	SLP-CCS-BK	46DVA-CS
Ceiling Support	-	46DVA-DC
Co-Axial to Co-Lineal Appliance Connector	-	46DVA-GCL
Decorative Ceiling Firestop - Black	SLP-DCF-BK	-
Decorative Radius Cover	DRC-RADIUS	-
Firestop Spacer/Ceiling Firestop	SLP-FSM	46DVA-FS
Flex Trap Cap with Firestop	SLP-FLEX-TRAP	-
Flex Trap Cap with Firestop and 30" Flex Pipe	SLP-FLEX-TRAP30	-
Masonry Chimney Conversion Kit	-	46DVA-KMC
Offset Support	-	46DVA-ES
Offset Wall Thimble, Black	SLP-WT-BK	-
Storm Collar	SLP-SCM	46DVA-SC
Wall Support Band	SLP-HVSM	46-DVA-WS
Wall Thimble, Black	SLP-WSM	46DVA-WT
<b>TERMINATION CAPS &amp; KITS</b>		
Basic Horizontal Termination Kit (A)	SLP-SK-BK	46DVA-KHA
Chimney Liner Termination Kit	-	46DVA-GK
Horizontal Square Termination Cap	SLP-HHW2	46DVA-HC
Horizontal Termination Kit (B)	-	46DVA-KHC
Snorkel Termination 14"	SLK-SNKD	46DVA-SNK14
Snorkel Termination 36"	-	46DVA-SNK36
*Stove Adaptor Kit (Vertical Cap Kit)	LINK-STOVE	-
Trapezoid Termination Kit (3-1/8"-4-3/4")	SLP-TRAP1	-
Trapezoid Termination Kit (5-1/4" X 9-1/4")	SLP-TRAP2	
Vertical Termination Cap	SLP-TVHW	46DVA-VCH

#### This is not a complete list - contact individual manufacturer for a complete and detailed list

**NOTES:** <sup>1</sup>Before cutting any holes check pipe manufacturers current instructions.

<sup>2</sup>Each pipe manufacturer has their own list of parts for kits. <sup>3</sup>SL is not interchangeable with SLP.

\* Stove Adaptor Kit (Vertical Cap Kit) Includes 30'-4" flex, adapters, wall thimble, masonry, ZC flashing, 991DA vertical cap.



**TIARA I-C** 

No one builds a better fire

Gas Stove - DV

Beginning Manufacturing Date: June 2010 Ending Manufacturing Date: Active

Tiaral-BK-C (Black), Tiaral-BR-C (Brown), Tiaral-CES-C (Espresso), Ending manufacturing Date: May 2011: Tiaral-CTO-C (Tuscan Olive)





Beginning Manufacturing Date: June 2010 Ending Manufacturing Date: Active

No one builds a better fire

IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers**. Provide model number and serial number when requesting service parts from your dealer or distributor.

Stocked

ITEM	DESCRIPTION	COMMENTS:	PART NUMBER	
	Log Set Assembly		SRV7055-013	Y
1	Log 1		7055-124	
2	Log 2		7055-125	
3	Log 3		7055-126	
4	Grill, Top Vent		7010-116	
		Black	7010-109BK	
	_	Brown	7010-109PBR	
5	Гор	Espresso	7010-109CES	
		Tuscan Olive	7010-109CTO	
6	SLP Stove Adaptor		SLP-SAM	
7	DV Adaptor		7010-172	
	Gasket, Adaptor		460-0610	
8	Relief Door Assembly		7010-003	
9	Cast, Mounting Bracket Bottom		7010-124	
10	Cast, Mounting Bracket Top	Qty 2 req	7010-138	
		Black	7010-110BK	
	Side, Left or Right	Brown	7010-110PBR	
11		Espresso	7010-110CES	
		Tuscan Olive	7010-110CTO	
12	Baffle Bracket		7010-137	
13	Baffle		7010-136	Y
14	Glass Assembly		7010-017	Y
15	Door Assembly w/Glass		7010-016	Y
		Black	7010-111BK	
16	Front	Brown	7010-111PBR	
10	Front	Espresso	7010-111CES	
		Tuscan Olive	7010-111CTO	
		Black	7010-113BK	
17	Deerlet	Brown	7010-113PBR	
	Door Leit	Espresso	7010-113CES	
		Tuscan Olive	7010-113CTO	
		Black	7010-112BK	
10	Door Pight	Brown	7010-112PBR	
	Door Right	Espresso	7010-112CES	
		Tuscan Olive	7010-112CTO	
19	Glass Retainer		7010-121	
20	Burner w/Neck Assembly		SRV7010-025	Y

Additional service part numbers appear on following page.

# HEATEGLO

# TIARA I-C

Beginning Manufacturing Date: June 2010 Ending Manufacturing Date: Active

#### No one builds a better fire

IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers**. Provide model number and serial number when requesting service parts from your dealer or distributor.

Stocked

model number and serial number when requesting service parts from your dealer or distributor.					at Depot
IT	EM	DESCRIPTION	COMMENTS:	PART NUMBER	
	21	Log Support Rear		7010-134	
	22	Latch, Draw	Qty 2 req	229-0640	Y
	23	Burner Plate		7010-022	
	24	Cord Bracket Assembly		SRV7010-081	Y
	25	Pilot Spacer		7031-256	



26.1	Pilot Assembly		230-1781	Y
26.2	Air Shutter Assembly		SRV7010-027	Y
26.3	Bulk Head		26457	Y
26.4	Bulk Head Stop		474-0090	
27	Blower Bracket		7010-146	
28	Blower Housing		7010-145	
29	Cover Plate		7010-159	
	Gasket, Cover Plate		7010-160	
20	Valve, LP		842-0230	Y
30	Valve, NG		842-0240	Y
31	Ignition Access Cover		464-0300	
32	Back Shield		7010-125	
33	ON/OFF Rocker Switch		230-0730	Y
34	Ignition Module		230-1880	Y
35	Valve Access Assembly		464-5060	
	Component Pack	Black	7010-009	
	Contains Warranty Card. On/Off Valve. Leveling Assembly.	Brown	7010-019	
	Owners Manual, Fasteners, Touch-Up Paint, Platinum	Espresso	7010-023	
	Embers	Tuscan Olive	7010-024	
	Conversion Kit NG		NGK-30K	Y
	Conversion Kit LP		LPK-30K	Y
	Pilot Orifice NG		842-4440	Y
	Pilot Orifice LP		200-2630	Y
	Regulator NG		230-1570	Y
	Regulator LP		230-1520	Y

Additional service part numbers appear on following page.



**TIARA I-C** 

No one builds a better fire

Beginning Manufacturing Date: June 2010 Ending Manufacturing Date: Active

IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. <b>Hearth and Home Technologies does not sell directly to consumers</b> . Provide model number and serial number when requesting service parts from your dealer or distributor.				Stocked at Depot
ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	AVK Repair Kit		<b>RIVNUT-REPAIR</b>	Y
	Blower Assembly (Optional)		GFK-160A	
	Knob, Rheostat		100-512	Y
	Rheostat Assembly		100-510A	Y
	Temp Sensor (Limit)		107-531A	Y
	Brick Set		BRICK-TI	
	Damper Stop		468-0210	
	Damper Plate		468-0360	
	Male Elbow		4021-045	
	Door Retainer		7010-122	
	Flex Line 3/8 Flare X 22L		7000-197	Y
	Gasket, Flue collar		455-0660	
	Grill, Rear Vent		RV-GRILLE-TI	
	Orifice NG (.096)		13844	Y
	Orifice LP (.059)		13445	Y
	Hinge Pins Gold	Pkg of 2	844-5750	Y
	Ignition cable		230-1900	Y
	Knob, Brass, .75		456-0080	
	Leveling Assembly		7000-000	
	Line, Gas, T6-19		450-6360	
	Magnet, Round		SRV7000-140	Y
	Mesh Screen		MESH-T1	
	Mineral Wool		050-721	
	ON/OFF Valve		15697	Y
	Orifice, NG, (.106)		19837	Y
	Orifice, LP, (.063)		17236	Y
		Black	812-0910	
	Tauch Un Daint	Brown	210-0710	
		Espresso	Touchup-CES	
		Tuscan Olive	Touchup-CTO	
	Valve Bracket		7010-212	
	Washer, 1/4 SAE	Pkg of 24	28758/24	Y
	Wire Harness		7010-156	
		Black	WS-TIARA-BK	
		Brown	WS-TIARA-BR	
	vvarming Sneives	Espresso	WS-TIARA-CES	
		No longer available	WS-TIARA-CTO	
		-		

## Hearth & Home Technologies LIMITED LIFETIME WARRANTY

Hearth & Home Technologies, on behalf of its hearth brands ("HHT"), extends the following warranty for HHT gas, wood, pellet, coal and electric hearth appliances that are purchased from an HHT authorized dealer.

#### WARRANTY COVERAGE:

HHT warrants to the original owner of the HHT appliance at the site of installation, and to any transferee taking ownership of the appliance at the site of installation within two years following the date of original purchase, that the HHT appliance will be free from defects in materials and workmanship at the time of manufacture. After installation, if covered components manufactured by HHT are found to be defective in materials or workmanship during the applicable warranty period, HHT will, at its option, repair or replace the covered components. HHT, at its own discretion, may fully discharge all of its obligations under such warranties by replacing the product itself or refunding the verified purchase price of the product itself. The maximum amount recoverable under this warranty is limited to the purchase price of the product. This warranty is subject to conditions, exclusions and limitations as described below.

#### WARRANTY PERIOD:

Warranty coverage begins on the date of original purchase. In the case of new home construction, warranty coverage begins on the date of first occupancy of the dwelling or six months after the sale of the product by an independent, authorized HHT dealer/ distributor, whichever occurs earlier. The warranty shall commence no later than 24 months following the date of product shipment from HHT, regardless of the installation or occupancy date. The warranty period for parts and labor for covered components is produced in the following table.

The term "Limited Lifetime" in the table below is defined as: 20 years from the beginning date of warranty coverage for gas appliances, and 10 years from the beginning date of warranty coverage for wood, pellet, and coal appliances. These time periods reflect the minimum expected useful lives of the designated components under normal operating conditions.

Warrant	ty Period	HHT Manufactured Appliances and Venting								
Parts	Labor	Gas	Wood	Pellet	EPA Wood	Coal	Electric	Venting	Components Covered	
1 Year		х	х	х	х	х	х	х	All parts and material except as covered by Conditions, Exclusions, and Limitations listed	
X X X Ignit						Igniters, electronic components, and glass				
2 ye	ears	Х	Х	Х	Х	Х			Factory-installed blowers	
			Х						Molded refractory panels	
3 ye	ears			Х					Firepots and burnpots	
5 years	1 year			Х	Х				Castings and baffles	
7 years	3 years		Х	х	Х				Manifold tubes, HHT chimney and termination	
10 years	1 year	х							Burners, logs and refractory	
Limited Lifetime	3 years	Х	Х	Х	Х	х			Firebox and heat exchanger	
90 [	Days	Х	Х	Х	Х	Х	Х	Х	All replacement parts beyond warranty period	

See conditions, exclusions, and limitations on next page.

# → E. Limited Lifetime Warranty (continued)

## WARRANTY CONDITIONS:

- This warranty only covers HHT appliances that are purchased through an HHT authorized dealer or distributor. A list of HHT authorized dealers is available on the HHT branded websites.
- This warranty is only valid while the HHT appliance remains at the site of original installation.
- This warranty is only valid in the country in which the HHT authorized dealer or distributor that sold the appliance resides.
- Contact your installing dealer for warranty service. If the installing dealer is unable to provide necessary parts, contact the nearest HHT authorized dealer or supplier. Additional service fees may apply if you are seeking warranty service from a dealer other than the dealer from whom you originally purchased the product.
- Check with your dealer in advance for any costs to you when arranging a warranty call. Travel and shipping charges for parts are not covered by this warranty.

#### WARRANTY EXCLUSIONS:

This warranty does not cover the following:

- Changes in surface finishes as a result of normal use. As a heating appliance, some changes in color of interior and exterior surface finishes may occur. This is not a flaw and is not covered under warranty.
- Damage to printed, plated, or enameled surfaces caused by fingerprints, accidents, misuse, scratches, melted items, or other external sources and residues left on the plated surfaces from the use of abrasive cleaners or polishes.
- Repair or replacement of parts that are subject to normal wear and tear during the warranty period. These parts include: paint, wood, pellet and coal gaskets, firebricks, grates, flame guides, batteries and the discoloration of glass.
- Minor expansion, contraction, or movement of certain parts causing noise. These conditions are normal and complaints related to this noise are not covered by this warranty.
- Damages resulting from: (1) failure to install, operate, or maintain the appliance in accordance with the installation instructions, operating instructions, and listing agent identification label furnished with the appliance; (2) failure to install the appliance in accordance with local building codes; (3) shipping or improper handling; (4) improper operation, abuse, misuse, continued operation with damaged, corroded or failed components, accident, or improperly/ incorrectly performed repairs; (5) environmental conditions, inadequate ventilation, negative pressure, or drafting caused by tightly sealed constructions, insufficient make-up air supply, or handling devices such as exhaust fans or forced air furnaces or other such causes; (6) use of fuels other than those specified in the operating instructions; (7) installation or use of components not supplied with the appliance or any other components not expressly authorized and approved by HHT; (8) modification of the appliance not expressly authorized and approved by HHT in writing; and/or (9) interruptions or fluctuations of electrical power supply to the appliance.
- Non-HHT venting components, hearth components or other accessories used in conjunction with the appliance.
- Any part of a pre-existing fireplace system in which an insert or a decorative gas appliance is installed.
- HHT's obligation under this warranty does not extend to the appliance's capability to heat the desired space. Information is provided to assist the consumer and the dealer in selecting the proper appliance for the application. Consideration must be given to appliance location and configuration, environmental conditions, insulation and air tightness of the structure.

#### This warranty is void if:

- The appliance has been over-fired or operated in atmospheres contaminated by chlorine, fluorine, or other damaging chemicals. Over-firing can be identified by, but not limited to, warped plates or tubes, rust colored cast iron, bubbling, cracking and discoloration of steel or enamel finishes.
- The appliance is subjected to prolonged periods of dampness or condensation.
- There is any damage to the appliance or other components due to water or weather damage which is the result of, but not limited to, improper chimney or venting installation.

#### **LIMITATIONS OF LIABILITY:**

 The owner's exclusive remedy and HHT's sole obligation under this warranty, under any other warranty, express or implied, or in contract, tort or otherwise, shall be limited to replacement, repair, or refund, as specified above. In no event will HHT be liable for any incidental or consequential damages caused by defects in the appliance. Some states do not allow exclusions or limitation of incidental or consequential damages, so these limitations may not apply to you. This warranty gives you specific rights; you may also have other rights, which vary from state to state. EXCEPT TO THE EXTENT PROVIDED BY LAW, HHT MAKES NO EXPRESS WARRANTIES OTHER THAN THE WARRANTY SPECIFIED HEREIN. THE DURATION OF ANY IMPLIED WARRANTY IS LIMITED TO DURATION OF THE EXPRESSED WARRANTY SPECIFIED ABOVE.

## F. Contact Information



No one builds a better fire

Heat & Glo, a brand of Hearth & Home Technologies 7571 215<sup>th</sup> Street West, Lakeville, MN 55044 www.heatnglo.com

Please contact your Heat & Glo dealer with any questions or concerns. For the location of your nearest Heat & Glo dealer, please visit www.heatnglo.com.



We	We recommend that you record the following pertinent information for your TIARA I-C GAS STOVE				
Date purchased/installed:					
Serial Number:		Location on appliance:			
Dealership purchased from:		Dealer phone:			
Notes:					

This product may be covered by one or more of the following patents: (United States) 5601073, 5613487, 5647340, 5890485, 5941237, 6006743, 6019099, 6053165, 6145502, 6374822, 6484712, 6601579, 6769426, 6863064, 7077122, 7098269, 7258116, 7470729, 8147240 or other U.S. and foreign patents pending.

2000-945B

Printed in U.S.A. - Copyright 2013