



**STEP 1:** Carefully remove the logs from the packaging. **CAUTION:** Logs are fragile!



**STEP 2: LOG #1 (SRV2014-701):** Place log # 1 centered on the grate and pushed against the back of firebox.



**STEP 3: LOG #2 (SRV2014-703):** Place log # 2 with the left tip of the log on the flat spot on the burner and the right end pulled forward against grate.



**STEP 4: LOG #3 (SRV2014-702):** Place burned area of log #3 on the flat spot on the burner, and knob on log resting on grate.



**STEP 5: LOG #4 (SRV780-707):** Place log #4 across log #3 and resting on log #1.



**STEP 6: LOG #5 (SRV2014-704):** Place log #5 on log #1 and log #2 with burned area facing burner.