

Log Assembly: LOGS-2062
Model: QV36A-FB

LOG PLACEMENT
INSTRUCTIONS

Carefully remove the logs from the packaging. **CAUTION:** Logs are fragile!



Carefully remove the grate from the foam supports and then remove the foam supports from around the burner.



Place grate on the base of the firebox surrounding the burner. The grate should be centered on the burner and pushed back until it contacts the burner.



LOG #1: (SRV2062-701)

Place log #1 on the back of burner. Rest log on back of the grate. The notches located on the bottom of the log should rest over the back corners of burner.



LOG #2: (SRV2062-702)

Place log #2 on the burner so that the bottom of the log conforms with the contour of the burner. The outside of the log should rest on the grate. The front of the log will rest against the right andiron.



LOG #3: (SRV2062-703)

Place log #3 on the burner in the same way but on the left front of the burner.



LOG #4: (SRV330-706)

Nest log #4 in the cut-out area on the right side of log #1. The thinnest “arm” of log #4 rests on top of log #2.



LOG #5: (SRV330-704)

Place the “Y” end of log #5 against the corresponding bump on log #3. The other end of the log should rest in the second smooth cut-out area on top of log #1.



LOG #6: (SRV340-705)

Rest log #6 on the left smooth cut-out area on top of log #1 and place the lower end on log #3. The notch on the bottom of log #6 should rest on the wedge shape on the end of log #3.

