

Sleeve Kit Installation Instructions

Model: Escape-36DV

CAUTION! Risk of Cuts, Abrasions or Flying Debris.
Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.

1. Remove mesh assembly or firescreen front from your Escape-36DV.
2. Remove refractory panels (3).
3. Remove glass assembly.
4. Disconnect power supplied to the light socket assembly.
5. **Note:** The power is supplied through the junction box located to the left of the firebox.
10. Connect power supplied to the light socket assembly.
Note: Test light for operation.
11. Install burner assembly.
12. Install logs and grates.
13. Install glass assembly.
14. Install refractory panels (3).
15. Install mesh assembly or firescreen front to your Escape-36DV.

	⚠ WARNING
<p>Shock hazard.</p> <ul style="list-style-type: none">• Disconnect power to light socket assembly before proceeding with step 5.	

6. Remove logs and grate.
7. Remove burner assembly.
8. Remove and discard socket assembly and wires.
9. Install new socket assembly kit (see figure 1).

Note: Use a high temperature silicone sealant to seal the hole where the existing pilot wires and the new light wires exit the metal wrap.



Figure 1.

Please contact your Heat & Glo dealer with any questions or concerns.
For the location of your nearest Heat & Glo dealer, please visit www.heatnglo.com.

Heat & Glo, a brand of Hearth & Home Technologies Inc.
7571 215th Street West, Lakeville, MN 55044
www.heatnglo.com