

# Models: Canyon, Ridge, Peak, Mesa

## LOG PLACEMENT INSTRUCTIONS



**WARNING:** Improper log placement could cause excess sooting and/or increased carbon monoxide spillage into building.

1. Install the two grate extensions on the back of the grate. Point the extensions forward.
2. Carefully remove the two or three base logs (depending on log set) from the box.
3. Place the longer of the two base logs in the front of the grate. The shorter base log

should be placed across the elevated extensions as shown.

NOTE: The Canyon log set uses two logs to form the front base log.

4. Place the top logs as shown in the respective photographs.



**CANYON:** Note: This log set uses two logs to form the front base log



**RIDGE**



**PEAK**



**MESA**