

LOG PLACEMENT INSTRUCTIONS

Log Set Assembly: LOGS-296

Models: QV32, QV32-A

CAUTION: Logs are fragile! Carefully remove the logs from the packaging. Pull metal base pan forward before setting logs in place.



STEP 1:

Place log #1 (SRV545-710) on the back of the grate, pull forward until it contacts the two rear locator tabs and slide right to contact the right locator.



STEP 2:

Align the slot in the bottom of log #2 (SRV536-705) with the second grate bar and rest the broken end on the burner. Be sure the broken tip is pushed back and to the right to contact the locator tab on the burner.



STEP 3:

Align the slot in the right, bottom of log #3 (SRV536-706) with the fourth grate bar. Slide the log back until it contacts the two front log locator tabs.



STEP 4:

Place log #4 (SRV536-704) on the flat spots of log #1 and log #3 as shown. Place the large end of log #5 (SRV536-718) on the edge of the grate bar and rest the burned end in the slot of log #1 as shown.



STEP 5:

Place the burned end of log #6 (SRV446-715) on the flat spot of log #3 and the large end on the refractory. Place the large end of log #7 (SRV484-705) on the flat spot of log #5 and rest the burned end on the refractory.

