

Instructions for the Installation of New Handle Kit for Explorer III Cast Griddle Lid Part: EXPLR-III-KIT

To install your new handle kit simply follow these instructions.

Note: Kit is to be installed with the cast griddle lid in the upright open position.



Step 1 Installing New Receiver

Open the cast griddle lid with current handle, and then ensure current handle is discarded. Place receiver button *(C1)* in slot from topside of the cast griddle lid. Hold the receiver button *(C1)* in place while threading in the allen head screw *(C3)* with x1 washer *(C2)* (Figure 1).

Note: Make sure the appliance is cool before attempting to install Receiver kit. Figure 2 Step 3 Close Cast Griddle Top Attach griddle handle (C5) to receiver (C1) by sliding handle ensuring that the griddle handle is securely engaged (Figure 3 on page 2). Carefully lower cast griddle lid. Figure 1 **HEARTH&HOME** 1445 North Highway www.quadrafire.com Colville, WA 99114 7014-273 August 25, 2016 Page 1 of 2

Injury Risk.

- Cast griddle top is heavy.
- When griddle top is open; pinch points exist.
- Keep body parts away from pinch points.

Step 2 Tighten Receiver

Tighten the allen head screw (C3) with allen wrench (C6) as tight as possible by hand (Figure 2).



QUADRA-FIRE[®]

Instructions for the Installation of New Handle Kit for Explorer III Cast Griddle Lid (CONTINUED)

Part: EXPLR-III-KIT



Figure 3 Ψ Step 4 Install Handle Storage Hanger

Locate the slot on the lower right backside of the appliance (figure 4). Slide the handle storage hanger (*C4*) into slot.

Step 5

After handle storage hanger *(C4)* is in slot lay bracket against appliance; the magnet will hold this in place **(Figure 4)**.



1445 North Highway Colville, WA 99114 HEARTH&HOME technologies 7014-273 August 25, 2016 Page 2 of 2

www.quadrafire.com

Step 6

When not in use, place griddle handle *(C5)* on storage bracket *(C4)* as shown in **Figure 5**.



WARNING

Fire RiskDo not leave top load de

Do not leave top load door open unless loading for fuel

Description	Service Part Number
Steel Griddle Handle Assembly	SRV7060-055
Top Load Receiver (w/ fasteners & allen wrench)	SRV7060-257
Griddle Handle Holder	SRV7060-056