

VWL-30-B SET-UP INSTRUCTIONS



4004-155



4004-154



4004-153



4004-143



4004-149



4004-144



STEP ONE: PLACE 4004-155 AS SHOWN



STEP TWO: PLACE 4004-154 AS SHOWN



STEP THREE: PLACE 4004-153 AS SHOWN



STEP FOUR: PLACE 4004-143 AS SHOWN



STEP FIVE: PLACE 4004-149 AS SHOWN



STEP SIX: PLACE 4004-144 AS SHOWN