

ST-CWL-18-B SET-UP INSTRUCTIONS



(2) 4004-131



(2) 4004-132



(2) 4004-128



(2) 4004-129



4004-130

1



STEP ONE: PLACE FIRST 4004-131 AS SHOWN

2




STEP TWO: PLACE FIRST 4004-132 AS SHOWN

3



STEP THREE: PLACE SECOND 4004-131 AS SHOWN

4



STEP FOUR: PLACE SECOND 4004-132 AS SHOWN

5



STEP FIVE: PLACE FIRST 4004-128 AS SHOWN

6



STEP SIX: PLACE SECOND 4004-128 AS SHOWN

7



STEP SEVEN: PLACE FIRST 4004-129 AS SHOWN

8



STEP EIGHT: PLACE SECOND 4004-129 AS SHOWN

9



STEP NINE: PLACE 4004-130 AS SHOWN