

VERSAWOOD 30" SET UP INSTRUCTIONS (FRONT LOGS ARE REVERSABLE)







STEP ONE: PLACE SRR-27/VSA AS SHOWN




STEP TWO: PLACE 15SR/VSA AS SHOWN




STEP THREE: PLACE 15SL/VSA AS SHOWN



STEP FOUR: PLACE 17S/VSA AS SHOWN



STEP FIVE: PLACE 16N/VSA AS SHOWN



STEP SIX: PLACE 15N/VSA AS SHOWN