



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
	Electric Log Assembly	No longer available	4030-055
1	120VAC Heater Assembly (Must order both Parts)	No longer available	SRV4030-541
2	Upper Glass Retainer	No longer available	4050-104
3	Lenticular Lens	No longer available	4030-218
4	Acrylic Panel	No longer available	4030-840
5	QV32E Grate Assembly	No longer available	4038-810
6	Rock Retainer	No longer available	4030-608
7	Light Tray Assembly	No longer available	4030-219
7.1	Flame Element Kit	No longer available	SRV-020
7.2	Halogen Light	No longer available	4030-200
7.3	Motor w/Vinyl Cover Assembly	No longer available	33961
8	31 in. door Track	No longer available	4030-883
9	Screen & Rod Assembly	No longer available	4030-225
10	Door Pivot Clip		4030-050
	Fixed Ember Bed		SRV31527
	Light Receptacle	No longer available	4030-913
	Power Cord	No longer available	33962
	Reflective Flame Decal	No longer available	4030-018
	Refractory Side LH	No longer available	4021-190
	Refractory Side RH	No longer available	4030-831
	Installation Manual		4030-832
			4030-782