


#1 Front



#2 Front Glass




#3 Log/Grate



#4 Remote




#5 Heater/Control Board




#6 Rotisserie




#7 Flame Screen



#8 LED



#9 Receiver



IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Front		FRONT-INS30	
2	Front Glass		GLA-INS30	Y
3	Log/Grate Assembly		LOGS-INS30	Y
4	Remote		REMOTE-INS30	Y
5	Heater/Control Board Assembly	Control Board, Heater & Fan Included	HEATER-INS30	Y
6	Rotisserie (Rod, Motor, & Screws)		ROTISS-INS30	Y
7	Flame Screen		FLAME-INS30	
8	LED Assembly	Includes all LEDs	LED-INS30	Y
9	Receiver		RECEIVER-ELECT	Y
	Surround 40" x 27"		SF-SI4027-BK	
	Hardware Bag (Includes 2 leveling legs w/fasteners)		HRDW-BI	Y