




IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.

**Stocked
in Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Starter Collar		30399	
2	Damper Assembly		34454	
3	Top Stand Off	Qty 4 Req	SRV4044-111	
4	Upper Front Face		30395L	
5	Side Column Left		30375L	
6	Top Door Track		30400	
7	Door Clips	Qty 2 Req	SRV30407	
	Tradtional Refractory			
8	Right Side Refractory		SRV28393	
9	Back Refractory		SRV28394	
10	Left Side Refractory		SRV28393	
	Hearth Refractory		SRV28391	
	Herringbone refractory available post week 3/04			
8	Right Side Refractory	No longer available	4010-013	
9	Back Refractory	No longer available	4010-015	
10	Left Side Refractory	No longer available	4010-014	
	Hearth Refractory	No longer available	4010-020	
11	Grate		GR21	Y
12	Hearth Pan	No longer available	30405	
	Hearth Stone Retainer	Post Ak560843	30403	
13	Firescreen Rod	Qry 2 Req	SRV31375	Y
14	Screen Assembly	Qty 2 Req	SRV30371	
15	Door Pivot Clip	Qty 2 Req	SRV31527	
16	Bottom Front Face	Not replaceable must order overlay CUST4004-107	30393L	
17	Side Column Right		30376L	
	Gas Tube		SRV30412	
	Smoke Shield		30402	