

WALL SWITCHES & REMOTE CONTROLS

	CONTROLS	Wall or Remote	IPI or SP†	On/Off	Automatic Battery Backup	Battery Strength Indicator	Fan Speed	Flame Control	Flame Modulation	Pilot Activation	AUX Function	Temp Readout	Thermostat Mode	Timer Mode
IntelliFire Plus Wireless Controls	RC300 RC300-HNG	Remote w/ Docking Station	IPI	●	●	●	●	5 Steps	●	●	● (three) ‡	●	●	●
	RC200 RC200-HNG	Remote w/ Docking Station	IPI	●	●	●	●	5 Steps		●				
	RC100 RC100-HNG	Wall	IPI	●	●	●								
Wireless Controls	TotalRemote RCT-MLT-HNG	Remote	Both	●			●	●				●	●	●
	SmartRemote-Battery SMART-BATT-HNG	Remote	Both	●								●	●	●
	SmartRemote-Hardwired SMART-STAT-HNG	Remote	Both	●								●	●	●
Wired Wall Controls	TotalSwitch WSK-MLT	Wall	Both	●			●	High/Low		●	● (one)	●	●	
	IntelliSwitch200 WSK200-HNG	Wall	IPI	●	●	●	●			●				
	EasySwitch WSK-21 & WSK-21-W	Wall	Both	●										

FEATURE GLOSSARY

On/Off: Turns the flames on and off.

Automatic Battery Backup: Senses power failure and automatically switches the unit to battery operation, keeping you and your family warm.

Battery Strength Indicator: IntelliSwitch200 - red led blinks to alert homeowner that new batteries are needed; solid- on indicator signifies that the hearth system is operating on battery power. IntelliFire Plus RC100 & 200 - red led blinks when button is pressed. Lack of red led light signifies that the batteries need changed. IntelliFire Plus RC300 - Displays a battery strength icon.

Fan Speed: Adjusts the speed of the fan, pushing heat into the room.

Flame: Adjusts the height of the flames, affecting ambiance and heat output.

Pilot Activation: Changes the pilot from 'as-needed' (activated only when the fireplace is turned on) to 'constant-on' (seasonal pilot remains on to improve performance during the coldest times of the year).

AUX Function: Controls assigned auxiliary functions, such as accent lighting or electric embers.

Temp Readout: Communicates room temperature.

Thermostat Mode: Maintains the specified room temperature by adjusting the hearth system much like a furnace thermostat.

Timer Mode: Shuts flames off automatically at a pre-set time.



The IntelliFire Plus™ Ignition System is an “intelligent” control system providing energy conservation and the comfort of a roaring fire...all at your fingertips! IntelliFire Plus features intermittent pilot ignition (IPI) allowing you to conserve fuel and money when the fireplace is not in use. Optional constant pilot mode—allows you to leave the pilot flame on in cold climates. In addition, the system offers seamless transition from AC to battery backup in a power outage, as well as built-in safety features and memory settings. Lastly, our new family of IntelliFire Plus wireless controls provides stylish and ergonomic controls with the features and benefits homeowners desire.

† IPI = Intermittent Pilot Ignition
SP = Standing Pilot

‡ Fan speed is one of three auxiliary functions

HEAT & GLO

No one builds a better fire
(888) 427-3973 | heatnglo.com

HNG-1068U-0615

CONTROLS

FOR GAS FIREPLACES



HEAT & GLO

HEAT AT YOUR FINGERTIPS:
THE WARMTH OF HOME AT
YOUR CONTROL.



ENJOYING YOUR GAS HEARTH SYSTEM JUST GOT EVEN EASIER.

Heat & Glo controls are uniquely designed to conveniently start your fire with a simple, easy click. Select the control that best meets your needs and your hearth features.

A sleek wall switch stays in one convenient location while a remote control goes where you go. Wireless controls bring added convenience of handy remote access, as well as a wall docking station.

All controls are UL listed and approved for use with Heat & Glo products.



OPTIONS, OPTIONS & MORE OPTIONS

INTELLIFIRE™ PLUS WIRELESS CONTROLS

IntelliFire Plus RC300 is specifically designed for use with our new IntelliFire Plus ignition system. It is easy-to-use, stylish and ergonomic in design. Features an LCD screen, intuitive menus and large buttons. This wireless control allows flexibility for wall placement, or use as a remote only.

Models: RC300-HNG

Features: Auto Battery Backup, Pilot Activation, On/Off, 5 Step Flame Height, Fan Speed (Auxiliary 1), Two Additional Auxiliary Functions, Room Temperature Readout, Thermostat Mode, Timer Mode, Child Lock, Wall Docking Station



IntelliFire Plus RC200 is specifically designed for use with our new IntelliFire Plus ignition system. It is easy-to-use, stylish and ergonomic in design. As a wireless control, it has the flexibility for wall placement, or use as a remote only.

Models: RC200-HNG

Features: Auto Battery Backup, Pilot Activation, On/Off, 5 Step Flame Height, Fan Speed, Child Lock, Wall Docking Station



IntelliFire Plus RC100 Designed specially for fireplaces with IntelliFire Plus, our state-of-the-art intermittent pilot ignition system.

Models: RC100-HNG

Features: On/Off



WIRELESS CONTROLS

TotalRemote This remote control effortlessly manages heat output and comfort level. For fireplaces and inserts.

Models: RCT-MLT-HNG

Features: Hardwired Receiver, Timer Mode, Thermostat Mode, Room Temperature Readout, Flame High/Low, Fan Speed, On/Off



SmartRemote An added level of function and convenience in a remote control. For fireplaces, stoves, inserts, and gas logs with or without line power.

Models: SMART-BATT-HNG, SMART-STAT-HNG

Features: Battery-Powered or Hardwired Receiver, Timer Mode, Thermostat Mode, Room Temperature Readout, On/Off



WIRED WALL CONTROLS

TotalSwitch Command of both comfort and ambiance.

Model: WSK-MLT

Features: Thermostat Mode, Room Temperature Readout, Auxiliary Function, Flame High/Low, Pilot Activation, Fan Speed, On/Off



IntelliSwitch200 Designed exclusively for Heat & Glo fireplaces with IntelliFire®, our state-of-the-art intermittent pilot ignition system.

Models: WSK200-HNG

Features: Auto Battery Backup, Battery Strength Indicator, Pilot Activation, On/Off, Fan Speed



Easy Switch Controls the most basic functions of the fireplace—on/off—in the easiest way possible.

Models: WSK-21, WSK-21-W

Features: On/Off

