

Firescreen Front 8000 Series - Installation Instructions -



Leave this manual with party responsible for use and operation.



WARNING

**HOT! DO NOT TOUCH.
SEVERE BURNS MAY RESULT.
CLOTHING IGNITION MAY RESULT.**



Glass and other surfaces are hot during operation and cool down.

- Keep children away.
- CAREFULLY SUPERVISE children in same room as appliance.
- Alert children and adults to hazards of high temperatures.
- To avoid burns or clothing ignition, the doors must remain closed if children will be present during the operation and cool down of the fireplace.
- Do NOT operate with protective barriers open or removed.
- Keep clothing, furniture, draperies and other combustibles away.

Installation

Note: Keep in mind the doors are HOT while in operation.

1. Remove any existing door from fireplace.
2. Remove any packaging from the door.
3. Hang door on fireplace by inserting hooks on sides into slots on each side of glass.

Interchangeable Decorative Panels

1. The decorative panel at the bottom of this door is interchangeable with many different options.
2. To replace these panels remove door from the unit. On the back of the door, remove the two 3/8" nuts on each panel (see Figure 1). Remove the panel from the bolts.
3. Slide the mesh out of the panel and place it in the new panel. Place the new panel onto the bolts and secure with the nuts.



Figure 1

Service Replacement Parts

PARTS	UNITS		
	DF-8-FS-BK	DF-8-FS-PT	DF-8-FS-BZ
Access Panel Assembly	2056-028	2056-028	2056-028
Mesh	2056-029	2056-029	2056-029
Hood	SRV560-175	SRV560-175-PT	SRV560-175-BZ