

Model:
ODGF42BZ & ODGF50BZ Glass Door Kit



These door kits have been tested for use with specific Hearth & Home Technologies products. Check with your local building code agency before you begin installation to ensure compliance with local codes, including the need for permits and follow-up inspections. If you encounter any problems regarding code approvals, or if you need clarification of any of the instructions contained here, contact your Hearth & Home Technologies dealer. For the dealer nearest you, please visit www.hearthnhome.com.

⚠ WARNING



HOT SURFACES!

Screen/mesh, glass doors and other surfaces are hot during operation AND cool down.

Hot screen/mesh and glass doors will cause burns.

- **DO NOT** touch screen/mesh or glass doors until cooled
- NEVER allow children to touch screen/mesh or glass doors
- Keep children away
- CAREFULLY SUPERVISE children in same room as fireplace.
- Alert children and adults to hazards of high temperatures.

High temperatures may ignite clothing or other flammable materials.

- Keep clothing, furniture, draperies and other flammable materials away.

NOTICE: All fingerprints and smudges must be wiped clean from the viewable surfaces of the door kit prior to the initial burning of the fireplace. If this is not done, these prints and smudges will be cured into the finish and set for the life of the fireplace. To keep the finish looking its best, gently wipe with a soft cloth and if desired, soap and water. Never use thinner or abrasive cleaners since these products will damage the finish.


Note:

Finished openings to allow for proper door installation:

ODGF42BZ - 38 x 42 inches (965 x 1067 mm)

ODGF50BZ - 38 x 50 inches (965 x 1270 mm)

CAUTION! Risk of Cuts/Abrasions. Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.



ODGF Bifold
Glass Doors

Figure 1 ODGF Door Kits

CAUTION! The door kit is heavy. We recommend two installers to put the doors in place.

WARNING! Risk of Fire! DO NOT place combustible materials on the metal fireplace face or columns.

A. Install Doors

- Remove doors from frame by lifting up and out of the hinges on the frame. Set aside.
- Set frame in fireplace. Make sure the hinges face out.
- Line up holes in the top frame with the threaded holes on the fireplace.
- Attach the top of the frame to the fireplace with the machine screws provided. Refer to Figure 2.
- If the bottom mounting plate is not sitting flush on the hearth stone, loosen but do not remove the two nuts (one at each end) indicated in Figure 2.
- Push the bottom mounting plate down tight to the stone.
- Adjust the bottom of the door frame so it is flush with the front of the fireplace columns.
- Tighten the two adjustment screws.
- Install the two thumb screws in the mounting plate and tighten.
- Place the doors back on the hinges.
- Handles slide side to side to lock and unlock.
- Close the doors completely, then slide the handle to lock.

