

Installation Instructions

SPEAKER-KIT Models: PHOENIX42-IFT

REQUIRED TOOLS

Screw gun equipped with a #2 phillips tip

KIT COMPONENTS

- (1) Bluetooth amp
- (2) Speakers
- (1) Power supply
- (1) Wire harness
- (1) Jumper wire

INSTALLATION

CAUTION! Risk of Cuts, Abrasions or Flying Debris. Wear protective gloves and safety glasses during installation. Sheet metal edges are sharp.

- Remove logs, grate, hearth refractory and burner assembly. Refer to the appliance installation manual for removal and replacement instructions.
- 2. Install Jumper Wire on Junction Box. See Fig. 1.




Figure 1

Connect the Wire Harness (red and black banana connectors) and Power Supply lead to the rear of the Bluetooth Amp. See Fig. 2.




Figure 2

- 4. Install Bluetooth Amp in the front left corner of appliance component space.
- 5. Route the Wire Harness and Power Supply wires around the back edge of the component space.
- 6. Plug Power Supply into appliance Junction Box rear outlet. See Fig. 3.




Figure 3

7. Reinstall Burner Assembly and Hearth Refractory Brackets. Route speaker connector wires through hole in Hearth Refractory Brackets. See Fig. 4.

Caution: Do not to pinch or damage wires when reinstalling sheet metal parts.




Figure 4

8. Connect speaker wires to speakers. See Fig 5.



Figure 5

9. Attach speakers to the left and right Hearth Refractory Brackets using (8) screws provided. See Fig. 6.



Figure 6

- Reinstall hearth refractory, grate and logs. Refer to the appliance installation manual for removal and replacement instructions.
- 11. Turn amp ON/OFF switch to ON.

NOTE: If properly connected, an audible tone followed by "Bluletooth Mode" announcement will be heard.

- 12. Pair mobile device.
- 13. Download a favorite crackling fire sound or music on a mobile device and play.

Hearth & Home Technologies 7571 215th Street West, Lakeville, MN 55044 www.heatilator.com

Please contact your Hearth & Home Technologies dealer with any questions or concerns. For the location of your nearest Hearth & Home Technologies dealer, please visit www.heatilator.com.