







20802 Kensington Blvd, Lakeville, Minnesota 55044 USA

# ASSEMBLY INSTRUCTION

ITEM NO. :PCLY-4034C / 3530C

## PARTS LIST


|   |                                 | QTY |
|---|---------------------------------|-----|
| A | Hearth                          | 1   |
| B | Leg assemblies                  | 2   |
| C | Breastboard assembly            | 1   |
| D | Vertical inner frame assemblies | 2   |
| E | Horizontal inner frame assembly | 1   |
| F | Side returns                    | 2   |
| G | Cabinet top                     | 1   |
| H | Wooden dowels                   | 17  |
| I | Screws                          | 21  |
| J | Cam pins, double head           | 4   |
| K | Cams                            | 8   |
| L | Ledger boards                   | 4   |
| M | Utility screws                  | 12  |




Please note:

This cabinet is for use with ELECTRIC fireplaces wired for 110/120 volts ONLY. This cabinet SHOULD NOT be used for 208/220/240 volt applications or with gas or woodburning fireplaces.


Step 1 :



Step 2 :



Step 3 :



Step 4 :

