

VWL-24-B SET-UP INSTRUCTIONS



4004-152



4004-150



4004-151



4004-143



4004-149



4004-144

1



STEP ONE: PLACE 4004-152 AS SHOWN

2



STEP TWO: PLACE 4004-150 AS SHOWN

3



STEP THREE: PLACE 4004-151 AS SHOWN

4



STEP FOUR: PLACE 4004-143 AS SHOWN

5



STEP FIVE: PLACE 4004-149 AS SHOWN

6



STEP SIX: PLACE 4004-144 AS SHOWN