

BWL-24-B SET-UP INSTRUCTIONS



4004-165



4004-166



4004-159



4004-161



4004-162



4004-160

1



STEP ONE: PLACE 4004-165 AS SHOWN

2



STEP TWO: PLACE 4004-166 AS SHOWN

3



STEP THREE: PLACE 4004-159 AS SHOWN

4



STEP FOUR: PLACE 4004-161 AS SHOWN

5



STEP FIVE: PLACE 4004-162 AS SHOWN

6



STEP SIX: PLACE 4004-160 AS SHOWN