

BWL-30-B SET-UP INSTRUCTIONS



4004-165



4004-168



4004-159



4004-162



4004-161



4004-160



STEP ONE: PLACE 4004-165 AS SHOWN



STEP TWO: PLACE 4004-168 AS SHOWN



STEP THREE: PLACE 4004-159 AS SHOWN



STEP FOUR: PLACE 4004-162 AS SHOWN



STEP FIVE: PLACE 4004-161 AS SHOWN



STEP SIX: PLACE 4004-160 AS SHOWN