

# MWL-21-B SET-UP INSTRUCTIONS



4004-174



4004-175



4004-176



4004-177



4004-178



4004-179



1

**STEP ONE: PLACE 4004-174 AS SHOWN**



2

**STEP TWO: PLACE 4004-175 AS SHOWN**



3

**STEP THREE: PLACE 4004-176 AS SHOWN**



4

**STEP FOUR: PLACE 4004-177 AS SHOWN**



5

**STEP FIVE: PLACE 4004-178 AS SHOWN**



6

**STEP SIX: PLACE 4004-179 AS SHOWN**