


For replacement parts, please contact Dimplex at
1-800-668-6663 (Customer Service) or
1-888-346-7539 (Tech support)



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.

ITEM	DESCRIPTION	COMMENTS*	PART NUMBER
1	Thermostat		2300150100RP
2	Thermostat Knob		8800000300RP
3	Heater ON/OFF Switch	Mod A, B, None	2800070100RP
		Mod C	2800070200RP
4	Light Dimmer Knob		8800000100RP
5	Power ON/ OFF Switch		2800040100RP
6	Grill		6900080159RP
7	Glass		6900100500RP
8	Log Set		0437880200RP
9	Mirror		6900100300RP
10	Support Foot	Qty. 4 req.	8800090100RP
11	Reflector Rotisserie		6900190300RP
12	A.C. Motor		6900360100RP
13	Light Harness, Lower		2500090100RP
14	Light Harness, Upper		2500080100RP
15	Heater Assembly	No longer available	2200290600RP
16	Light Dimmer		2800020100RP

* When ordering replacement parts for your electric appliance it is important to verify the Mod of the appliance (e.g. Mod "A", Mod "B", Mod "C" or None) to ensure you receive the correct parts.