


For replacement parts, please contact Dimplex at
1-800-668-6663 (Customer Service) or
1-888-346-7539 (Tech support)



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
1	Flame Projection Panel		0437970100RP
2	Thermostat		2300150100RP
3	Thermostat Knob		8800000300RP
4	Heater ON/OFF Switch		2800070200RP
5	Flame Speed Knob		8800000200RP
6	Light Dimmer Knob		8800000100RP
7	Power ON/ OFF Switch		2800070100RP
8	Grill		6900080159RP
9	Glass		6900100500RP
10	Log Set		0437960100RP
11	Mirror		6900100300RP
12	Support Foot	Qty. 4 req.	8800090100RP
13	Reflector Rotisserie		6900190400RP
14	D.C. Motor		2000150100RP
15	Light Harness, Lower		2500090100RP
16	Light Harness, Upper		2500080100RP
17	Heater Assembly		2200290400RP
18	Light Dimmer		2800020100RP
19	Flame Speed Control		3222180300RP

