



**IMPORTANT: THIS IS DATED INFORMATION.** When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
	Electric Log Assembly	No longer available	4030-055
1	120VAC Heater Assembly (Must order both parts)	No longer available	SRV4030-541
		No longer available	4050-104
2	Upper Glass Retainer	No longer available	4030-218
3	Acrylic Panel	No longer available	4038-810
4	Molded Ember Bed	No longer available	4030-913
5	Rock Retainer	No longer available	4030-219
6	Light Tray Assembly	No longer available	SRV-020
6.1	Flame Element Kit	No longer available	4030-200
6.2	Halogen Light	No longer available	33961
6.3	Motor w/Vinyl Cover Assembly	No longer available	4030-883
7	Screen & Rod Assembly	No longer available	4030-050
8	Top Grille Assembly	No longer available	4030-028
9	Hood	No longer available	4030-530
10	Black Louver Assembly	No longer available	4030-090
11	Grate	No longer available	4030-897
12	Lenticular Lens	No longer available	4030-840
13	Power Cord	No longer available	4030-018
	Reflective Flame Decal	No longer available	4021-190
	On/Off Rocker Switch Assembly	No longer available	4030-847
	Installation Manual		4030-781