



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Electric Log Assembly	No longer available	4030-055	
1	Upper Glass Retainer	No longer available	4030-218	
2	Acrylic Panel	No longer available	4038-810	
3	Molded Ember Bed	No longer available	4030-913	
4	Rock Retainer	No longer available	4030-219	
5	Light Tray Assembly	No longer available	SRV-020	
5.1	Flame Element Kit	No longer available	4030-200	
5.2	Halogen Light	No longer available	33961	
5.3	Motor w/Vinyl Cover Assembly	No longer available	4030-883	
6	Screen & Rod Assembly	No longer available	4030-050	
7	Top Grille Assembly	No longer available	4030-028	
8	Hood	No longer available	4030-530	
9	Black Louver Assembly	No longer available	4030-090	
10	Grate	No longer available	4030-897	
11	Lenticular Lens	No longer available	4030-840	
12	Power Cord	No longer available	4030-018	
	Reflective Flame Decal	No longer available	4021-190	
	Installation Manual		4030-781	