



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER
	Electric Log Assembly	No longer available	4030-055
1	240VAC Heater Assembly	No longer available	SRV4030-539EV
2	Upper Glass Retainer	No longer available	4030-218
3	Acrylic Panel	No longer available	4038-810
4	Molded Ember Bed	No longer available	4030-913
5	Rock Retainer	No longer available	4030-219
6	Light Tray Assembly	No longer available	SRV-020
6.1	Flame Element Kit	No longer available	4030-200
6.2	Halogen Light	No longer available	33961
6.3	Motor w/Vinyl Cover Assembly	No longer available	4030-883
7	Screen & Rod Assembly	No longer available	4030-050
8	Top Grille Assembly	No longer available	4030-028
9	Hood	No longer available	4030-530
10	Black Louver Assembly	No longer available	4030-090
11	Grate	No longer available	4030-897
12	Lenticular Lens	No longer available	4030-840
13	Power Cord	No longer available	4030-018
	Reflective Flame Decal	No longer available	4021-190
	On/Off Rocker Switch	No longer available	4030-847
	Installation Manual		4030-781