



Log Set Assembly



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Log, Top L & R/Top	No longer available	SRV17229	
2	Log, Top Back Left	No longer available	18782A	
3	Log, Top Middle	No longer available	SRV18781	
4	Log, Top Back Right	No longer available	SRV18780	
5	Log, Back	No longer available	SRV18758	
6	Log, Middle	No longer available	SRV18757	
7	Log, Front	No longer available	SRV18756	
8	Burner Assy.	No longer available	18788A	
9	Log Support Bracket	No longer available	18695	
10	Ember Tray, Rear	No longer available	18698	
11	Burner Support Assy.	No longer available	18688C	
12	Bracket, Pilot	No longer available	18731D	
13	Pilot Tube		SRV446-301	Y
14	Pilot Assembly NG		SRV4021-728	Y
	Pilot Assembly LP		SRV4021-729	Y
	Thermopile		2103-512	Y
15	Igniter Bracket	No longer available	20509	
16	Igniter, Push Button		291-513	Y
17	Valve, ON/OFF		SRV15697	Y
18	Flexline		SRV302-320	Y
19	Connector, Brass	No longer available	14325/2	
20	Connector, Male	No longer available	17069A	
21	Valve NG	No longer available	18735	
	Valve LP	No longer available	25811	
22	Valve Cover	No longer available	19208C	
23	Orifice NG (.144)	No longer available	18740	
	Orifice LP (3.086)	No longer available	15648	
24	Brass Elbow		SRV17524	
25	Switch, ON/OFF Rocker	No longer available	25398	
26	Damper Stop Assy.		14354	Y
	Lava Rock		SRV4021-296	
	Mineral Wool		SRV14333	