



**Log Set Assembly**




IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.



**Stocked at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	<b>Log Assembly</b>		27793	<b>Y</b>
1	Front Bottom Left Log		SRV26623	
2	Back Left Log		SRV26621	
3	Front Top Left Log	<b>No longer available</b>	SRV17229	
4	Middle Log		SRV26620	
5	Rear Top Log	Qty 2 req	SRV26627	
6	Front Middle Log		SRV26626	
7	Middle Right Log		SRV26625	
8	Back Right Log		SRV26622	
9	Front Bottom Right Log		SRV26624	
10	Top Standoff	Qty 4 req	SRV4044-111	
11	Top End Left Face - <b>Overlay only</b>		27653	
12	End Upper Face - <b>Overlay only</b>	<b>No longer available</b>	27656	
13	End Hood	<b>No longer available</b>	27659	
14	End Screen - Qty. 2 req.	Post 17/98	29693	<b>Y</b>
15	End Glass Assembly	Qty 2 req	SRV4002-045	<b>Y</b>
16	Back Refractory	<b>No longer available</b>	31212	
17	End Lower Face - <b>Overlay only</b>	<b>No longer available</b>	25913	
18	End Bottom Front Face - <b>Overlay only</b>	<b>No longer available</b>	25914	
19	Front Bottom Front Face - <b>Overlay only</b>	<b>No longer available</b>	25916	
20	Front Lower Access Face		25893	
21	Screen		26161	<b>Y</b>
22	Glass Assembly		4002-053	<b>Y</b>
23	Hood		27658	
24	Front Upper Face - <b>Overlay only</b>		27655	
25	Top Front Face - <b>Overlay only</b>	<b>No longer available</b>	27651	
26	Top End Right Face - <b>Overlay only</b>	<b>No longer available</b>	27652	

**# 27 Electronic Ignition Valve Assembly**



IMPORTANT: THIS IS DATED INFORMATION. Parts must be ordered from a dealer or distributor. **Hearth and Home Technologies does not sell directly to consumers.** Provide model number and serial number when requesting service parts from your dealer or distributor.



**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
27.1	Ignitor	Pre 32/97	26541	Y
	Ignitor	Post 32/97	28048	Y
27.2	Bulkhead	<b>No longer available</b>	35403	
27.3	Valve, NG		SRV462-500B	Y
	Valve, LP		SRV462-501B	Y
27.4	Brass Connector - Male - Valve/Tube		13425	
27.5	Burner Supply Tube		25919	
27.6	Ignition Control Box		SRV15695	Y
27.7	Transformer		SRV20947	Y
27.8	Burner Pan Assembly		25847	Y
27.9	Burner Orifice (.115) - NG		SRV26617	Y
	Burner Orifice (.067) - LP		SRV17812	Y
27.10	Flex Line		7000-197	Y
27.11	ON/OFF Valve		SRV15697	Y

Additional service part numbers appear on following page.

