



Log Set Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Logs, Bottom	No longer available	14291A	
2	Logs, Top	No longer available	13423B	
3	Log, Top Twig	No longer available	14285B	
4	Grate Assembly	No longer available	31153	
5	Burner Pan Assembly - NG	No longer available	14184C	
	Burner Pan Assembly - LP	No longer available	14417B	
6	Pilot Assembly - NG	No longer available	14201D	
	Pilot Assembly - LP	No longer available	14206C	
7	Orifice - NG	No longer available	14202B	
8	Valve Extension Knob	No longer available	14549A	
9	Handle Extension - 3 in.	No longer available	14321B	
10	Valve	No longer available	14320B	
11	Valve Shield Assembly	No longer available	14340A	
12	Brass Connector Elbow, 90 degree		SRV4021-045	
13	Gas Tube Assembly	No longer available	14339B	
14	Brass Fitting	No longer available	14325/2	
	Air Mixer Assembly - LP	No longer available	14551A	
	Brass Male Connector - Flex	Pkg of 5	303-315/5	Y
	Burner Cap	No longer available	14322B	
	Damper Stop		14354	Y
	Flare End, 3/8 in.	No longer available	14324B	
	Valve Assembly - NG	No longer available	14304B	
	Valve Assembly - LP	No longer available	14305C	
	Lava Rock (2 lb.)		4021-296	
	Mineral Wool		SRV14333	
	Sand	No longer available	14330A	
	Vermiculite		28746	
	Installation Instructions		14335B	