



### Log Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Set Assembly	No longer available	LOGS-20	
1	Pilot Assembly NG		446-512A	Y
	Pilot Assembly LP		446-513A	Y
	Thermopile		2103-512	Y
	Pilot Tube		SRV446-301	Y
2	Valve NG		060-500	Y
	Valve LP		060-501	Y
3	Flex Gas Connector	No longer available	302-325A	
4	Wire Assembly 24 in.	No longer available	045-554A	
5	Piezo Ignitor		291-513	Y
6	ON/OFF Rocker Switch		060-521A	Y
7	Grate Assembly	No longer available	049-350A	
8	Burner NG	No longer available	049-326A	
	Burner LP	No longer available	049-325A	
	Burner Tube		567-301A	Y
	Orifice LP (#50B)	No longer available	049-801	
	Orifice NG (#56B)	No longer available	049-807	