



Log Set Assembly



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Log, Front	No longer available	SRV18759	
2	Log, Middle	No longer available	SRV18760	
3	Log, Back	No longer available	SRV18761	
4	Log, Top Left & Right	No longer available	SRV17229	
5	Log, Top Back Left	No longer available	18782A	
6	Log, Top Middle	No longer available	SRV18781	
7	Log, Top Back Right	No longer available	SRV18780	
8	Burner Assembly	No longer available	18737	
9	Ember Tray, Rear	No longer available	18697	
10	Burner Support Pan	No longer available	18689C	
11	Pilot Bracket	No longer available	18731D	
12	Pilot Assembly - NG	No longer available	14201D	
	Pilot Assembly - LP	No longer available	14206C	
13	Regulator Bracket	No longer available	18734D	
14	Regulator - NG	No longer available	18775A	
	Regulator - LP	No longer available	18773A	
15	Connector, Male	Pkg of 5	303-315/5	Y
16	Gas Tube Assembly	No longer available	14339B	
17	Connector, Brass	No longer available	14325A	
18	Damper Stop Assembly	No longer available	14354A	
19	Valve Cover	No longer available	18743D	
20	Orifice (.157) - NG	No longer available	18741	
	Orifice (.096) - LP		13844	Y
21	Elbow, Brass		SRV17524	
22	Valve	No longer available	14320B	
23	Pipe Nipple	No longer available	SRV4021-041	
24	Street Elbow, 90°	No longer available	17767A	
	Lava Rock		SRV4021-296	
	Mineral Wool		SRV14333	
	Installation Instructions		18774	