



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Left Rear Trim	No longer available	760-139	
2	Rear Hood Assembly, No Trim	No longer available	760-115A	
3	Right Rear Trim	No longer available	760-140	
4	Left Front Trim	No longer available	760-142	
5	Temperature Gauge	No longer available	760-183	
6	Front Hood Assembly, No Trim	No longer available	760-116A	
7	Right Front Trim	No longer available	760-141	
8	Warming Rack Assembly	No longer available	760-198A	
9	Hood Handle	No longer available	760-126	
10	Cooking Grids	No longer available	760-109	
11	Sear Plate	No longer available	760-108	
12	Outer Shroud back	No longer available	760-218	
13	Burner Rail	No longer available	760-117	
14	Grill Bracket	No longer available	760-148	
15	Convection Plate	No longer available	760-100	
16	Outer Shroud Left Hand	No longer available	760-219	
17	Front Panel	No longer available	760-105	
18	Operations Panel Assembly	No longer available	760-107A	
19	On/Off Switch		SRV32D0232	Y
20	Control Knob Spline Shaft	No longer available	760-195	
21	Control Knob	No longer available	760-188	
	Electrode 250C	No longer available	760-125	Y
	Logic Box	No longer available	760-189	Y
	24-Valve	No longer available	760-191	Y
22	Drip Tray	No longer available	760-106	
23	Orifice Assembly	No longer available	760-194A	
24	Burner Assembly	No longer available	760-301A	
25	Shield	No longer available	760-110	
26	Outer Shroud Right Hand	No longer available	760-220	
27	Cart Retainer	No longer available	760-221	
28	Searing Plate handle	No longer available	760-173	
29	Hose/ Regulator Assembly	No longer available	760-182	
	Meat Probe	No longer available	760-144	
	Natural Gas Conversion Kit	No longer available	NGK-PGE-24	