



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Electric Log Assembly	No longer available	4030-055	
1	120VAC Heater Assembly (Must order both Parts)	No longer available	SRV4030-541	
		No longer available	4050-104	
2	Upper Glass Retainer	No longer available	4030-218	
3	Lenticular Lens	No longer available	4030-840	
4	Acrylic Panel	No longer available	4038-810	
5	QV32E Grate Assembly	No longer available	4030-608	
6	Rock Retainer	No longer available	4030-219	
7	Light Tray Assembly	No longer available	SRV-020	
7.1	Flame Element Kit	No longer available	4030-200	
7.2	Halogen Light	Qty 2 req	33961	Y
7.3	Motor w/Vinyl Cover Assembly	No longer available	4030-883	
8	31 in. door Track	No longer available	4030-225	
9	Screen & Rod Assembly	No longer available	4030-050	
10	Door Pivot Clip		SRV31527	
	Fixed Ember Bed	No longer available	4030-913	
	Light Receptacle	No longer available	33962	
	Power Cord	No longer available	4030-018	
	Reflective Flame Decal	No longer available	4021-190	
	Refractory Side LH	No longer available	4030-831	
	Refractory Side RH	No longer available	4030-832	
	Installation Manual		4030-782	