


Log Set Assembly



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	SERIAL #	PART NUMBER	
	Log Set Assembly		LOGS-950	Y
1	Log 1		SRV530-711	N
2	Log 2		SRV402-701	N
3	Log 3		SRV560-703	N
4	Log 4		SRV560-702	N
5	Log 5		SRV560-704	N
6	Log-6		SRV569-707	N
7	Grate Assembly		560-360A	N
8	Base Refractory NG	Pre 4196	SRV560-337	N
		Post 4196	SRV560-339	N
	Base Refractory LP	Pre 1119	SRV560-337	N
		Post 1119	SRV560-339	N
9	Glass Door Assembly		GLA-950TR	Y
10	Hood		SRV560-175	N
11	Top Louver NG	Pre 6522	DF-950T	N
		Post 6522	560-256A	N
	Top Louver LP	Pre 1243	DF-950T	N
		Post 1243	560-256A	N
12	Bottom Louver NG	Pre 6522	DF-950B	N
		Post 6522	560-257A	N
	Bottom Louver LP	Pre 1243	DF-950B	N
		Post 1243	560-257A	N
13	Burner NG		560-231A	Y
	Burner LP		560-233A	Y
14	Junction Box	Standing Pilot	100-250A	Y
		DSI	100-254A	Y
	Glass Latch Assembly		386-122A	Y
	Exhaust Baffle		530-299	N
	Piezo Ignitor		291-513	Y
	Flex Ball Valve Assembly		302-320A	Y
	Orifice NG (#36A)		079-831	Y
	Orifice LP (#51A)		079-803	Y
	Mineral Wool		050-721	N
	Touch Up Paint		TUPB-12	N

Additional service part numbers appear on following page.

