


IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	Stocked at Depot
1	Burner Tube		477-301A	Y
2	Valve NG		060-500	Y
	Valve LP		060-501	Y
3	Grate Assembly		SRV526-360	
4	Piezo Ignitor		291-513	Y
5	ON/OFF, Switch		SRV32D0232	Y
6	Flex Ball Valve Assembly		302-320A	Y
7	Orifice LP (2.30 mm)		526-800	Y
	Orifice NG (1.55 mm)		526-801	Y
8	Burner	No longer available	569-701A	
	Pilot Assembly NG		446-512A	Y
	Pilot Assembly LP		446-513A	Y
	Thermopile		2103-512	Y
	Pilot Tube		SRV446-301	Y
	Single Wire Assembly 24 in.		049-555A	Y
	Wire Assembly 24 in.		089-550A	Y



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	Stocked at Depot
	Log Assembly		LOGS-STCFL	Y
9	Log 1	No longer available, Must order complete assembly	SRV569-710	
10	Log 2		SRV569-711	
11	Log 3			
12	Log 4		SRV481-755	
13	Log 5			
14	Log 6		SRV569-708	
15	Log 7		SRV569-709	
16	Log 8		SRV569-704	
17	Log 9		SRV569-706	
18	Log 10		SRV569-707	
19	Log 11		SRV569-702	
20	Log 12		SRV569-703	
21	Log 13		SRV569-705	