



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked  
at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Top Right Log V	No longer available	4004-143	
2	Top Center Log V	No longer available	4004-144	
3	Top Left Log 24" V	No longer available	4004-149	
4	Bottom Front Left Log 30" V	No longer available	4004-153	
5	Bottom Front Right Log 30" V	No longer available	4004-154	
6	Back Log 30" V	No longer available	4004-155	
	30" Versawood Installation Sheet		4004-158	