Catalytic Performance Pack - Instructions

Model: Dauntless

Kit Includes

- Ceramic Catalyst
- Temperature Probe & Bracket
- 3/16" Drill Bit
- (3) #8 Tek Screws

Install the Ceramic Catalyst

- 1. Locate the access cover positioned at the rear center of the unit, Figure 1.
- 2. Remove the access cover by pulling straight up and out, Figure 2.
- 3. Install the catalyst by gently placing it into the cavity and straight down, Figure 3. Place the catalyst where the catalyst's ceramic components will not be damaged.




Figure 1 - Locate access cover.





Figure 2 - Remove access cover.

Tools Required

- Gloves
- Drill Gun
- 1/4" Nut Driver



VERMONT CASTINGS

Figure 3 - Install catalyst.

Install the Catalyst Temperature Probe

- Install the catalyst temperature probe by removing the knockout located at the back left hand side of the unit, Figure 4.
- Once knockout is removed, drill a hole using the 3/16" Drill bit supplied in the dimple located just behind the air jacket.
- 3. Install thermostat duct, bracket and temperature probe using (2) #8 Tek screws also supplied in the kit.
- 4. Lastly, make sure to fold the bracket strap over catalyst probe and secure with remaining screw.




Figure 4 - Install the Catalyst Temperature Probe