

TOP VENT ADAPTER INSTALLATION INSTRUCTIONS

Vertical adapter and clean-out.

Part : TPVNT-6

For Free Standing Pellet Appliances



Tools Required:

Electric drill, #26 drill bit (included), #2 Phillips screwdriver, and high temp silicone (500° F).



1. Put a 1/4 inch bead of silicone on the outer edge of the appliance exhaust outlet (Figure 1). Do not apply silicone inside appliance exhaust outlet.



HEARTH & HOME technologies 7014-282A March 22, 2017 Page 1 of 2

- 2. Slide the Vent Adapter (C1) onto the exhaust outlet over 4. bead of silicone making sure the adapter is rotated into the desired position (Figure 2). Vent Adapter Figure 2 Silicone outer edge 3. Drill 2 holes with #26 drill bit (C3) through the Exhaust Outlet using the 2 holes already in the short horizontal Figure 4 pipe on the Vent Adapter as a guide. Secure using two mounting screws (C2) (Figure 3). 5. complete (Figure 5). Drill 1 hole on each side and secure with mounting screws Figure 3 Figure 5
 - 4. Put a 1/4 inch bead of silicone on the outer edge of the Vent Adapter exhaust outlet (C1) (Figure 4). Following venting manufacturing instructions, install venting to Vent Adapter (C1). (*Note: Appliance adapter from venting manufacture may be required.*) Do not apply silicone inside appliance exhaust outlet.



5. After performing regular cleaning of venting, open the clean-out cover and vacuum out debris; close when complete (**Figure 5**).

