




Please consult the manufacturer's installation manual for all details and requirements before making a final design layout decision.

# Icon I100


## 50" Wood Fireplace

MODEL	FRONT WIDTH		BACK WIDTH		HEIGHT		DEPTH		FIREPLACE OPENING
	Actual	Framing	Actual	Framing	Actual	Rough Opening Framing*	Actual	Framing	
I100	60-5/8	61-5/8	41-5/8	61-5/8	70-1/2	71	29-1/2	30-1/2	50 x 33


\* Framing must be filled in to top of front standoff after unit is installed.




Top View



Front View




Left Side View




Right Side View


**APPLIANCE LOCATION**




**MANTEL PROJECTIONS**




**MANTEL LEG/WALL PROJECTIONS**




**HEARTH EXTENSIONS**




**FRAMING DIMENSIONS**



**CLEARANCES TO COMBUSTIBLES**



**HEARTH EXTENSION CONSTRUCTION**



**PRODUCT LISTING CODES**

US UL 127

Product information provided is not complete and is subject to change without notice. Product installation must adhere strictly to instructions accompanying product to avoid risk of fire and potential injury.

Additional information can be found online at [www.heatilator.com](http://www.heatilator.com)